

[Manuals.plus](#) /

› [Lenovo](#) /

› Lenovo ThinkPad E14 Gen 2 Laptop User Manual

Lenovo 20T60020US

Lenovo ThinkPad E14 Gen 2 Laptop User Manual

Model: 20T60020US

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Lenovo ThinkPad E14 Gen 2 laptop. Please read this guide thoroughly to ensure proper use and to maximize the performance and longevity of your device.

The Lenovo ThinkPad E14 Gen 2 is a powerful and reliable notebook designed for productivity, featuring an AMD Ryzen 3 processor, 4GB of RAM, 256GB of storage, and the Windows 10 Pro operating system.

SETUP

1. Unpacking

Carefully remove your laptop and all accessories from the packaging. Ensure the following items are present:

- Lenovo ThinkPad E14 Gen 2 Laptop
- AC Power Adapter and Power Cord
- Documentation (this manual, warranty information)



Image: The Lenovo ThinkPad E14 Gen 2 laptop, typically shown with its lid closed, displaying its sleek design. This image represents the main product.

2. Connecting Power

1. Connect the power cord to the AC power adapter.
2. Plug the AC power adapter into the power connector on your laptop.
3. Plug the other end of the power cord into a working electrical outlet.

It is recommended to fully charge the battery before initial use.

3. Initial Boot and Windows 10 Pro Setup

1. Open the laptop lid and press the power button, usually located on the side or top right of the keyboard.
2. The laptop will power on and guide you through the initial setup process for Windows 10 Pro. Follow the on-screen instructions to configure language, region, network settings, and create a user account.
3. Ensure you have an active internet connection during setup to download necessary updates.

OPERATING YOUR LAPTOP

1. Power On/Off and Sleep Mode

- **Power On:** Press the power button.
- **Shut Down:** Click the Windows Start button, then Power > Shut down.
- **Restart:** Click the Windows Start button, then Power > Restart.
- **Sleep:** Close the laptop lid or click the Windows Start button, then Power > Sleep.

2. Keyboard and Touchpad

The laptop features a full-sized keyboard and a precision touchpad for navigation. Familiarize yourself with common keyboard shortcuts and touchpad gestures for efficient operation.

3. Connectivity

- **Wi-Fi:** To connect to a wireless network, click the Wi-Fi icon in the taskbar, select your desired network, and enter the password if prompted.
- **USB Ports:** Use the available USB ports to connect external devices such as mice, keyboards, or external storage drives.

4. Webcam Usage

The integrated webcam allows for video conferencing and capturing images. Access webcam functions through applications like Camera (built-in Windows app) or third-party communication software.

MAINTENANCE

1. Cleaning Your Laptop

- Use a soft, lint-free cloth slightly dampened with water or a specialized screen cleaner to clean the display.
- For the keyboard and chassis, use a soft cloth. Avoid harsh chemicals or abrasive materials.
- Regularly clean dust from vents to ensure proper airflow and prevent overheating.

2. Software Updates

Keep your Windows 10 Pro operating system and drivers updated. Windows Update automatically manages system updates. You can manually check for updates by going to Settings > Update & Security > Windows Update.

3. Battery Care

- Avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place if not used for extended periods.
- Use only the original Lenovo AC power adapter.

TROUBLESHOOTING

1. Laptop Does Not Power On

- Ensure the AC adapter is securely connected to the laptop and a working power outlet.

- Check if the power outlet is functional by plugging in another device.
- If the battery is completely drained, allow it to charge for at least 30 minutes before attempting to power on.

2. Display Issues

- If the screen is blank, try adjusting the display brightness using the function keys (Fn + F5/F6, or similar, refer to keyboard icons).
- Ensure the laptop is not connected to an external monitor that might be set as the primary display.
- Restart the laptop.

3. Wi-Fi Connectivity Problems

- Verify that Wi-Fi is enabled on your laptop (check the Wi-Fi icon in the taskbar).
- Restart your wireless router and modem.
- Ensure you are entering the correct Wi-Fi password.

4. Slow Performance

- Close unnecessary applications running in the background.
- Check for and install any pending Windows updates.
- Run a disk cleanup and defragmentation (for HDD) or optimize drives (for SSD).

SPECIFICATIONS

Feature	Detail
Brand	Lenovo
Model Number	20T60020US
Processor	AMD Ryzen 3
Operating System	Windows 10 Pro
RAM Memory	4 GB DDR4 SDRAM
Storage	256 GB (Type not specified, typically SSD)
Screen Size	Approximately 14 Inches (Note: Some listings may incorrectly state 4.7 inches)
Display Resolution	1920 x 1080 pixels (Full HD)
Graphics	Integrated AMD Graphics
Connectivity	Wi-Fi, USB
Webcam	Yes
Item Weight	1.1 Kilograms
Form Factor	Notebook
UPC	195042464061

WARRANTY INFORMATION

Your Lenovo ThinkPad E14 Gen 2 laptop typically comes with a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects and hardware failures under normal use conditions. For detailed terms and conditions, please refer to the warranty document included with your product or visit the official Lenovo support website.

SUPPORT

For further assistance, technical support, or to download the latest drivers and software, please visit the official Lenovo support website:

<https://support.lenovo.com/>

When contacting support, please have your laptop's model number (20T60020US) and serial number ready.