

Phomemo D30

Phomemo D30 Label Maker Machine User Manual

Model: D30 | Brand: Phomemo

INTRODUCTION

The Phomemo D30 Label Maker is a portable, Bluetooth-enabled mini label printer designed for various organizational and labeling needs. Utilizing thermal printing technology, it operates without ink, toner, or ribbons, offering a cost-effective and convenient labeling solution. Its compact size and rechargeable battery make it ideal for use in homes, offices, schools, and small businesses.

This device supports both continuous and fixed-length label tapes and features an upgraded German thermal print head for enhanced clarity. The accompanying mobile application provides extensive customization options, including a wide selection of symbols, frames, and fonts, along with functions for creating barcodes, QR codes, and importing data.

WHAT'S IN THE BOX

Upon unboxing your Phomemo D30 Label Maker, please verify that all components are present:

- 1 x Phomemo D30 Label Maker
- 1 x User Manual
- 1 x USB Charging Cable
- 1 x Roll of 80-PCS Pre-cut White Labels (12x40mm)



What Will You Get

1* Phomemo D30 label maker 1* User Manual
1* 80 Pre-cut white labels (12x40mm) 1* Charging Cable

Image: Contents of the Phomemo D30 Label Maker package.

SETUP GUIDE

1. Charging the Device

Before first use, fully charge your Phomemo D30 Label Maker. Connect the provided USB charging cable to the micro USB port on the device and plug the other end into a compatible USB power adapter (not included) or computer USB port. The indicator light will blink during charging and turn solid when fully charged.




Image: The Phomemo D30 Label Maker being charged via its micro USB port.

2. Downloading the Phomemo App

The Phomemo D30 operates via a dedicated mobile application. Search for "Phomemo" in your device's app store (iOS App Store or Google Play Store) and download the official application. Ensure your smartphone or tablet meets the minimum system requirements (iOS or Android).




Image: The Phomemo D30 printer and the mobile application interface.

3. Loading Label Paper

Proper loading of the label paper is crucial for optimal printing. Open the label compartment cover. Place the roll of thermal labels into the compartment, ensuring the label side faces the print head. Feed the leading edge of the label paper into the narrow slot until it is slightly visible from the output slot. Close the cover firmly. The printer will automatically adjust the label to the correct printing position.



Image: The Phomemo D30 Label Maker with label paper correctly loaded.

OPERATING INSTRUCTIONS

1. Connecting via Bluetooth

Turn on your Phomemo D30 Label Maker by pressing and holding the power button until the indicator light illuminates. Enable Bluetooth on your smartphone or tablet. Open the Phomemo app, and it will automatically search for and connect to your D30 printer. Once connected, the indicator light on the printer will be solid blue.

2. Using the Phomemo App

The Phomemo app offers a comprehensive suite of tools for label creation:

- **Text:** Enter custom text with various fonts and sizes.
- **Icons & Symbols:** Choose from over 1000 pre-loaded icons and symbols to enhance your labels.
- **Frames & Borders:** Apply decorative frames and borders (over 60 options available).
- **Barcodes & QR Codes:** Generate and print barcodes and QR codes for product identification or information sharing. Note that very long QR code data may affect print quality and readability.
- **Images:** Insert images from your device's gallery.
- **Templates:** Utilize pre-designed templates for common labeling tasks.
- **Other Functions:** Explore features like timestamps, Excel imports, scanning, OCR, and voice recognition for advanced label design.



Image: Overview of the Phomemo app's creative functions for label design.




Image: Examples of endless label styles and customization options.

3. Printing Your Labels

Once your label design is complete in the app, tap the "Print" button. The Phomemo D30 will quickly print your label. The built-in cutter allows for easy separation of labels from the roll.

Reliable Printing Quality

For Clear Texts & Images



Image: Labels printed by the Phomemo D30 on various containers.

MAINTENANCE

Cleaning the Print Head

Although the Phomemo D30 uses inkless thermal printing, regular cleaning of the print head is recommended to maintain optimal print quality and extend the device's lifespan. Use a soft, lint-free cloth lightly dampened with rubbing alcohol to gently wipe the print head. Ensure the device is turned off and disconnected from power before cleaning. Allow the print head to dry completely before closing the cover and resuming use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Poor print quality or faded text	Dirty print head; low battery; incorrect label loading; very small text/complex QR codes.	Clean the print head. Recharge the device. Ensure labels are loaded with the thermal side facing the print head. For QR codes, reduce character count or simplify design.
Labels not feeding correctly	Label roll improperly installed; cover not closed securely.	Re-install the label roll, ensuring the label side faces the print head and is fed into the slot. Close the cover firmly until it clicks. Note that some refill rolls may be wound differently (label side inward vs. outward).
Cannot connect via Bluetooth	Bluetooth is off on device/phone; printer is off or low battery; app issue.	Ensure Bluetooth is enabled on both devices. Turn the printer off and on again. Recharge the printer. Restart the Phomemo app or your phone.
Printer not responding	Low battery; device frozen.	Recharge the device. If unresponsive, press and hold the power button for 10 seconds to force a restart.

SPECIFICATIONS

Feature	Detail
Model Name	D30
Printing Technology	Thermal
Connectivity	Bluetooth 4.0
Print Resolution	203 DPI (Dots Per Inch)
Max Print Speed (Monochrome)	60 ppm
Compatible Label Width	12-15mm
Battery	Rechargeable Lithium Polymer (1000mAh)
Dimensions (D x W x H)	1.14"D x 2.95"W x 5.17"H
Item Weight	5.6 ounces (160 grams)
Supported OS	iOS, Android

WARRANTY AND SUPPORT

Phomemo offers a **Lifetime Warranty** for the D30 Label Maker, demonstrating their commitment to product quality and customer satisfaction. For any inquiries, technical assistance, or warranty claims, please contact Phomemo customer support. You can typically find contact information within the Phomemo app under the "Contact Us" section or on the official Phomemo website.

For additional resources, you may refer to the official Phomemo store:[Phomemo Store on Amazon](#).



Related Documents - D30

Quick Start Guide

D30



English

[Phomemo D30 Label Maker Quick Start Guide](#)

A quick start guide for the Phomemo D30 Label Maker, covering product introduction, getting started, replacing the paper roll, connection methods, charging, and button/indicator light instructions.

Quick Start Guide

D30



English

[Phomemo D30 Label Maker Quick Start Guide](#)

A quick start guide for the Phomemo D30 portable thermal label maker, covering unboxing, setup, app connection, paper roll replacement, and charging instructions.

Instruction

D30 Product Instruction



Please read this instruction book carefully before operating the product.

[Phomemo D30 Smart Mini Label Maker Product Instruction Manual](#)

Comprehensive user guide for the Phomemo D30 Smart Mini Label Maker, detailing item checklist, specifications, parts and features, power and indicator lights, usage instructions, app download and connection, label size identification, printing modes (Lite and Creation), daily cleaning, troubleshooting, warranty information, and FCC compliance.

Instruction

D30 Product Instruction



Please read this instruction carefully before using this product and avoid any damage.
For more detailed information, please check the official website: www.phomemo.com



Operation guide QR code

⚠️ Note: Please scan the QR code to get the printer operation guide.

Table of Contents

01	02	03	04
Packing List	Parts Description	App Download Method	Best Guide
05	06	07	08
Paper Roll Installation	Printer Connection	Confirm the Label Size	Printing Guide
09	10	11	
Product Specifications	Daily Cleaning	Solution for Common Problems	
12	13	14	
Product Warranty	FCC Caution	Warranty / Maintenance Card	

01 Packing List




Printer*1, Product instruction*1, Charging cable*1

The number of paper rolls in this list is subject to the actual shipment.

02 Parts Description Appearance Introduction

Printer display



Label paper display

Various labels available for purchase




02 Parts Description Power Button and Indicator Light



Power button description		
Button	Operation method	Function
Power button	Press and hold 2s	Turn on/off
Touch button	Touch	Press the touch button
Stroke button	Stroke	Press the stroke button

Power indicator status		
Green light on	Normal status (printing)	
Green light slowly	Charging with power on	
Green light quickly	Charging with power on	
Red light on	Low level of paper, cover opened, high temperature	
Red light slowly	Low battery	
Red light quickly	Low battery	

03 App Download Method



New functions will be updated with new functions in regular phone calls to the actual device.

Function	Description
1	Click to select the text, then click the text, highlighting and select various functions.
2	Click to select the text, then click the text, highlighting and select various functions.
3	Click to select the text, then click the text, highlighting and select various functions.
4	Click to select the text, then click the text, highlighting and select various functions.
5	Click to select the text, then click the text, highlighting and select various functions.
6	Click to select the text, then click the text, highlighting and select various functions.
7	Click to select the text, then click the text, highlighting and select various functions.
8	Click to select the text, then click the text, highlighting and select various functions.
9	Click to select the text, then click the text, highlighting and select various functions.
10	Click to select the text, then click the text, highlighting and select various functions.
11	Click to select the text, then click the text, highlighting and select various functions.
12	Click to select the text, then click the text, highlighting and select various functions.
13	Click to select the text, then click the text, highlighting and select various functions.
14	Click to select the text, then click the text, highlighting and select various functions.
15	Click to select the text, then click the text, highlighting and select various functions.
16	Click to select the text, then click the text, highlighting and select various functions.
17	Click to select the text, then click the text, highlighting and select various functions.
18	Click to select the text, then click the text, highlighting and select various functions.
19	Click to select the text, then click the text, highlighting and select various functions.
20	Click to select the text, then click the text, highlighting and select various functions.

Click the print label after editing. When the printing is completed, the label is printed.



9. Product Specifications

Product name	Small Label Printer
Product model	SL1
Printing technology	Thermal printing
Effective printing width	12.5mm
Supportable materials	Pre-cut paper, black and white paper, continuous paper
Printing density	1.25 dots/mm
Printing resolution	1200 dpi
Print head service life	100000
Communication interface	Bluetooth 4.2
Product size	110 (L) x 70 (W) x 30 (H) mm
Power source	5V/1A
Power supply method	Micro USB
Supportable operating system	Android, iOS

10. Daily Cleaning

Turn off the printer. Use a cotton swab dipped in a little alcohol.



Wipe the print head gently. Do not touch the print head with your fingers. If the print head is dirty, it will affect the printing quality.



Do not touch the print head with your fingers. If the print head is dirty, it will affect the printing quality.

11. Solutions for Common Problems, etc.

Not centered, misplaced, offset, skipped, etc.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.

Please make sure that the paper roll is correctly placed in the machine.



[Phomemo D30 Small Label Printer Instruction Manual](#)

Discover the Phomemo D30 Small Label Printer user manual, providing comprehensive instructions for setup, operation, app connectivity, paper installation, printing guides (Lite and Creation modes), product specifications, daily cleaning, and troubleshooting common issues. Optimize your labeling tasks with this portable thermal printer.



[Phomemo D30 Small Label Printer User Manual and Setup Guide](#)

Comprehensive user manual for the Phomemo D30 Small Label Printer, covering product features, app download, boot guide, paper roll installation, printer connection, printing instructions (Lite and Creation modes), product specifications, daily cleaning, troubleshooting common problems, warranty information, and FCC caution.