

Midea MAF20P0BPK

Midea 2L Air Fryer Instruction Manual

MODEL: MAF20P0BPK

[Safety](#) [Overview](#) [Setup](#) [Operating](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#)

[Support](#)

1. Important Safety Instructions

Please read all instructions carefully before using the Midea 2L Air Fryer. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the voltage indicated on the appliance matches your local power supply. Do not immerse the cord, plug, or appliance in water or other liquids.
- **Placement:** Place the air fryer on a stable, heat-resistant surface, away from walls and other appliances to allow for proper air circulation. Do not place near flammable materials.
- **Operation:** Do not overfill the basket. Hot steam is released during operation; keep hands and face away from the air outlet. The appliance surfaces become hot during use. Use oven mitts when handling hot components.
- **Children:** This appliance is not intended for use by children. Close supervision is necessary when any appliance is used near children.
- **Maintenance:** Always unplug the appliance and allow it to cool completely before cleaning. Do not use abrasive cleaners or scouring pads.
- **Damage:** Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any manner. Contact customer support for assistance.

2. Product Overview

The Midea 2L Air Fryer is designed for healthy cooking with minimal oil. Its compact design makes it suitable for small kitchens and easy storage.

DU CONGELÉ AU DORÉ EN QUELQUES MINUTES

360°

Circulation d'air à

58%

d'économie d'énergie



Figure 1: Midea 2L Air Fryer. This image shows the compact design of the air fryer with its main body and the cooking basket partially pulled out.

Components:

- **Temperature Control Knob:** Adjusts cooking temperature from 80°C to 200°C.
- **Timer Knob:** Sets cooking time up to 60 minutes. Features an automatic shut-off.
- **Cooking Basket:** Removable, non-stick basket for holding food.
- **Crisper Plate:** Removable, non-stick plate inserted into the basket for optimal air circulation and crisping.
- **Air Outlet:** Located at the rear of the appliance for hot air release.



Figure 2: Key features of the Midea Air Fryer. This image highlights the mechanical control knob, the non-stick interior coating being cleaned, and a graphic indicating the product is BPA and PFOA free.

3. Setup and First Use

Before First Use:

1. Remove all packaging materials and stickers from the appliance.
2. Clean the cooking basket and crisper plate thoroughly with hot water, dish soap, and a non-abrasive sponge. Rinse and dry completely.
3. Wipe the exterior of the appliance with a damp cloth.
4. Place the air fryer on a stable, level, heat-resistant surface. Ensure there is at least 10 cm (4 inches) of free space around the back and sides, and above the appliance for proper ventilation.

Preheating (Optional but Recommended):

Preheating helps ensure even cooking and better results.

1. Plug the air fryer into a grounded wall outlet.
2. Set the temperature knob to your desired cooking temperature (e.g., 180°C / 350°F).
3. Set the timer knob to 3-5 minutes. The power indicator light will turn on.
4. Once the timer rings, the air fryer is preheated.

4. Operating the Air Fryer

The Midea 2L Air Fryer offers a 5-in-1 multi-cooker functionality for frying, grilling, baking, roasting, and defrosting.

General Operation:

1. Place the crisper plate inside the cooking basket.
2. Place your food into the cooking basket. Do not exceed the MAX fill line.
3. Slide the cooking basket back into the air fryer until it clicks into place.
4. Set the desired temperature using the temperature control knob (80°C to 200°C).
5. Set the desired cooking time using the timer knob (up to 60 minutes). The power and heating indicator lights will illuminate.
6. The air fryer will automatically shut off when the timer reaches zero, indicated by an audible ring.
7. Carefully pull out the basket and remove the cooked food. Use heat-resistant utensils.

Cooking Tips:

- For best results, shake the basket halfway through cooking for items like fries or chicken nuggets to ensure even browning.
- Some foods may require a small amount of oil (1-2 teaspoons) for extra crispiness, but many can be cooked without any added oil.
- Refer to the quick cooking guide for recommended times and temperatures for common foods.



Figure 3: Quick Cooking Guide. This image displays recommended cooking times and temperatures for various foods such as fries, chicken wings, pizza, cake, vegetables, and meat.



Figure 4: 12 Cooking Options. This image illustrates various food types that can be prepared, including defrosting, fries, chicken wings, drumsticks, fish, shrimp, vegetables, sweet potato, meat, pizza, cake, and egg tarts.



Figure 5: Healthy Cooking with Less Oil. This image demonstrates the air fryer's ability to cook crispy fries with up to 90% less oil compared to traditional frying methods.

5. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Basket and Crisper Plate:** The removable cooking basket and crisper plate have a non-stick coating and are dishwasher safe. Alternatively, wash them with hot water, dish soap, and a non-abrasive sponge.
3. **Interior:** Wipe the interior of the appliance with a damp cloth. For stubborn food residue, use a mild detergent and a soft brush. Ensure the interior is dry before next use.
4. **Exterior:** Wipe the exterior with a damp cloth. Do not use abrasive cleaners or harsh chemicals.
5. **Storage:** Store the cleaned and dried air fryer in a cool, dry place.

LAVABLE AU LAVE -VAISSELLE POUR UN NETTOYAGE FACILE



Figure 6: Dishwasher Safe Components. This image shows the removable cooking basket and crisper plate placed in a dishwasher rack, highlighting their easy cleaning feature.

6. Troubleshooting

If you encounter any issues with your Midea Air Fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in. Timer not set.	Ensure the power cord is securely plugged into a grounded outlet. Set the timer to the desired cooking time.
Food is not cooked evenly.	Basket is overfilled. Food not shaken.	Do not overfill the basket. Shake the basket halfway through cooking for even results.
Food is not crispy.	Not enough cooking time or high enough temperature. Food too moist.	Increase cooking time or temperature. Pat food dry before cooking. A light spray of oil can help.
White smoke coming from the appliance.	Grease residue from previous use.	Clean the basket and crisper plate thoroughly after each use to remove grease buildup.
Appliance smells during first use.	Manufacturing residue burning off.	This is normal for first use and will dissipate. Ensure good ventilation.

7. Product Specifications

Technical details for the Midea 2L Air Fryer (Model MAF20P0BPK).

Feature	Detail
Model Number	MAF20P0BPK
Capacity	2 Liters
Power Output	1150 Watts
Voltage	230 Volts
Temperature Range	80°C to 200°C (176°F to 392°F)
Timer	Up to 60 minutes with automatic shut-off
Control Method	Tactile (Rotary Knobs)
Dimensions (L x W x H)	21.8 x 21.8 x 23.2 cm (8.6 x 8.6 x 9.1 inches)
Weight	2.65 Kilograms (5.84 lbs)
Material	Plastic (Exterior and Interior)
Special Features	Healthy cooking, Non-stick coating, Dishwasher safe components, BPA-free
Color	Black
Country of Origin	China

8. Warranty and Customer Support

Midea products are manufactured to high-quality standards. For warranty information, please refer to the warranty card included with your purchase or visit the official Midea website.

If you have any questions, require technical assistance, or need to report a problem with your Midea 2L Air Fryer, please contact Midea customer support. Contact details can typically be found on the Midea official website or in your product packaging.

When contacting support, please have your product model number (MAF20P0BPK) and purchase date available.