

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Linksys](#) /
- › [Linksys MR9600 AX6000 Mesh WiFi 6 Router User Manual](#)

Linksys MR9600

Linksys MR9600 AX6000 Mesh WiFi 6 Router User Manual

Model: MR9600-RM2

1. INTRODUCTION

This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your Linksys MR9600 AX6000 Mesh WiFi 6 Router. Please read this guide thoroughly before using the device to ensure optimal performance and network stability.



Image 1.1: Front view of the Linksys MR9600 AX6000 Mesh WiFi 6 Router, showcasing its sleek design and four external antennas.



Image 1.2: Side view of the Linksys MR9600 AX6000 Mesh WiFi 6 Router, highlighting its ventilation design and antenna placement.

2. PACKAGE CONTENTS

Ensure all items are present in your package:

- Linksys MR9600 AX6000 Mesh WiFi 6 Router
- Power Adapter
- Ethernet Cable
- Quick Start Guide (if included)

Note: The product may include a battery pack as listed in some specifications, but it is typically for internal clock or memory backup and not user-replaceable.

3. SETUP INSTRUCTIONS

Follow these steps to set up your Linksys MR9600 router:

3.1. Physical Connection

1. **Position the Router:** Place your router in a central location, away from obstructions and devices that may cause interference (e.g., cordless phones, microwaves).
2. **Connect to Modem:** Connect one end of the provided Ethernet cable to the yellow 'Internet' port on the back of your MR9600 router. Connect the other end to your modem's Ethernet port.
3. **Connect Power:** Plug the power adapter into the router's '12V' power port and then into an electrical outlet. The LED on the front of the router will light up. Wait for it to turn solid blue, indicating it is ready for setup.



FUTURE-READY WIFI

Flexible, scalable and ready for tomorrow. Expand or adjust your network as your needs change.

Image 3.1: Rear view of the Linksys MR9600 router, illustrating the Internet (yellow), Ethernet (blue), USB, Reset, and Power ports.

3.2. Software Setup (Using Linksys App)

The easiest way to set up your router is using the Linksys App:

1. **Download the App:** Download the Linksys App from the Apple App Store or Google Play Store on your smartphone or tablet.
2. **Launch the App:** Open the Linksys App and tap 'Set Up a New Wi-Fi Network'.
3. **Follow On-Screen Instructions:** The app will guide you through connecting to the router's temporary Wi-Fi network, creating your new network name (SSID) and password, and configuring other settings.




Image 3.2: Screenshot of the Linksys App interface, showing options for setting up a Mesh WiFi Router and other network types.

3.3. Web-Based Setup

Alternatively, you can use a web browser for setup:

1. **Connect a Device:** Connect a computer to one of the router's blue Ethernet ports or connect wirelessly to the default Wi-Fi network (SSID and password are on the bottom of the router).
2. **Open Browser:** Open a web browser and navigate to <http://linksysmartwifi.com> or the router's default IP address (usually 192.168.1.1).
3. **Follow Instructions:** Follow the on-screen prompts to configure your network settings.

4. OPERATING INSTRUCTIONS

Understanding the features of your Linksys MR9600 router for optimal network management.

4.1. Intelligent Mesh Technology

The MR9600 utilizes Intelligent Mesh Technology to provide seamless, whole-home Wi-Fi coverage, eliminating dead zones

and buffering. It can cover up to 3,000 square feet and support over 40 devices.



Image 4.1: A Linksys router on a desk next to a laptop, illustrating the concept of Intelligent Mesh Technology providing 3000 sq ft of coverage.



LINKSYS
Intelligent
Mesh™

Eliminates dead zones and buffering with reliable Wi-Fi that seamlessly connects your entire home.



Image 4.2: A diagram depicting a house with Linksys Intelligent Mesh coverage, indicating elimination of dead zones and reliable Wi-Fi throughout the home.

4.2. Wi-Fi 6 (802.11ax) Performance

This router supports the latest Wi-Fi 6 standard, offering speeds up to 6.0 Gbps for efficient streaming, gaming, and high-bandwidth activities across multiple devices.



Image 4.3: A person holding a game controller, with graphics indicating Wi-Fi 6 technology and speeds up to 6 Gbps, suitable for streaming, gaming, and non-stop entertainment.




Image 4.4: A hand holding a TV remote control, with circular graphics indicating support for 40+ devices and 4K/8K streaming capabilities.

4.3. Advanced Features (via Linksys App)

The Linksys App provides convenient control over your network:

- **Device Prioritization:** Allocate bandwidth to specific devices for critical tasks like gaming or video calls.
- **Parental Controls:** Manage internet access and content for connected devices.
- **Guest Access:** Create a separate, secure Wi-Fi network for guests without sharing your main network password.

5. MAINTENANCE

Regular maintenance ensures your router operates efficiently.

- **Firmware Updates:** Periodically check for and install firmware updates through the Linksys App or web interface. Updates provide security enhancements and performance improvements.
- **Router Placement:** Ensure the router remains in an open, central location for optimal signal distribution. Avoid placing it near large metal objects or other electronics that could cause interference.

- **Rebooting:** If you experience network issues, try rebooting the router by unplugging its power adapter for 10 seconds and then plugging it back in.

6. TROUBLESHOOTING

Common issues and their solutions.

6.1. No Internet Connection

- **Check Cables:** Ensure all Ethernet cables are securely connected to the router and modem.
- **Modem Status:** Verify your modem is working correctly and has an active internet connection.
- **Reboot Devices:** Power cycle your modem first, wait 60 seconds, then power cycle your router.
- **ISP Outage:** Contact your Internet Service Provider (ISP) to check for local outages.

6.2. Slow Speeds or Dropped Connections

- **Router Placement:** Move the router to a more central location, away from interference.
- **Interference:** Identify and move devices that might cause interference (e.g., microwaves, cordless phones).
- **Firmware:** Ensure your router's firmware is up to date.
- **Device Overload:** Too many devices actively using the network can reduce speeds. Consider prioritizing critical devices using the Linksys App.

6.3. Factory Reset

A factory reset restores the router to its original factory settings. This will erase all custom configurations, including your Wi-Fi name and password.

1. With the router powered on, press and hold the 'Reset' button on the back of the router for 10-15 seconds using a paperclip or similar pointed object.
2. Release the button when the LED on the front starts flashing.
3. Wait for the router to reboot. You will then need to set up the router again as if it were new.

7. SPECIFICATIONS

Feature	Detail
Brand	Linksys
Model Number	MR9600-RM2
Product Dimensions	11.82 x 6.67 x 2.26 inches
Item Weight	3.47 pounds
Wireless Standard	802.11ax (Wi-Fi 6)
Frequency Band Class	Dual-Band
Connectivity Technology	Ethernet, Wi-Fi
Special Feature	WPS (Wi-Fi Protected Setup)
Recommended Uses	Gaming, 4K/8K Streaming

Coverage	Up to 3,000 sq. ft.
Supported Devices	40+

8. WARRANTY AND SUPPORT

8.1. Warranty Information

This product is often sold as an Amazon Renewed item. Amazon Renewed products are eligible for replacement or refund under the [Amazon Renewed Guarantee](#) if you are not satisfied with your purchase. For specific warranty details from Linksys, please refer to the documentation included with your product or visit the official Linksys website.

8.2. Technical Support

For further assistance, technical support, or to access the latest drivers and firmware, please visit the official Linksys support website:

www.linksys.com/support