

[Manuals.plus](#) /

› [Parkside](#) /

› Parkside PFS 400 A1 Electric Paint Spray System - Instruction Manual

## Parkside PFS 400 A1

# Parkside PFS 400 A1 Electric Paint Spray System - Instruction Manual

Model: PFS 400 A1 | Brand: Parkside

## 1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Parkside PFS 400 A1 Electric Paint Spray System. Please read this manual thoroughly before first use and keep it for future reference.

## 2. SAFETY WARNINGS

**WARNING:** Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Use the paint spray system in a well-ventilated area to prevent the accumulation of hazardous fumes.
- Avoid direct contact of paint or cleaning solutions with skin and eyes. Wear appropriate personal protective equipment (PPE) such as gloves, safety glasses, and a respirator.
- Keep the appliance out of reach of children and pets.
- Ensure the work area is free from ignition sources, as many paints and solvents are flammable.
- Always disconnect the power supply before cleaning, maintenance, or when not in use.

## 3. PRODUCT OVERVIEW AND COMPONENTS

The Parkside PFS 400 A1 is an electric paint spray system designed for uniform application of paint, varnishes, and glazes on various surfaces.



Figure 1: Parkside PFS 400 A1 Electric Paint Spray System. This image shows the main unit, consisting of the motor housing, handle, spray gun assembly, and the detachable paint container.

**Included Components:**



Figure 2: Accessories included with the paint spray system. From left to right: viscosity measuring cup, cleaning brush, cleaning needle, two nozzles (1.8mm and 2.6mm), and a filter.

- Main Spray Unit (with 900 ml detachable tank)
- 2 Nozzles (1.8 mm and 2.6 mm)
- 1 Viscosity Measuring Cup
- 1 Cleaning Brush
- 1 Cleaning Needle
- Filter Material

## 4. SETUP

1. **Prepare the Work Area:** Ensure the area is clean, well-ventilated, and adequately lit. Cover any surfaces not intended for painting.
2. **Prepare the Paint:** The system is suitable for commercial paints, varnishes, and glazes with a viscosity up to 70 DIN seconds.
  - Use the included viscosity measuring cup to check the paint's consistency. Fill the cup with paint and time how long it takes for the liquid to flow out completely. Refer to your paint manufacturer's recommendations for optimal viscosity.
  - If the paint is too thick, dilute it according to the paint manufacturer's instructions.

3. **Fill the Paint Tank:** Unscrew the 900 ml paint tank from the spray gun. Fill it with the prepared paint. Do not overfill. Securely reattach the tank to the spray gun.
4. **Select the Nozzle:** Choose between the 1.8 mm and 2.6 mm nozzles based on the paint type and desired spray pattern. The 2.6 mm nozzle is generally for thicker paints or larger coverage, while the 1.8 mm nozzle is for finer finishes.
5. **Adjust Spray Pattern:** The spray gun offers 3 independently adjustable spray modes:
  - **Round Jet:** For small areas or edges.
  - **Flat Jet (Horizontal):** For horizontal surfaces.
  - **Flat Jet (Vertical):** For vertical surfaces.

Adjust the nozzle cap to achieve the desired pattern.

## 5. OPERATING INSTRUCTIONS

1. **Power Connection:** Connect the power cord to a suitable electrical outlet.
2. **Test Spray:** Before painting your actual surface, perform a test spray on a piece of cardboard or scrap material. This allows you to fine-tune the spray pattern and flow rate.
3. **Spraying Technique:**
  - Hold the spray gun at a consistent distance (typically 15-30 cm) from the surface.
  - Move the spray gun smoothly and evenly across the surface, overlapping each pass slightly to ensure uniform coverage.
  - Avoid tilting the spray gun excessively, especially when the paint level in the tank is low, to prevent air from entering the suction tube.
  - Release the trigger at the end of each pass to prevent paint buildup.
4. **Applying Paint:** The system provides uniform application on both smooth and structured surfaces.



Figure 3: The Parkside PFS 400 A1 Electric Paint Spray System being used to apply paint to a radiator, demonstrating its capability for structured surfaces.

5. **Finishing:** Once painting is complete, disconnect the power supply immediately. Proceed to the cleaning section.

## 6. MAINTENANCE AND CLEANING

Proper cleaning after each use is crucial for the longevity and performance of your paint spray system.

1. **Empty the Paint Tank:** Pour any remaining paint back into its original container.
2. **Initial Rinse:** Fill the tank with an appropriate cleaning solution (water for water-based paints, mineral spirits or paint thinner for oil-based paints). Spray the cleaning solution through the gun until it runs clear. Do this in a well-ventilated area or outdoors.
3. **Disassemble and Clean Components:**
  - Unscrew the paint tank and clean it thoroughly with the cleaning solution and the included cleaning brush.
  - Remove the nozzle and air cap. Clean them using the cleaning brush and cleaning needle to remove any dried paint. Ensure all small holes are clear.
  - Clean the suction tube and filter.
  - Wipe down the exterior of the spray gun with a damp cloth. Do not immerse the motor unit in liquid.
4. **Dry and Reassemble:** Allow all components to dry completely before reassembling the spray gun. Store the unit in a clean, dry place.

## 7. TROUBLESHOOTING

This section addresses common issues you might encounter with your paint spray system.

Problem	Possible Cause	Solution
No spray or weak spray	Nozzle clogged, paint too thick, air vent blocked, low paint level.	Clean nozzle and air cap. Dilute paint. Check and clear air vent on tank. Refill paint tank.
Uneven spray pattern	Nozzle partially clogged, incorrect nozzle adjustment, inconsistent spraying distance.	Clean nozzle. Adjust nozzle cap for desired pattern. Maintain consistent distance from surface.
Paint drips or runs	Paint too thin, spraying too close, applying too much paint.	Thicken paint if necessary. Increase spraying distance. Apply thinner coats.
Motor not starting	No power, faulty connection.	Check power outlet and cord. Ensure connections are secure. If problem persists, contact customer support.

## 8. SPECIFICATIONS

Feature	Detail
Model	PFS 400 A1
Rated Power	400 W
Max. Flow Rate	800 ml/min
Tank Volume	900 ml
Nozzle Sizes	1.8 mm, 2.6 mm
Dimensions (L x D x H)	28.4 x 29.6 x 13.4 cm (approx.)
Weight	Approx. 1.32 kg (paint spray system)
Material (Housing)	Polyamide, Fiberglass (PA6 + GF30)
Material (Tank)	High-Density Polyethylene (HDPE)

## 9. WARRANTY AND SUPPORT

For warranty claims, technical support, or spare parts, please refer to the warranty card included with your product or contact the manufacturer directly. Keep your proof of purchase for any warranty-related inquiries.

