



[Manuals.plus](#) /

› [YEDI HOUSEWARE](#) /

› [YEDI HOUSEWARE GV030 Air Fryer User Manual](#)

YEDI HOUSEWARE GV030

YEDI HOUSEWARE GV030 Air Fryer User Manual

Model: GV030 | 2-Quart Capacity

[Product Overview](#)

[Important Safeguards](#)

[Parts & Features](#)

[Before First](#)

[Use](#) [Setup](#) [Operation](#) [Cleaning & Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. PRODUCT OVERVIEW

The YEDI HOUSEWARE GV030 Air Fryer is a compact 2-quart (1.86 L) appliance designed for efficient air frying. It features a temperature range of 180°F to 400°F and a cooking timer up to 30 minutes, controlled by easy-to-use analog dials. The unit includes a removable pot with a non-stick coating and a removable inner tray for convenient cooking and cleaning.



Figure 1: Front view of the YEDI HOUSEWARE GV030 Air Fryer, showcasing its compact design and control dials.

2. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.

- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

3. PARTS AND FEATURES

Familiarize yourself with the components of your YEDI HOUSEWARE GV030 Air Fryer:

1. **Main Unit:** The primary housing of the air fryer.
2. **Temperature Control Dial:** Located on the front, used to set the cooking temperature from 180°F to 400°F.
3. **Timer Dial:** Located on the top, used to set the cooking time up to 30 minutes.
4. **Removable Pot/Basket:** The main cooking container with a non-stick coating.
5. **Removable Inner Tray:** Sits inside the pot, allowing air circulation around food and collecting excess oil.
6. **Handle:** For safely pulling out the pot/basket.
7. **Power Indicator Light:** Illuminates when the unit is powered on.
8. **Heating Indicator Light:** Illuminates when the heating element is active.



Figure 2: Top-down view highlighting the temperature and timer dials for precise control.



Figure 3: The YEDI HOUSEWARE GV030 Air Fryer shown with its packaging and the included removable inner tray.

4. BEFORE FIRST USE

Before using your air fryer for the first time, it is important to prepare it properly to ensure optimal performance and eliminate any manufacturing odors.

1. **Unpack:** Carefully remove all packaging materials from the air fryer and its accessories.
2. **Clean Components:** Wash the removable pot and inner tray thoroughly with warm, soapy water. Rinse well and dry completely. The main unit should be wiped with a damp cloth. Do not immerse the main unit in water.
3. **Initial Burn-Off:** To eliminate any potential manufacturing odors (often described as a "chemical" or "burning rubber" smell by some users), perform an initial burn-off cycle:
 - Place the empty pot and inner tray back into the air fryer.
 - Plug the air fryer into a grounded electrical outlet.
 - Set the temperature dial to 400°F (200°C).
 - Set the timer dial to 5-10 minutes.
 - Allow the unit to run in a well-ventilated area. A slight odor or smoke may be present during this initial use; this is normal and will dissipate.
 - Repeat this process 2-3 times if the odor persists.
4. **Final Cleaning:** After the burn-off cycles, allow the unit to cool completely. Re-wash the pot and inner tray with warm, soapy water and a small amount of vinegar to further neutralize any lingering smells. Wipe down the interior

of the main unit with a damp cloth.

Your air fryer is now ready for use.

5. SETUP

Follow these steps to set up your air fryer for cooking:

1. **Placement:** Place the air fryer on a stable, flat, heat-resistant surface. Ensure there is at least 6 inches (15 cm) of clear space around the back and sides of the unit for proper ventilation.
2. **Insert Tray:** Ensure the removable inner tray is properly seated inside the removable pot.
3. **Insert Pot:** Slide the assembled pot and tray firmly into the main unit until it clicks into place.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. The power indicator light will illuminate.

6. OPERATING INSTRUCTIONS

The YEDI HOUSEWARE GV030 Air Fryer uses rapid air circulation technology to cook food with little to no oil.

6.1. Basic Operation

1. **Prepare Food:** Place your desired food items into the air fryer pot, ensuring not to overfill. For best results, food should be in a single layer or shaken periodically.
2. **Set Temperature:** Turn the temperature control dial to your desired cooking temperature (180°F - 400°F).
3. **Set Timer:** Turn the timer dial to your desired cooking time (up to 30 minutes). The air fryer will begin heating immediately. The heating indicator light will illuminate.
4. **Cooking Process:** The air fryer will automatically turn off once the set time has elapsed, and a bell will sound. The heating indicator light will turn off.
5. **Check Food:** Carefully pull out the pot using the handle. Use tongs to remove cooked food.
6. **Shake/Flip (Optional):** For even cooking, especially with larger quantities or certain foods like fries, pull out the pot halfway through the cooking time and gently shake or flip the food. Then, reinsert the pot to resume cooking.



Figure 4: The air fryer basket pulled out, showing crispy french fries ready for serving.



Figure 5: The air fryer basket containing roasted brussels sprouts, demonstrating its versatility for vegetables.



Figure 6: The YEDI HOUSEWARE GV030 Air Fryer displayed with a variety of air-fried dishes, including vegetables, chicken, and fries.

6.2. Cooking Tips

- For crispier results, lightly spray or toss food with a small amount of oil before air frying.
- Do not overcrowd the basket. Cook in batches if necessary to ensure even cooking and crispiness.
- Smaller food items typically require shorter cooking times than larger ones.
- Preheating the air fryer for 3-5 minutes at the desired temperature can improve cooking results.
- You can adjust the time and temperature dials at any point during the cooking process.

7. CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and optimal performance of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Clean Pot and Tray:** The removable pot and inner tray should be hand washed with warm, soapy water. Use a non-

abrasive sponge or cloth to protect the non-stick coating. Do not use abrasive cleaning materials or metal utensils. Rinse thoroughly and dry completely.

3. **Clean Main Unit:** Wipe the exterior of the air fryer with a damp cloth. For the interior, gently wipe with a damp cloth and mild detergent if necessary. Never immerse the main unit in water or any other liquid.
4. **Storage:** Ensure all parts are clean and dry before storing. Store the air fryer in a cool, dry place.

Important: The pot and inner tray are not dishwasher compatible. Hand washing is required.

8. TROUBLESHOOTING

If you encounter issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet issue; timer not set.	Ensure the power cord is securely plugged into a working outlet. Turn the timer dial to the desired cooking time.
Food is not cooked evenly.	Basket is overcrowded; food not shaken/flipped.	Cook in smaller batches. Shake or flip food halfway through cooking.
Food is not crispy.	Too much moisture; not enough oil; basket overcrowded.	Pat food dry before cooking. Lightly spray or toss with oil. Do not overcrowd the basket.
White smoke coming from the appliance.	Grease residue from previous use; high-fat food.	Clean the pot and inner tray thoroughly after each use. For high-fat foods, drain excess fat during cooking.
Chemical smell during first use.	Manufacturing residue.	Perform initial burn-off cycles as described in "Before First Use" section. Ensure good ventilation.

9. SPECIFICATIONS

Feature	Detail
Model	GV030
Brand	YEDI HOUSEWARE
Capacity	2 Quarts (1.86 Liters)
Temperature Range	180°F - 400°F
Timer	Up to 30 minutes
Control Type	Analog Dials
Material	Aluminum (Pot), Plastic (Exterior)
Color	Black
Care Instructions	Hand Wash (Pot/Tray)
Item Weight	6 Pounds
Included Components	Removable Inner Tray, Recipe Book, Manual

10. WARRANTY AND SUPPORT

For information regarding warranty coverage, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official YEDI HOUSEWARE website. Keep your proof of purchase for warranty claims.

For further assistance, you may contact YEDI HOUSEWARE customer service through their official channels. Contact information is typically available on the product packaging or their website.

YEDI HOUSEWARE Official Store: [Visit Store on Amazon.ca](#)

