

USWELDWIRE WGM150

USWELDWIRE 180A MIG Gun Instruction Manual

Model: WGM150

[Safety](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

INTRODUCTION

This manual provides instructions for the safe and effective use of your USWELDWIRE 180A MIG Gun, Model WGM150. This MIG gun is designed for compatibility with various Miller Millermatic welders, including models 90, 120, 130, 130XP, 135, 140, 141, and 150. Please read this manual thoroughly before installation and operation to ensure proper function and safety.

SAFETY INFORMATION

Welding operations involve inherent risks. Always adhere to general welding safety practices and consult your welder's instruction manual for comprehensive safety guidelines. Failure to follow safety precautions can result in serious injury or death.

- **Electric Shock:** Welding can cause fatal electric shock. Ensure proper grounding of equipment. Do not touch live electrical parts. Wear dry, insulated gloves and protective clothing.
- **Fumes and Gases:** Welding fumes and gases can be hazardous to your health. Work in a well-ventilated area. Use an exhaust system to remove fumes from the breathing zone.
- **Arc Rays:** Arc rays can burn eyes and skin. Wear a welding helmet with appropriate shade filter and protective clothing (gloves, long sleeves, pants).
- **Fire and Explosion:** Welding sparks and hot metal can cause fires or explosions. Keep flammable materials away from the welding area. Have a fire extinguisher readily available.
- **Hot Parts:** Welding equipment and workpieces become hot. Allow parts to cool before handling or wear heat-resistant gloves.

SETUP

1. Unpacking and Inspection

Carefully remove the MIG gun from its packaging. Inspect the gun, cable, and connector for any signs of damage during shipping. If any damage is observed, do not proceed with installation and contact customer support.

2. Connecting the MIG Gun to the Welder

Ensure your welding machine is turned off and disconnected from the power source before connecting the MIG gun.

1. Locate the MIG gun connection port on your Miller Millermatic welder. This is typically a Euro-style connector or a direct connection point depending on your specific model.
2. Align the connector of the USWELDWIRE MIG gun with the port on the welder.
3. Insert the connector firmly and secure it according to your welder's specifications. This may involve tightening a collar nut or engaging a locking mechanism.
4. Ensure the trigger cable (if separate) is also connected securely to the appropriate receptacle on the welder.



Image: The USWELDWIRE 180A MIG Gun, showing its cable and connector. This image illustrates the general appearance of the MIG gun before connection to a welding machine.

3. Installing Consumables

The MIG gun comes with a .030 liner and nozzles pre-installed. Verify these components are correctly seated.

- **Contact Tip:** Ensure the correct size contact tip for your welding wire diameter is installed and

tightened securely into the diffuser.

- **Nozzle:** Thread the gas nozzle onto the gun head until it is snug. Do not overtighten.
- **Liner:** The wire liner guides the welding wire from the feeder to the contact tip. Ensure it is properly seated and extends through the gun cable without kinks. The included liner is for .030 wire.

OPERATING INSTRUCTIONS

Once the MIG gun is properly connected and consumables are installed, refer to your Miller Millermatic welder's manual for specific operating procedures, including wire loading, gas connection, and parameter settings.

- **Wire Feed:** Load the appropriate welding wire into your welder's wire feeder. Ensure the wire feeds smoothly through the gun liner and out of the contact tip.
- **Gas Flow:** Connect your shielding gas cylinder and regulator. Set the gas flow rate according to your welding process and material requirements (typically 15-25 CFH for MIG welding).
- **Parameter Settings:** Adjust the voltage and wire feed speed on your welder based on the material thickness, wire diameter, and shielding gas being used. Consult your welder's chart or a welding guide for recommended settings.
- **Trigger Operation:** To initiate welding, position the gun over the workpiece and press the trigger. The trigger activates the wire feed, gas flow, and welding arc. Release the trigger to stop welding.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your MIG gun.

- **Nozzle Cleaning:** Periodically clean spatter from inside the nozzle using a reamer or pliers designed for MIG gun maintenance. Excessive spatter can disrupt gas flow and affect weld quality.
- **Contact Tip Replacement:** Replace the contact tip when the bore becomes enlarged or clogged, leading to poor arc stability or wire feeding issues. Ensure the replacement tip matches the wire diameter.
- **Liner Inspection and Replacement:** Inspect the wire liner for kinks, wear, or contamination. A worn or dirty liner can cause erratic wire feeding. Replace the liner if necessary.
- **Cable Care:** Avoid kinking or crushing the gun cable. Store the gun properly to prevent damage to the cable and internal components.

TROUBLESHOOTING

This section addresses common issues encountered during MIG welding with your gun.

Problem	Possible Cause	Solution
Erratic Wire Feed	Worn or dirty liner, incorrect drive roll tension, clogged contact tip, wrong contact tip size.	Inspect and clean/replace liner. Adjust drive roll tension. Clean or replace contact tip. Ensure correct contact tip size.
Poor Arc Stability	Loose contact tip, spatter in nozzle, insufficient shielding gas, incorrect welding parameters.	Tighten contact tip. Clean nozzle. Check gas flow and connections. Adjust voltage/wire feed speed.

Problem	Possible Cause	Solution
No Wire Feed	Wire tangled in spool, drive rolls not engaged, trigger cable disconnected, power issue with welder.	Check wire spool. Engage drive rolls. Verify trigger cable connection. Consult welder manual for power issues.
Excessive Spatter	Incorrect voltage/wire feed speed, improper gun angle, contaminated workpiece.	Adjust welding parameters. Maintain proper gun angle. Clean workpiece thoroughly.

SPECIFICATIONS

Feature	Detail
Model Number	WGM150
Amperage Rating	180A
Compatibility	Miller Millermatic 90, 120, 130, 130XP, 135, 140, 141, 150
Cable Length	10ft (as per current product variant)
Included Liner	.030 inch wire liner
Item Weight	3.91 pounds
Manufacturer	XLIAN (Brand: USWELDWIRE)

WARRANTY AND SUPPORT

For specific warranty information regarding your USWELDWIRE 180A MIG Gun, please refer to the manufacturer's official website or contact USWELDWIRE customer service directly. Warranty terms and conditions may vary.

For technical assistance, troubleshooting beyond this manual, or to inquire about replacement parts, please contact USWELDWIRE customer support through their official channels.