

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [RunCam](#) /

› [RunCam Hybrid 2 4K FPV and HD Recording Camera Instruction Manual](#)

RunCam Hybrid 2

RunCam Hybrid 2 4K FPV and HD Recording Camera Instruction Manual

INTRODUCTION

The RunCam Hybrid 2 is an advanced dual-lens camera system designed for FPV (First Person View) applications and high-definition (HD) video recording. It integrates a 4K HD recording lens with a dedicated analog Phoenix 2 sensor lens, providing both high-quality recorded footage and a clear, low-latency FPV feed. This manual provides essential information for the proper installation, operation, and maintenance of your RunCam Hybrid 2 camera.

PRODUCT OVERVIEW

The RunCam Hybrid 2 features a compact, single-board design, making it suitable for micro FPV setups. Its dual-lens configuration ensures that the FPV view closely matches the recorded HD footage, enhancing the piloting experience.

Key Features:

- **Dual Lens System:** Combines a 4K HD recording lens (SONY 8MP sensor) with an analog FPV lens (Phoenix 2, SONY 1.3MP sensor).
- **Single Board Design:** Achieves a compact form factor with both lenses mounted closely on a single PCB.
- **Easy Installation:** 19mm camera module width allows direct mounting in micro FPV frames without adapters.
- **QR Code Parameter Settings:** Configure camera settings conveniently via a smartphone app by scanning a generated QR code.
- **UART Control:** Connects to a flight controller's UART port for remote control of recording functions via your radio transmitter.




Image: Analog Output Upgraded to Phoenix 2. The camera provides an improved FPV image feed.

Analog Output Upgraded to "Phoenix 2", Same Sensor



Image: Single board design for simple installation.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1x RunCam Hybrid 2 Camera
- 1x Plastic cover
- 1x 3PIN FPV silicone cable (male)
- 1x 3PIN FPV silicone cable (female)
- 1x Set of M2 screws
- 1x Manual




Image: Package contents of the RunCam Hybrid 2.

SPECIFICATIONS

Parameter	Value
HD Sensor	SONY 8MP
Analog Sensor	SONY 1.3MP (Phoenix 2)
Field of View (FOV)	HD Recording FOV 145° (FPV FOV 150° @ 4:3)
Video Resolution	4K@30fps / 2.7K@60fps / 2.7K@50fps / 1080P@120fps / 1080P@100fps / 1080P@60fps / 1080P@50fps
Video File Format	MP4
TV Mode	NTSC (720 x 480) / PAL (720 x 576) (Switchable)

Interface	HD supports UART remote control; FPV (analog) supports UART firmware upgrade.
Max Micro SD Card Supported	Up to 128GB (U3 recommended for 2.7K60/1080P120; U1 for others). Must be FAT32 format.
Mounting Holes	20 x 20 mm
PCB Size	29 x 29 mm
Lens Module Size	19 x 25 mm
Lens Specifications	M10 HD Lens and M8 FPV Lens
Input Power	DC 5-20V (Do not directly power with 4S battery or higher to avoid overvoltage).
Working Current	480mA @ 5V / 140mA @ 12V
Weight	18g

Package



1x Camera




1x Plastic cover



1x 3PIN FPV silicone cable(male)



1x 3PIN FPV silicone cable(female)



1x Set of M2 screws



Manual*1

Image: RunCam Hybrid 2 Dimensions.

SETUP

Follow these steps to properly set up your RunCam Hybrid 2 camera:

1. **Physical Installation:** Mount the 19mm camera module into your drone or vehicle frame. The compact design allows for direct integration into micro FPV setups.
2. **Wiring Connections:** Refer to the wiring diagram below for correct connections.

- **VCC+ (5-20V):** Connect to a stable DC power source within the specified voltage range. *Warning: Do not directly power with a 4S battery or higher, as this can cause overvoltage and damage the camera.*
 - **GND:** Connect to ground.
 - **Video:** Connect to your FPV video transmitter (VTX) for analog video output.
 - **TX/RX:** Connect to a UART port on your flight controller for remote control functionality and firmware updates.
3. **Micro SD Card Insertion:** Insert a formatted Micro SD card (FAT32 format, U3 speed class recommended for 2.7K60/1080P120, U1 for other resolutions) into the designated slot. Ensure the card is inserted correctly to avoid data corruption.



Image: RunCam Hybrid 2 PCB Layout and Wiring Diagram.

OPERATING

Once the camera is installed and powered, you can begin operation:

1. **Power On:** Apply power to the camera. The FPV feed should appear on your goggles or monitor.
2. **Recording Control:**

- **Manual Control:** Use the Power/Shutter Button on Side A of the PCB to start and stop HD recording.
 - **UART Remote Control:** If connected to a flight controller's UART, configure your Betaflight (or similar) settings to assign a switch on your radio to control recording start/stop.
3. **Mode Switching:** Use the Mode Switch Button on Side A to cycle through different camera modes or settings if available.
 4. **QR Code Parameter Settings:** For advanced configuration, download the RunCam app on your smartphone. Adjust desired settings within the app, generate a QR code, and then scan this QR code with the RunCam Hybrid 2 camera. The camera will automatically apply the new settings.




Image: QR Code Parameter Settings via RunCam App.

MAINTENANCE

To ensure optimal performance and longevity of your RunCam Hybrid 2 camera, follow these maintenance guidelines:

- **Lens Cleaning:** Regularly clean both the HD and FPV lenses with a soft, lint-free cloth and lens cleaning solution. Avoid abrasive materials that could scratch the lenses.
- **Power Supply:** Always ensure the camera receives power within the specified DC 5-20V range.

Incorrect voltage can cause irreversible damage.

- **SD Card Management:** Periodically back up your recorded footage and format the Micro SD card to maintain optimal recording performance and prevent file corruption. Use a high-quality, recommended speed class SD card.
- **Physical Inspection:** Regularly check for any loose connections, damaged cables, or physical damage to the camera module.

TROUBLESHOOTING

If you encounter issues with your RunCam Hybrid 2, refer to the following common problems and solutions:

- **No Power/Camera Not Turning On:**

- Check all power connections (VCC+, GND) for proper wiring and secure contact.
- Verify that the input voltage is within the DC 5-20V range.
- Ensure no short circuits are present in the wiring.

- **No FPV Video Output:**

- Check the video signal cable connection from the camera to your VTX and from the VTX to your goggles/monitor.
- Confirm that the TV mode (NTSC/PAL) setting on the camera matches your display device. This can be adjusted via QR code settings.
- Ensure the VTX is powered and functioning correctly.

- **Recording Errors / Corrupted Files:**

- Ensure the Micro SD card is formatted to FAT32.
- Use a high-speed Micro SD card (U3 or higher for 4K/high frame rate recording).
- Try formatting the SD card again or using a different, known-good SD card.
- Check the SD card slot for any debris or damage.

- **QR Code Settings Not Applying:**

- Ensure the QR code is clearly visible and well-lit when scanning.
- Hold the QR code steady in front of the camera lens until the settings are confirmed.
- Verify that you are using the official RunCam app for generating QR codes.

- **UART Control Not Working:**

- Check TX/RX wiring between the camera and the flight controller.
- Verify UART settings in your flight controller firmware (e.g., Betaflight) are correctly configured for camera control.
- Ensure the correct protocol is selected in the flight controller software.