

## KitchenAid KHBBV83VB

# KitchenAid Cordless Variable Speed Hand Blender

Model: KHBBV83VB

Brand: KitchenAid

## IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your KitchenAid Cordless Hand Blender. Keep this manual for future reference. Always follow basic safety precautions, including:

- Do not immerse the motor body in water or other liquids.
- Keep hands, hair, and clothing, as well as spatulas and other utensils, away from the blending arm during operation to prevent injury.
- Ensure the appliance is turned off and unplugged before assembling, disassembling, or cleaning.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not use outdoors. Indoor use only.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.

## PRODUCT OVERVIEW AND WHAT'S INCLUDED

Your KitchenAid Cordless Hand Blender comes with several components designed for versatile blending, chopping, and whisking tasks.



**Figure 1:** Complete set of the KitchenAid Cordless Hand Blender including the main unit, blending arm, whisk, chopper, pitcher, pan guard, and charger.

- **Main Blender Unit:** The cordless motor body with power button and battery indicator.
- **Removable 8" Blending Arm:** Features a 4-point stainless steel blade for efficient blending.
- **Whisk Attachment:** For whipping egg whites, cream, and emulsifying vinaigrettes.
- **2.5 Cup BPA-Free Chopper Attachment:** Ideal for chopping herbs, nuts, and cheeses.
- **1 Liter BPA-Free Pitcher with Lid:** Convenient for blending and storing.
- **Pan Guard:** U.S. patent-pending design to protect cookware surfaces during blending.
- **Charger:** For recharging the lithium-ion battery.





**Figure 2:** The main blender unit separated from the 8-inch blending arm, highlighting the detachable design.

## SETUP AND CHARGING

Before first use, ensure the battery is fully charged. The hand blender is powered by a rechargeable lithium-ion battery.

### Charging the Battery

1. Connect the charger to the charging port located at the top of the main blender unit.
2. Plug the charger into a standard electrical outlet.
3. The battery indicator light will illuminate to show charging status. A full charge from empty takes approximately 2 hours or less.
4. The battery indicator light signals when it is time to charge the battery.



Figure 3: The cordless hand blender with its charger, emphasizing its portability and ease of charging.

### Assembling the Hand Blender

1. Ensure the main blender unit is turned off and unplugged from the charger.
2. Align the blending arm or desired attachment (whisk, chopper) with the motor body.
3. Twist the attachment clockwise until it locks securely into place.

4. To remove, twist counter-clockwise and pull apart.

## OPERATING INSTRUCTIONS

The KitchenAid Cordless Hand Blender offers variable speed control for precise results.

### General Blending

1. Attach the 8" blending arm to the main unit.
2. Place ingredients in the 1-liter pitcher or a suitable pot/container.
3. Immerse the blending arm into the ingredients.
4. Press the variable speed trigger switch to begin blending. The speed increases as you press harder.
5. Use the safety switch to prevent accidental activation.
6. Move the blending arm up and down to ensure all ingredients are processed evenly.
7. The pan guard can be used to protect cookware surfaces.



**Figure 4:** Blending soup directly in a pot using the cordless hand blender, showcasing its ease of use for various recipes.

# Blend, Mix and Puree with ease



## 4-Point Blade Design

For the perfect puree



## Pan Guard

Helps protect cookware



## Variable Speed

For greater flexibility and control

**Figure 5:** Key features: 4-point blade for perfect purees, pan guard for cookware protection, and variable speed trigger for precise control.

### Using the Whisk Attachment

1. Attach the whisk attachment to the main unit.
2. Use for whipping egg whites to fluffy peaks, cream, or emulsifying vinaigrettes and mayonnaise.
3. Start at a lower speed and gradually increase as needed.



Figure 6: The whisk attachment in use, demonstrating its capability for aeration and emulsification.

## Using the Chopper Attachment

1. Attach the chopper attachment to the main unit.
2. Place ingredients like herbs, nuts, or cheeses into the chopper bowl.
3. Secure the lid and press the variable speed trigger to chop.
4. Pulse for coarse chopping or hold for finer results.



**Figure 7:** The chopper attachment being used to process ingredients, highlighting its utility for various food preparation tasks.

## MAINTENANCE AND CLEANING

Proper cleaning ensures the longevity and hygiene of your hand blender.

- Always unplug the charger and detach attachments before cleaning.
- The blending arm, 1-liter pitcher with lid, chopper attachment, and pan guard are dishwasher-safe (top rack recommended).
- Wipe the main blender unit with a damp cloth. Do not immerse it in water.
- Ensure all parts are completely dry before reassembling or storing.

## TROUBLESHOOTING

If you encounter issues with your KitchenAid Cordless Hand Blender, refer to the following common solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Blender does not turn on.	Battery is depleted or not charged. Safety switch not engaged.	Charge the battery fully. Ensure the safety switch is disengaged before pressing the trigger.
Battery indicator light not working.	Charger not properly connected.	Ensure the charger is securely connected to both the blender and the power outlet.
Ingredients not blending smoothly.	Too many ingredients or too thick. Not enough liquid.	Reduce the amount of ingredients. Add more liquid if necessary. Move the blending arm up and down.
Chopper attachment not chopping effectively.	Overfilled or ingredients are too large.	Do not overfill the chopper bowl. Cut larger ingredients into smaller pieces before processing.

## SPECIFICATIONS

Feature	Detail
Brand	KitchenAid
Model Number	KHBBV83VB
Color	Blue Velvet
Special Feature	Cordless
Capacity	1 Liters (pitcher)
Product Dimensions	2.5"D x 2.5"W x 16.3"H
Included Components	Blending Stick, Charging Cable, Base, 1 Liter BPA-free pitcher with lid, BPA-Free Chopper Attachment, Pan Guard
Style	Immersion Blenders
Recommended Uses	Mixing, Blending, Chopping
Power Source	Battery Powered (Rechargeable Lithium Ion)
Number of Speeds	Variable (trigger controlled)
Voltage	8V
Material Type Free	BPA Free
Item Weight	2.44 pounds
UPC	883049535470

## **WARRANTY AND SUPPORT**

KitchenAid products are manufactured to high-quality standards and are warranted to be free from defects in material and workmanship.

For detailed warranty information, product registration, or technical support, please visit the official KitchenAid website or contact their customer service. Keep your purchase receipt for warranty claims.

You can find more information and support at the [KitchenAid Store on Amazon](#).

© 2024 KitchenAid. All rights reserved.