

Ornalry XR-MM-C2007

Ornalry XR-MM-C2007 Kids Digital Dinosaur Alarm Clock User Manual

Model: XR-MM-C2007

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Ornalry Kids Digital Dinosaur Alarm Clock (Model: XR-MM-C2007). Please read this manual thoroughly before using the product to ensure proper function and safety. Keep this manual for future reference.

2. SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Keep the device away from water and other liquids.
- Do not attempt to disassemble or repair the device yourself. Contact qualified personnel for service.
- Use only the provided USB cable for charging.
- This product is not a toy. Adult supervision is recommended for young children.

3. PACKAGE CONTENTS

- 1 x Ornalry Kids Digital Dinosaur Alarm Clock
- 1 x USB Charging Cable
- 1 x User Manual (This document)

4. PRODUCT OVERVIEW

The Ornalry Kids Digital Dinosaur Alarm Clock is designed to be a fun and functional addition to a child's bedroom. It features a digital display, night light, dual alarms, and sleep training functions.



Figure 4.1: Front view of the Ornlry Kids Digital Dinosaur Alarm Clock. The clock features a digital display for time and various icons for settings, along with two control buttons on the side.

Key features include:

- Digital Time Display
- Timer Night Light (1-60 minutes)
- Dual Alarms with Snooze Function
- Three Workday Alarm Modes
- Intelligent Sunrise & Sunset Simulation
- Energy Saving Mode
- USB Charging
- Temperature Display (Celsius/Fahrenheit switchable)
- Nap Countdown Timer (1-59 minutes)

- 6 Playful Alarm Sounds with 5 Volume Levels

5. SETUP

5.1 Charging the Device

The alarm clock is equipped with a 2000mA high-capacity lithium battery. Before first use, or when the battery is low, charge the device using the provided USB cable.

1. Connect the small end of the USB cable to the charging port on the back or side of the alarm clock.
2. Connect the larger end of the USB cable to a standard USB power adapter (not included) or a computer's USB port.
3. The charging indicator (if present) will illuminate during charging and turn off when fully charged.

5.2 Initial Power On

Once charged, the clock should power on automatically. If not, press and hold the main power button (if available) or connect it to power to activate.

6. OPERATING INSTRUCTIONS

6.1 Setting the Time

Specific button functions are not detailed in the product description, but typically involve a "Set" or "Time" button. Refer to the on-device labels for precise button identification.

1. Press and hold the **SET** button (or similar) to enter time setting mode. The hour display will flash.
2. Use the **UP** and **DOWN** buttons (or similar) to adjust the hour.
3. Press **SET** again to confirm the hour and move to minute setting. The minute display will flash.
4. Use the **UP** and **DOWN** buttons to adjust the minutes.
5. Press **SET** to confirm and exit time setting mode.

6.2 Setting Dual Alarms and Workday Modes

The clock supports two independent alarms and three workday modes.



Figure 6.1: Example of personalized alarm time settings, showing a weekday alarm (7:00 AM Mon-Fri) and a daily alarm (22:00 Mon-Sun).

1. Press and hold the **ALARM 1** button (or similar) to enter Alarm 1 setting mode.
2. Adjust the hour and minutes using the **UP** and **DOWN** buttons, confirming each with **ALARM 1**.
3. After setting the time, you can select the alarm mode:
 - **1-5:** Monday to Friday
 - **1-6:** Monday to Saturday
 - **1-7:** Monday to Sunday (Daily)
4. Repeat the process for **ALARM 2** using its dedicated button.
5. To enable/disable an alarm, short press the respective **ALARM** button. An alarm icon will appear/disappear on the display.

6.3 Snooze Function

When an alarm sounds, you can activate the snooze function for an additional 5 minutes of sleep.



Figure 6.2: Illustration of the snooze function, activated by touching the night light button for 5 minutes of extra sleep.

- When the alarm rings, touch the night light button (or indicated snooze button) to activate snooze. The alarm will pause for 5 minutes and then sound again.
- To stop the alarm completely during snooze, press any other button on the clock.

6.4 Night Light & Sleep Trainer

The clock features a night light with a timer function to help children sleep.

Timed night light

Set the night light delay off mode and turn off the night light after 1-60 minutes, Create an ideal sleeping environment. Let child feel safe in the dark



Figure 6.3: The timed night light feature, which can be set to turn off after 1-60 minutes, creating a comfortable sleeping environment.

- Press the **NIGHT LIGHT** button (or similar) to turn the night light on/off.
- To set the timer for the night light, press and hold the **NIGHT LIGHT** button. The timer setting will flash.
- Use the **UP** and **DOWN** buttons to set the desired duration (1-60 minutes).
- Press the **NIGHT LIGHT** button again to confirm the setting. The light will automatically turn off after the set time.

6.5 Intelligent Sunrise & Sunset Simulation

This feature helps to gently wake you up and prepare for sleep by gradually changing light intensity.

- **Sunrise Simulation:** From 6:00 AM to 5:59 PM, the wake-up light will gradually increase in brightness, simulating a sunrise to gently rouse you from sleep.
- **Sunset Simulation:** From 6:00 PM to 5:59 AM, the LED light will automatically dim, creating a soothing environment conducive to sleep.

6.6 Energy Saving Mode

The clock is set to energy-saving mode by default to conserve battery life.

- In energy-saving mode, the display will turn off after a period of inactivity.
- To wake up the display, tap the clock or the surface it's on, or clap your hands.

6.7 Alarm Voice and Volume

Choose from 6 different alarm sounds and adjust the volume to your preference.



Figure 6.4: The clock offers a wide range of adjustable volume modes and 6 kinds of soft ringtones for a personalized wake-up experience.

- When setting an alarm, you will typically have an option to select the alarm sound. Use the **UP** and **DOWN** buttons to cycle through the 6 available ringtones.
- To adjust the alarm volume, look for a dedicated volume button or a volume setting within the alarm setup menu. There are 5 wake-up volume levels.

6.8 Temperature Display and Nap Timer



Figure 6.5: Overview of features including alarm clock, temperature display, nap timer, and night light.

- **Temperature Display:** The clock displays the current room temperature. You can switch between Celsius (°C) and Fahrenheit (°F) by pressing a dedicated button (often labeled **TEMP** or by a long press on an existing button).
- **Nap Timer:** To set a nap countdown timer (1-59 minutes), locate the **NAP** or **TIMER** button. Press it to activate and use the **UP** and **DOWN** buttons to set the duration.

7. MAINTENANCE

- Clean the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Ensure the charging port is free of dust and debris.
- Store the device in a cool, dry place when not in use for extended periods.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock does not turn on.	Low battery or not charged.	Connect to a USB power source and charge the device.
Alarm does not sound.	Alarm is not enabled or volume is too low.	Ensure the alarm is activated (icon visible) and check the alarm volume settings.
Display is off.	Energy-saving mode is active.	Tap the clock or the surface it's on, or clap hands to wake the display.
Night light does not turn off.	Timer not set or set for a long duration.	Check the night light timer setting or manually turn it off.

9. SPECIFICATIONS

- **Model:** XR-MM-C2007
- **Brand:** Ornalry
- **Material:** ABS, Silicone
- **Display Type:** Digital
- **Power Source:** Corded Electric (USB Charging), Battery (Lithium Ion, 2000mA)
- **Product Dimensions:** 12.7 x 3.81 x 10.16 cm (5W x 4H centimetres)
- **Item Weight:** 289.17 g
- **Special Features:** Charging Port, Timer Night Light, Dual Alarms, Sunrise/Sunset Simulation, Energy Saving Mode, Temperature Display, Nap Timer

10. WARRANTY AND SUPPORT

This product is designed for reliability and durability. For any questions, technical support, or warranty claims, please refer to the retailer where the product was purchased or contact Ornalry customer service through their official channels. Please retain your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question