



[Manuals.plus](#) /

> [Aucma](#) /

> Aucma Juicer Machine User Manual

Aucma Juicer-3005red2

Aucma Juicer Machine User Manual

Model: Juicer-3005red2

INTRODUCTION

Welcome to the Aucma Juicer Machine user manual. This document provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new Aucma Slow Juicer Extractor. Designed to maximize juice yield and preserve nutrients, this cold press juicer is suitable for a wide variety of fruits and vegetables. Please read this manual thoroughly before first use to ensure optimal performance and longevity of your appliance.



Image: The Aucma Slow Juicer Machine, red in color, with a juice collection cup filled with green juice and a pulp collection cup.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using electrical appliances.

- Read all instructions before operating the juicer.
- Do not immerse the motor base in water or other liquids.
- Ensure the voltage rating on the appliance matches your local power supply before connecting.
- Unplug from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always ensure the juicer is properly assembled before operation.
- Do not put fingers or other objects into the feed chute while the appliance is in operation. If food becomes lodged, use the food pusher provided.
- This appliance is for household use only.

- Keep children away from the appliance during operation.

PRODUCT COMPONENTS

Familiarize yourself with the various parts of your Aucma Juicer Machine.



Image: All components of the Aucma Juicer Machine laid out, including the motor base, auger, filter, juice cup, pulp cup, and cleaning brush.

1. Food Pusher
2. Feed Chute
3. Juicing Bowl/Chamber
4. Auger (Spiral System)
5. Filter Screen
6. Juice Outlet
7. Pulp Outlet
8. Motor Base with Control Knob
9. Juice Collection Cup
10. Pulp Collection Cup
11. Cleaning Brush

SETUP AND ASSEMBLY

Before first use, wash all detachable parts (excluding the motor base) with warm, soapy water. Rinse thoroughly and dry.

1. Place the motor base on a stable, flat, and dry surface.
2. Insert the juicing bowl onto the motor base, aligning the red dot on the bowl with the red dot on the base, then twist clockwise until it locks into place.
3. Insert the filter screen into the juicing bowl.
4. Place the auger (spiral system) into the center of the filter screen, pushing down firmly until it seats properly.
5. Attach the feed chute assembly onto the juicing bowl, aligning the marks and twisting clockwise until it clicks securely.
6. Position the juice collection cup under the juice outlet and the pulp collection cup under the pulp outlet.



Image: A finger pressing the quick-release button for disassembling the juicer, indicating ease of assembly and disassembly.

OPERATING INSTRUCTIONS

1. Preparation of Ingredients

Wash all fruits and vegetables thoroughly. For optimal juicing and to prevent clogging, cut ingredients into smaller pieces that fit easily into the feed chute. Remove hard pits from fruits like peaches or plums. For fibrous vegetables like celery, cut into 1-inch pieces.

EXTRACT ALL KINDS OF SOFT & HARD FRUITS AND VEGETABLES



Orange Juice



Watermelon Juice



Kiwi Juice



Raspberry Juice



Celery Juice



Carrot Juice



Apple Juice



Ginger Root Juice

Image: A display of various fruits and vegetables, such as oranges, apples, carrots, celery, and berries, indicating the versatility of the juicer.

2. Juicing Process

- Ensure the juicer is correctly assembled and the juice and pulp cups are in place.
- Plug the power cord into a grounded electrical outlet.
- Turn the control knob to the "ON" position. The motor will start quietly.
- Slowly feed the prepared ingredients into the feed chute. Use the food pusher to gently guide the ingredients down. Do not force ingredients into the chute, as this can damage the motor or clog the auger.
- The juicer will extract juice into the juice cup and separate pulp into the pulp cup.
- When finished juicing, turn the control knob to the "0" (OFF) position and unplug the appliance.



Image: A close-up view of the Aucma Juicer's control knob, showing the "REV" (Reverse), "0" (Off), and "ON" settings.

Note: The Aucma Juicer is equipped with intelligent protection chips. It will automatically stop after 20 minutes of continuous operation to prevent overheating. If this occurs, allow the machine to cool down for at least 30 minutes before resuming use.

3. Reverse Function

If ingredients become jammed or the juicer stops during operation, turn the control knob to the "REV" (Reverse) position and hold it for a few seconds. This will rotate the auger in the opposite direction to dislodge any blockages. Release the knob to return to the "0" position, then switch back to "ON" to resume juicing.

ANTI-SLIP BUTTON AND EASY TO USE



Image: A comparison showing the Aucma juicer's control knob, highlighting its anti-slip design which allows for easy switching between modes without needing to continuously press a button for reverse function, unlike some other models.

MAINTENANCE AND CLEANING

Regular cleaning ensures hygiene and extends the lifespan of your juicer. Clean the appliance immediately after each use.

1. Unplug the juicer from the power outlet.
2. Remove the juice and pulp collection cups.
3. Press the quick-release button (often located near the feed chute assembly) and twist the feed chute assembly counter-clockwise to detach it.
4. Remove the auger and filter screen from the juicing bowl.
5. Wash all detachable parts (juicing bowl, auger, filter screen, feed chute assembly, food pusher, juice cup, pulp cup) under running water using the provided cleaning brush. For stubborn pulp, soak parts in warm, soapy water before scrubbing.
6. The filter screen requires particular attention to ensure all mesh holes are clear.
7. Wipe the motor base with a damp cloth. Never immerse the motor base in water.
8. Dry all parts thoroughly before reassembling or storing.

Easy to disassemble and clean

One Button Disassemble, complete disassembly and cleaning within 5 minutes



Image: A person cleaning the disassembled parts of the Aucma Juicer, including the filter and auger, under running water with the cleaning brush, demonstrating the ease of cleaning.

TROUBLESHOOTING

If you encounter issues with your Aucma Juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; power outage; not assembled correctly.	Ensure plug is securely in outlet. Check power supply. Reassemble all parts correctly, ensuring they click into place.
Motor stops during operation.	Overload protection activated; ingredients jammed.	Turn off and unplug. If overheated, allow to cool for 30 minutes. If jammed, use "REV" function. If still stuck, disassemble and clear blockage.
Low juice yield or wet pulp.	Filter screen clogged; ingredients too soft/overripe; feeding too quickly.	Clean filter screen thoroughly. Use fresh, firm produce. Feed ingredients slowly and allow the juicer to process fully.

Problem	Possible Cause	Solution
Loud noise or vibration.	Improper assembly; hard ingredients causing strain.	Disassemble and reassemble carefully, ensuring all parts are securely locked. Cut hard ingredients into smaller pieces.

If the problem persists after attempting these solutions, please contact Aucma customer support.

SPECIFICATIONS

Brand: Aucma

Model Name: Juicer-3005red2

Color: Red

Special Feature: Quiet Motor, Reverse Function, Intelligent Protection Chips

Product Dimensions: 16.5"D x 7.8"W x 12"H

Item Weight: 7.48 pounds

Power Source: Corded Electric

Maximum Power: 150 Watts

Voltage: 120 Volts

Number of Speeds: 1

Blade Material: Stainless Steel

Recommended Uses: Apple, Beetroot, Carrot, Celery, Fruits, Vegetables

Care Instructions: Hand wash detachable parts. Motor base wipe clean.

WARRANTY AND SUPPORT

Aucma is committed to product quality and customer satisfaction. For any questions, concerns, or technical support regarding your Aucma Juicer Machine, please contact Aucma customer service. Refer to the product packaging or the official Aucma website for the most current contact information. Please retain your proof of purchase for warranty claims.

