

[Manuals.plus](#) /

› [QwikProducts](#) /

› QwikProducts QwikSwap X1 Universal ECM Blower Motor Replacement Board Instruction Manual

QwikProducts QT6101

QwikProducts QwikSwap X1 Universal ECM Blower Motor Replacement Board Instruction Manual

Model: QT6101

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of the QwikProducts QwikSwap X1 Universal ECM Blower Motor Replacement Board (Model QT6101). The QwikSwap X1 is designed to replace failed Constant Torque ECM, X13, or SelecTech blower motors up to 1 HP in furnaces and air handlers, offering an efficient and cost-effective solution.




Figure 1: The QwikSwap X1 Universal ECM Blower Motor Replacement Board.

2. SAFETY INFORMATION

WARNING: Electrical Shock Hazard

- Always disconnect power to the furnace or air handler at the main service panel before installing or servicing the QwikSwap X1.
- Installation should only be performed by a qualified HVAC technician or electrician.
- Ensure all wiring connections are secure and comply with local electrical codes.
- Do not operate the unit with damaged wiring or components.

3. PACKAGE CONTENTS

The QwikSwap X1 package includes:

- One (1) QwikSwap X1 Replacement Board

4. PRODUCT OVERVIEW

The QwikSwap X1 (Model QT6101) is a single-speed ECM motor replacement board designed for universal compatibility with Constant Torque ECM, X13, or SelecTech blower motors up to 1 HP. It facilitates the conversion to a Permanent Split Capacitor (PSC) motor, offering a reliable and efficient alternative.



The image shows the QwikSwap X1 motor replacement board, a green printed circuit board (PCB) with various electronic components. It features a black plastic mounting bracket at the top with a hole for a screw. The board has several terminal blocks: 'TO PSC MOTOR' and 'COM' at the top left, and 'FROM OLD MOTOR' with terminals C, L, G, N, 1, 2, 3, 4, 5 in the center. There are also two large electrolytic capacitors at the bottom. The board is labeled with 'QwikSwap', 'QT6101', and 'REV 1'. It is set against a green background with a white dotted pattern.

QwikSwap X1

SINGLE SPEED ECM MOTOR REPLACEMENT

-  Single-speed Operation
-  Up to 1 HP ECM Motors
-  No Programming Required

QwikProducts®
by Mainstream Engineering

HIGH-EFFICIENCY DESIGN • ASSEMBLED IN THE USA

Figure 2: Key features of the QwikSwap X1 board, including single-speed operation, compatibility with up to 1 HP ECM motors, and no programming requirement.

Key benefits include:

- **Affordable Replacement:** Provides a cost-effective alternative to expensive OEM ECM motor replacements.
- **Rapid Installation:** Designed for straightforward installation, minimizing downtime.
- **High-Efficiency Design:** Engineered to improve energy efficiency and potentially extend the lifespan of your HVAC unit.

Product Video Overview

Your browser does not support the video tag.

5. INSTALLATION

Follow these steps carefully to install the QwikSwap X1 board:

1. **Disconnect Power:** Before beginning any work, ensure that all power to the furnace or air handler is completely disconnected at the circuit breaker or fuse box. Verify with a voltage tester.
2. **Access Blower Compartment:** Open the access panel to the blower motor compartment of your HVAC unit.
3. **Identify Existing Wiring:** Locate the wiring harness connected to the failed ECM motor. Note the connections for common, power leads, and any speed taps.
4. **Remove ECM Motor:** Disconnect the wiring from the ECM motor and remove the motor from the unit.
5. **Install PSC Motor:** Install the new Permanent Split Capacitor (PSC) motor into the unit. Ensure it is properly mounted and secured.
6. **Connect QwikSwap X1:**
 - Move the wires from the original ECM motor's control board to the corresponding terminals on the QwikSwap X1 board. The QwikSwap X1 is designed to interface with the existing control signals.
 - Connect the common and power lead(s) of the new PSC motor to the designated terminals on the QwikSwap X1 board.
 - Connect the appropriate capacitor to the PSC motor as required.

Rapid Installation Without Programming

- 1 Move the wires from the failed ECM to X1
- 2 Connect the PSC motor's common & power lead
- 3 You're all set!



Figure 3: Wiring diagram illustrating the connection points on the QwikSwap X1 board for both the existing system wiring and the new PSC motor.



Affordable Replacement for OEM ECM Motors

Figure 4: Hands performing wiring connections within an HVAC unit, demonstrating the installation process.

7. **Secure Wiring:** Ensure all connections are tight and properly insulated. Route wires to prevent pinching or damage.
8. **Close Compartment:** Replace the blower compartment access panel.
9. **Restore Power:** Restore power to the furnace or air handler at the main service panel.
10. **Test Operation:** Initiate a call for heating or cooling to verify the proper operation of the blower motor.

6. OPERATION

Once installed, the QwikSwap X1 board operates by converting the signals from your HVAC system's control board to properly drive the new PSC motor. It is designed for single-speed operation, meaning the PSC motor will run at a consistent speed when activated by the system's demand for airflow.

The QwikSwap X1 requires no programming. It automatically adapts to the system's signals to ensure correct blower motor function.

7. MAINTENANCE

The QwikSwap X1 board itself requires no routine maintenance. However, regular maintenance of the overall HVAC system and the PSC blower motor is recommended to ensure optimal performance and longevity.

- Periodically inspect wiring connections for tightness and signs of wear.
- Ensure the PSC motor is kept clean and free from debris.
- Replace air filters regularly as per your HVAC system manufacturer's recommendations.

8. TROUBLESHOOTING

If you encounter issues after installing the QwikSwap X1, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Blower motor does not start.	No power to the unit. Incorrect wiring connections. Faulty PSC motor or capacitor. QwikSwap X1 board malfunction.	Check circuit breaker and ensure power is restored. Review installation steps and verify all wiring. Test PSC motor and capacitor independently. Contact QwikProducts support.
Blower motor runs continuously.	Incorrect wiring of control signals. System control board issue.	Verify control signal wiring to the QwikSwap X1. Consult HVAC technician for system control board diagnosis.
Reduced airflow.	Dirty air filter. Improperly sized PSC motor. Ductwork issues.	Replace air filter. Ensure PSC motor matches system requirements. Consult HVAC technician for ductwork inspection.

9. SPECIFICATIONS

Feature	Detail
Model Number	QT6101
Compatibility	Universal replacement for Constant Torque ECM, X13, or SelecTech blower motors
Motor Horsepower (Max)	1 HP
Voltage	115/240 Volts (as per original ECM motor)
Operation	Single Speed
Product Dimensions	7.13 x 10 x 1.5 inches (approximate board dimensions)
Weight	4.32 ounces (approximate)
Manufacturer	QwikProducts

10. WARRANTY AND SUPPORT

For warranty information, technical support, or assistance with your QwikSwap X1 board, please contact QwikProducts directly. Refer to the product packaging or the official QwikProducts website for the most current contact details.

QwikProducts Website: [Visit QwikProducts Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question