

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Samsung](#) /

› Samsung Galaxy Tab A7 SM-T500 Tablet User Manual

## Samsung SM-T500

# Samsung Galaxy Tab A7 SM-T500 Tablet User Manual

Model: SM-T500

---

## 1. OVERVIEW

---

This manual provides essential information for the use and maintenance of your Samsung Galaxy Tab A7 SM-T500 tablet. The device features a 10.4-inch WUXGA+ display, 3 GB RAM, and 64 GB of internal storage, running on Android 10. It is powered by a Qualcomm SM6115 Snapdragon 662 SoC with a Qualcomm Kryo 260 Gold processor. This particular unit is a professionally inspected and tested renewed product, ensuring it functions and appears like new.



*Image 1.1: Front view of the Samsung Galaxy Tab A7 SM-T500 tablet, showcasing its dark gray finish and display.*

## 2. WHAT'S IN THE BOX

---

Upon unboxing your Samsung Galaxy Tab A7 SM-T500, you should find the following items:

- Samsung Galaxy Tab A7 SM-T500 Tablet
- USB-C Power Adapter
- USB-C Cable

## 3. SETUP

---

### 3.1 Initial Charging

Before first use, it is recommended to fully charge your tablet. Connect the provided USB-C cable to the tablet's USB-C port and the USB-C power adapter. Plug the adapter into a wall outlet. The charging indicator will appear on the screen.

## 3.2 Powering On/Off

- To power on: Press and hold the **Power button** located on the side of the tablet until the Samsung logo appears.
- To power off: Press and hold the **Power button**, then select 'Power off' from the options on the screen.

## 3.3 Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup process. This includes selecting your language, connecting to a Wi-Fi network, agreeing to terms and conditions, and signing in with or creating a Google account. Follow the on-screen prompts to complete the setup.

## 3.4 Expanding Storage

The Samsung Galaxy Tab A7 SM-T500 supports storage expansion via a MicroSD card. Locate the MicroSD card slot on the side of the tablet. Insert a compatible MicroSD card (up to 1 TB) into the slot until it clicks into place. The tablet will prompt you to format the card for use.

# 4. OPERATING INSTRUCTIONS

---

## 4.1 Touchscreen Navigation

Navigate the tablet using standard touchscreen gestures:

- **Tap:** Select an item or open an app.
- **Swipe:** Scroll through pages or lists.
- **Pinch:** Zoom in or out on content.
- **Long Press:** Access contextual menus or move icons.

## 4.2 Volume Control

The **Volume Up** and **Volume Down** buttons are located on the side of the tablet. Use them to adjust media volume, ringtone volume, and notification volume.

## 4.3 Connecting Headphones

The tablet includes a 3.5mm headphone jack. Insert your wired headphones into this port for private audio listening. Alternatively, Bluetooth headphones can be paired via the tablet's Bluetooth settings.

## 4.4 Camera Usage

The tablet is equipped with an 8-megapixel rear camera and a 2-megapixel front camera. Open the Camera app to capture photos and videos. Tap the screen to focus and press the shutter button to take a picture.

# 5. MAINTENANCE

---

## 5.1 Cleaning the Tablet

To clean the tablet, use a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaner. Avoid harsh chemicals, abrasive materials, or excessive moisture.

## 5.2 Software Updates

Regularly check for and install software updates to ensure optimal performance and security. Navigate to **Settings > Software update** to check for available updates.

## 5.3 Battery Care

To prolong battery life, avoid exposing the tablet to extreme temperatures. It is recommended to keep the battery charge between 20% and 80% for daily use. Fully discharging the battery frequently can reduce its overall lifespan.

# 6. TROUBLESHOOTING

## 6.1 Device Not Turning On

If the tablet does not turn on, ensure it is sufficiently charged. Connect it to the power adapter and allow it to charge for at least 30 minutes before attempting to power it on again. If the issue persists, try a forced restart by holding the Power button and Volume Down button simultaneously for about 10-15 seconds.

## 6.2 Screen Unresponsive

If the touchscreen is unresponsive, try restarting the device. If a restart does not resolve the issue, ensure the screen is clean and free of debris or moisture. If the problem continues, a factory reset may be necessary (see section 6.4).

## 6.3 Charging Issues

If the tablet is not charging, verify that the USB-C cable and power adapter are securely connected and undamaged. Try using a different compatible USB-C cable and adapter if available. Ensure the charging port on the tablet is clean and free of lint or debris.

## 6.4 Factory Reset (Last Resort)

A factory reset will erase all data from your tablet and restore it to its original factory settings. **Back up all important data before proceeding.** To perform a factory reset, go to **Settings > General management > Reset > Factory data reset** and follow the on-screen instructions.

# 7. SPECIFICATIONS

Feature	Specification
Brand	Samsung
Model Name	Galaxy Tab A7
Item Model Number	98b931a8-ee55-46e3-bced-1e6e2e87ea11
Operating System	Android 10
Screen Size	10.4 Inches
Max Screen Resolution	1600x1066 pixels (WUXGA+)
Processor	Qualcomm SM6115 Snapdragon 662 SoC

Feature	Specification
RAM	3 GB
Memory Storage Capacity	64 GB
Expandable Storage	MicroSD up to 1 TB
Graphics Coprocessor	Adreno 610
Wireless Type	802.11ac
Color	Dark Gray
Battery Capacity	5100 mAh

## 8. WARRANTY AND SUPPORT

---

This product is a renewed item and is covered by the **Amazon Renewed Guarantee**. This guarantee ensures that if you are not satisfied with your purchase, renewed products are eligible for replacement or refund. Please refer to the Amazon Renewed Guarantee terms and conditions for full details.

For technical support, software issues, or further assistance, please visit the official Samsung support website or contact their customer service. Keep your purchase receipt and product information handy when seeking support.