

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Gevi](#) /

> [Gevi Air Fryer GEDFG006T-U-GV0923 User Manual](#)

Gevi 1

Gevi Air Fryer User Manual

Model: GEDFG006T-U-GV0923

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions before using this appliance.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

PRODUCT OVERVIEW

The Gevi Air Fryer is designed for healthy cooking with minimal oil. It features a 6.3-quart capacity, an LED touch digital screen, and 8 preset cooking functions. The appliance utilizes 360° rapid air circulation technology for even cooking.

6.3 QT BIG CAPACITY

≈ 55
Chicken Drumsticks



Image: Gevi Air Fryer with its cooking basket containing food, demonstrating its 6.3-quart capacity.

Components:

- Main Unit
- Removable Frying Basket
- Nonstick Crisper Plate
- Control Panel (LED Touch Screen)
- Power Cord

Control Panel:

The intuitive LED touch panel allows for easy selection of cooking functions, temperature, and time adjustments.

SMART LED TOUCH PANEL

LED Intelligent Touch Screen
Simple Operation Arrives Delicious



Image: Detailed view of the Gevi Air Fryer's smart LED touch panel, showing preset icons and time/temperature controls.

BEFORE FIRST USE

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Wipe the exterior of the appliance with a damp cloth.
3. Clean the frying basket and crisper plate thoroughly with hot water, dish soap, and a non-abrasive sponge. These parts are dishwasher-safe.
4. Dry all parts completely before assembly.

SETUP

1. Place the air fryer on a stable, level, heat-resistant surface. Ensure there is at least 4 inches of clear space around the back and sides of the appliance for proper ventilation.
2. Insert the crisper plate into the frying basket.

3. Slide the assembled frying basket back into the main unit until it clicks into place.
4. Plug the power cord into a grounded electrical outlet.

OPERATING INSTRUCTIONS

Basic Operation:

1. Place ingredients into the frying basket. Do not overfill.
2. Slide the basket back into the air fryer.
3. Press the Power button (●) to turn on the appliance. The LED display will illuminate.
4. Select a preset cooking function or manually set the temperature and time.
 - **Using Presets:** Press the desired preset icon (e.g., Fries, Chicken, Fish, Shrimp, Cake, Steak, Bacon, Pizza). The appliance will automatically set the recommended time and temperature.
 - **Manual Setting:** Use the Temperature (°F) and Time (min) buttons, along with the + and - buttons, to adjust settings.
5. Press the Start/Pause button (▶||) to begin cooking.
6. During cooking, you can pull out the basket to shake or flip food. The air fryer will pause automatically and resume when the basket is reinserted.
7. The air fryer will beep when cooking is complete. Carefully remove the basket and transfer food.

8 COOKING PRESETS

Meet All Your Cooking Needs With Gevi Air Fryer



Fries



Chicken



Fish



Shrimp



Cake



Steak



Bacon



Pizza



Image: The Gevi Air Fryer's control panel highlighting the 8 available cooking presets.

Rapid Air Circulation:

The air fryer uses 360° rapid and even heat circulation, powered by a 1700W heating element, to cook food quickly and achieve crispy results with less oil.

360° RAPID & EVEN HEAT CIRCULATION

1700W High Power and 360° Heat Circulation
Provide Fast & Even Fry and Tasty Results



Image: Illustration of the 360° rapid air circulation technology within the air fryer, ensuring even cooking.

COOKING GUIDE

Cooking times and temperatures may vary based on food type, quantity, and desired crispiness. Always ensure food is cooked to safe internal temperatures.

Tips for Best Results:

- For crispy results, lightly brush or spray food with oil.
- Shake the basket halfway through cooking for even browning, especially for smaller items like fries or nuggets.
- Do not overcrowd the basket; cook in batches if necessary to ensure proper air circulation.
- Preheating the air fryer for 3-5 minutes can improve cooking performance.

CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your air fryer.

1. Unplug the air fryer and allow it to cool completely before cleaning.
2. Remove the frying basket and crisper plate.
3. Clean the frying basket and crisper plate with hot water, dish soap, and a non-abrasive sponge. These parts are dishwasher-safe.
4. Wipe the exterior of the air fryer with a damp cloth. Do not immerse the main unit in water.
5. Clean the interior of the appliance with a damp cloth and mild detergent if necessary.
6. Ensure all parts are dry before storing or next use.



Image: The air fryer basket being placed into a dishwasher, illustrating its dishwasher-safe feature.

Storage:

Store the air fryer in a cool, dry place. Ensure the power cord is neatly wrapped and secured.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in. Power outlet not working.	Ensure the power cord is securely plugged into a grounded outlet. Check the outlet with another appliance.
Food is not cooked evenly.	Basket is overcrowded. Food not shaken or flipped.	Cook food in smaller batches. Shake or flip food halfway through cooking.
White smoke comes from the appliance.	Grease residue from previous use. Fatty ingredients being cooked.	Clean the basket and crisper plate thoroughly after each use. For fatty foods, drain excess oil from the basket.
Food is not crispy.	Not enough oil applied. Temperature too low or time too short.	Lightly brush or spray food with oil. Increase cooking temperature or time as needed.

SPECIFICATIONS

Model Number	GEDFG006T-U-GV0923
Capacity	6.3 Quarts
Wattage	1800 Watts (Note: Some product descriptions may state 1700W, refer to product label for exact rating)
Voltage	120 Volts
Control Method	Touch Control (LED Digital Screen)
Nonstick Coating	Yes
Product Dimensions	12.2 x 10.4 x 13.3 inches
Item Weight	15.95 pounds

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact Gevi customer service. Keep your purchase receipt as proof of purchase.

Contact information can typically be found on the manufacturer's official website or on the product packaging.

