

NEDIS KAAF250EBK

Nedis KAAF250EBK 6.5L 1800W Air Fryer Instruction Manual

Model: KAAF250EBK

1. INTRODUCTION

Thank you for choosing the Nedis KAAF250EBK Air Fryer. This appliance uses hot air circulation to cook your favorite foods with little to no oil, offering a healthier alternative to traditional frying. Please read this instruction manual carefully before using the product to ensure safe and optimal performance. Keep this manual for future reference.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse the cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

- Do not use the appliance for other than intended use.
- Ensure adequate ventilation around the appliance during use.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Nedis KAAF250EBK Air Fryer.



Image: The Nedis KAAF250EBK Air Fryer, featuring a sleek black design and a digital touch control panel displaying temperature settings.

Main Components:

- **Main Unit:** The primary housing containing the heating element and fan.
- **Frying Basket:** The removable container where food is placed for cooking.
- **Crisper Plate:** A removable plate inserted into the frying basket to allow air circulation around food and drain excess oil.
- **Handle:** For safely pulling out and inserting the frying basket.
- **Digital Touch Control Panel:** For setting temperature, time, and selecting cooking presets.



Image: An exploded view illustrating the main unit, the removable frying basket, the crisper plate, and the power cord, highlighting the appliance's separate components.

4. SETUP

Before First Use:

1. **Unpack:** Remove all packaging materials and promotional labels from the air fryer.
2. **Clean:** Wash the frying basket and crisper plate thoroughly with hot water, dish soap, and a non-abrasive sponge. Rinse and dry completely. Wipe the inside and outside of the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, heat-resistant, and level surface. Ensure there is at least 10 cm (4 inches) of free space on the back and sides of the appliance, and 10 cm (4 inches) above it, to allow for proper air circulation.
4. **Power Connection:** Plug the power cord into a grounded wall outlet.

5. OPERATING INSTRUCTIONS

Basic Operation:

1. **Prepare Food:** Place the crisper plate into the frying basket. Place the ingredients into the frying basket. Do not exceed the MAX indication.
2. **Insert Basket:** Slide the frying basket back into the main unit until it clicks into place.
3. **Power On:** Plug the appliance into a power outlet. The display will light up.
4. **Set Temperature and Time:** Use the touch control panel to adjust the temperature (80°C to 200°C) and cooking time (1 to 60 minutes). You can also select from pre-set cooking programs if available.

5. **Start Cooking:** Press the start button to begin the cooking process.
6. **Shake Basket (Optional):** For some foods, it may be necessary to shake the basket halfway through the cooking time to ensure even cooking. Carefully pull out the basket, shake it, and then slide it back in. The air fryer will resume cooking automatically.
7. **Cooking Completion:** The air fryer will beep when the set cooking time has elapsed. Carefully pull out the basket and place it on a heat-resistant surface.
8. **Serve:** Remove the cooked food from the basket using tongs. Be careful of hot steam.



Image: The air fryer with its basket partially removed, revealing potato wedges ready for cooking or shaking, demonstrating the ease of access during operation.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Clean Basket and Crisper Plate:** The frying basket and crisper plate have a non-stick coating. Wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn food residues, soak them in hot water for about 10 minutes. These parts are not dishwasher safe.
3. **Clean Interior:** Wipe the interior of the appliance with a damp cloth. Do not use abrasive cleaners or

steel wool.

4. **Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth.
5. **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.

7. TROUBLESHOOTING

If you encounter issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; power outlet not working; basket not inserted correctly.	Check power cord connection; test outlet with another appliance; ensure basket is fully pushed in.
Food is not cooked evenly.	Basket overloaded; food not shaken/turned.	Do not overload the basket; shake or turn food halfway through cooking.
White smoke comes from the appliance.	Grease residue from previous use; fatty ingredients.	Clean the basket and crisper plate thoroughly; remove excess oil from food before air frying.
Food is not crispy.	Ingredients not suitable for air frying; too much moisture.	Ensure ingredients are dry; lightly brush with oil for extra crispiness.

8. SPECIFICATIONS

- **Model Number:** KAAF250EBK
- **Capacity:** 6.5 Liters
- **Power Output:** 1800 Watts
- **Voltage:** (Not specified, typically 220-240V for EU)
- **Temperature Range:** 80°C - 200°C (176°F - 392°F)
- **Control Method:** Touch Control
- **Material:** Plastic (exterior), Non-stick interior coating
- **Dimensions (L x W x H):** Approximately 36 cm x 32 cm x 32 cm
- **Color:** Black
- **Special Feature:** Temperature Control



Image: The Nedis KAAF250EBK Air Fryer with its approximate dimensions indicated: 32cm width, 32cm depth, and 36cm height, providing a visual reference for size.

9. WARRANTY AND SUPPORT

This Nedis KAAF250EBK Air Fryer comes with a **2-year manufacturer's warranty**. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting beyond this manual, or warranty inquiries, please contact your retailer or the official Nedis customer service. Refer to the contact information provided with your purchase or visit the official Nedis website for further assistance.