

Discovery E8200

Discovery E8200 Electric Trekking Bike User Manual

Model: E8200 | Brand: Discovery

INTRODUCTION

Welcome to the user manual for your new Discovery E8200 Electric Trekking Bike. This manual provides essential information for the safe and efficient operation, assembly, maintenance, and troubleshooting of your bicycle. Please read this manual thoroughly before your first ride and keep it for future reference.

The Discovery E8200 is an assisted pedaling trekking bike featuring 28-inch wheels, a cushioned front fork, mechanical disc brakes, and a Shimano 7-speed derailleur. It is equipped with a 250W rear wheel motor and a 36V 10.4Ah (374.4 Wh) battery, offering up to 70 km of range and a maximum assisted speed of 25 km/h. The bike includes 6 levels of assistance controlled via an LCD screen on the handlebar, along with a 6 km/h walk-assist function.



Figure 1: Side view of the Discovery E8200 Electric Trekking Bike, showcasing its frame, wheels, and integrated battery.

SAFETY INFORMATION

Your safety is paramount. Always adhere to the following safety guidelines:

- Always wear a helmet that meets safety standards.
- Ensure all components, especially brakes, tires, and quick releases, are in good working order before each ride.
- Familiarize yourself with local traffic laws and regulations regarding electric bicycles.
- Do not ride under the influence of alcohol or drugs.
- Be visible: Use lights and reflective gear, especially when riding in low light conditions.
- Maintain a safe distance from other vehicles and pedestrians.
- Avoid riding in extreme weather conditions.
- Do not modify the electrical system or motor of the bicycle.
- Keep hands and feet clear of moving parts, especially the chain and gears.
- The battery should only be charged using the original charger provided.

SETUP AND INITIAL ASSEMBLY

Your Discovery E8200 bike may require some assembly upon arrival. Follow these steps carefully:

1. **Unpacking:** Carefully remove the bicycle and all components from the packaging. Retain packaging for potential future transport or returns.
2. **Handlebar Installation:** Attach the handlebar to the stem. Ensure it is centered and the bolts are tightened securely. Adjust the angle for comfortable riding.
3. **Seat Post and Saddle:** Insert the seat post into the frame and adjust the saddle height to ensure your feet can comfortably touch the ground when stopped, or for optimal pedaling efficiency. Tighten the quick-release lever or bolt.
4. **Pedal Attachment:** Identify the left (L) and right (R) pedals. The left pedal has a reverse thread. Apply a small amount of grease to the threads and screw them into the crank arms. Tighten firmly with a wrench.
5. **Front Wheel Installation (if detached):** If the front wheel is not pre-installed, align the disc brake rotor with the caliper and insert the axle into the fork dropouts. Secure with the quick-release skewer or axle nuts.
6. **Tire Inflation:** Inflate both tires to the recommended pressure indicated on the tire sidewall.
7. **Initial Battery Charge:** Before your first ride, fully charge the battery. Connect the charger to the battery port and then to a power outlet. The indicator light on the charger will change when fully charged.
8. **Brake Check:** Test both front and rear brakes to ensure they engage properly and stop the bike effectively. Adjust if necessary.
9. **General Inspection:** Double-check all bolts, nuts, and quick releases to ensure they are tight and secure.



Figure 2: Front view of the bike, useful for handlebar and front wheel assembly.



Figure 3: Detailed view of the handlebar, showing the display unit and controls for initial setup.

OPERATING INSTRUCTIONS

Understanding your bike's controls and features will enhance your riding experience.

1. Powering On/Off and LCD Display

The LCD display on your handlebar controls the electric assist system.

- **Power On:** Press and hold the power button on the display for a few seconds until the screen illuminates.
- **Power Off:** Press and hold the power button again until the screen turns off.
- **Display Information:** The LCD shows current speed, battery level, assistance level (PAS), trip distance, and total odometer.
- **Assistance Levels:** Use the '+' and '-' buttons to cycle through the 6 levels of pedal assistance. Level 1 provides minimal assist, while Level 6 provides maximum assist.
- **Walk-Assist Function:** Press and hold the '-' button (or a dedicated walk-assist button if present) to activate the 6 km/h walk-assist mode, useful for pushing the bike uphill or through pedestrian areas.



Figure 4: Detailed view of the LCD display, showing battery, speed, and pedal assist level indicators.

2. Gear Shifting (Shimano 7-Speed)

Your bike is equipped with a Shimano 7-speed derailleur system.

- Use the shifter on the right handlebar to change gears.
- Shift to a lower gear (larger cog) for easier pedaling on inclines.
- Shift to a higher gear (smaller cog) for faster speeds on flat terrain or downhill.
- Always pedal lightly when shifting gears to ensure smooth transitions and prevent damage to the drivetrain.



Figure 5: Rear view of the bike, highlighting the Shimano 7-speed derailleur and rear rack.

3. Braking System (Mechanical Disc Brakes)

The Discovery E8200 features mechanical disc brakes for reliable stopping power.

- The right brake lever controls the rear brake, and the left brake lever controls the front brake.
- Apply both brakes simultaneously for effective and controlled stopping.
- Avoid sudden, hard braking with only the front brake, especially at high speeds, as this can lead to loss of control.
- Brake performance may be reduced in wet conditions. Ride cautiously.



Figure 6: Rear disc brake and motor assembly.



Figure 7: Front disc brake assembly.

MAINTENANCE

Regular maintenance will prolong the life of your electric bike and ensure safe operation.

- **Battery Care:**
 - Charge the battery fully after each ride, or at least once a month if not in use, to maintain battery health.
 - Store the battery in a cool, dry place, away from direct sunlight and extreme temperatures.
 - Do not completely drain the battery regularly, as this can reduce its lifespan.
- **Tire Pressure:** Check tire pressure before each ride and inflate to the recommended PSI (pounds per square inch) found on the tire sidewall.
- **Brakes:** Regularly inspect brake pads for wear and replace them when necessary. Ensure brake levers have proper tension and the brakes engage smoothly.
- **Chain and Drivetrain:** Keep the chain clean and lubricated. Periodically check for chain stretch and wear on the gears.
- **Bolts and Fasteners:** Periodically check all bolts, nuts, and quick releases for tightness. Loose components can be dangerous.
- **Cleaning:** Clean your bike regularly with a damp cloth and mild soap. Avoid using high-pressure washers directly on electrical components.
- **Professional Service:** For complex repairs or adjustments, especially involving the motor or electrical system, consult a qualified bicycle mechanic.

TROUBLESHOOTING

This section addresses common issues you might encounter with your Discovery E8200.

Problem	Possible Cause	Solution
Motor not assisting / No power	Battery low or not charged; Power button not pressed; Loose electrical connection; System error.	Charge battery fully; Ensure display is powered on; Check all visible cable connections; Consult manual for error codes or contact support.
Battery not charging	Charger not connected properly; Faulty charger or battery; Power outlet issue.	Ensure secure connection; Try a different power outlet; Contact support for charger/battery replacement.
Brakes squealing or not effective	Dirty brake pads/rotors; Worn brake pads; Misaligned caliper; Loose cable.	Clean pads/rotors with disc brake cleaner; Replace worn pads; Adjust caliper alignment; Tighten brake cable.
Gears not shifting smoothly	Dirty or unlubricated chain; Derailleur out of adjustment; Bent hanger.	Clean and lubricate chain; Adjust derailleur limit screws and cable tension; Consult a bike mechanic for bent hanger.
Unusual noises from bike	Loose components; Dry bearings; Something rubbing.	Inspect all parts for looseness; Lubricate moving parts; Identify and remove rubbing objects.

SPECIFICATIONS


Feature	Detail
Model	Discovery E8200
Bike Type	Electric Trekking Bike

Feature	Detail
Frame Material	Aluminum
Wheel Size	28 Inches
Color	Matte Black
Motor Power	250 W (Rear Wheel Motor)
Battery	36 V 10.4 Ah (374.4 Wh) Lithium-ion
Max Assisted Range	Up to 70 km (43 miles)
Max Assisted Speed	25 km/h (15.5 mph)
Assistance Levels	6 levels, controlled via LCD display
Gears	Shimano 7-speed derailleur
Brakes	Mechanical Disc Brakes (Front & Rear)
Suspension	Front Fork Suspension
Included Components	Bicycle, Battery, Charger

WARRANTY AND SUPPORT

For information regarding your product's warranty, please refer to the warranty card or documentation included with your purchase. Warranty terms and conditions may vary.

If you encounter issues not covered in the troubleshooting section or require further assistance, please contact the retailer or manufacturer's customer support. Have your model number (E8200) and purchase details ready when contacting support.




[pdf] User Manual Instructions Guide

Sophos UTM Administration Guide Limited Pdf Manual SophosUTM manual en docs sophos nsg utm 9700 us |||

Sophos UTM Administration Guide Product version: 9.700 Contents Contents ii 1 Installation 17 ... Hardware and license information not the owner , for example: processor Intel R Core TM 2 Duo CPU **E8200** 2.66GHz memory 512MiB System Memory eth0 network 82545EM Gigabit Ethernet Controller id: UTM...


lang:en score:26 filesize: 6.72 M page_count: 568 document date: 2019-10-25



[\[pdf\]](#) User Manual Instructions Guide

Sophos UTM Administration Guide Limited Utm 9 Manual Pdf SophosUTM manual en docs sophos nsg utm on aws 707 |||


Sophos UTM on AWS Administration Guide Product version: 9.707 Contents Contents ii 1 Installati ... Hardware and license information not the owner , for example: processor Intel R Core TM 2 Duo CPU **E8200** 2.66GHz memory 512MiB System Memory eth0 network 82545EM Gigabit Ethernet Controller id: UTM... lang:en **score:25** filesize: 7.04 M page_count: 578 document date: 2021-07-30



[\[pdf\]](#) User Manual Instructions Guide Declaration of Conformity

Sophos UTM Administration Guide Limited manual en doc sophos nsg utm 9 708 |||


Sophos UTM Administration Guide Product version: 9.706 Contents Contents ii 1 Installation 16 ... Hardware and license information not the owner , for example: processor Intel R Core TM 2 Duo CPU **E8200** 2.66GHz UTM 9 58 4.2 WebAdmin Settings 4 Management memory 512MiB System Memory eth0 n... lang:en **score:25** filesize: 7.35 M page_count: 589 document date: 2022-02-04



[\[pdf\]](#) User Manual Instructions Guide

Sophos UTM Administration Guide Limited Xg Firewall Manual Pdf XG Web Reference and Admin administration guide 9 600 docs sophos nsg utm 6 en us |||


Sophos UTM Administration Guide Product version: 9.600 Contents Contents ii 1 Installation 17 ... Hardware and license information not the owner , for example: processor Intel R Core TM 2 Duo CPU **E8200** 2.66GHz memory 512MiB System Memory eth0 network 82545EM Gigabit Ethernet Controller id: UTM... lang:en **score:24** filesize: 7.23 M page_count: 591 document date: 2019-01-17



[\[pdf\]](#) User Manual Instructions Guide

Sophos UTM Administration Guide Limited manual en docs sophos nsg utm 9 703 us

Sophos UTM Administration Guide Product version: 9.703 Contents Contents ii 1 Installation 17 ... Hardware and license information not the owner , for example: processor Intel R Core TM 2 Duo CPU **E8200** 2.66GHz memory 512MiB System Memory eth0 network 82545EM Gigabit Ethernet Controller id: UTM... lang:en **score:24** filesize: 6.73 M page_count: 568 document date: 2020-04-09



[\[pdf\]](#) User Manual Instructions Guide


Sophos UTM 9 7 06 Administration Guide Limited manual en docs sophos nsg utm 706 |||

Sophos UTM Administration Guide Product version: 9.706 Contents Contents ii 1

Installation 18 ... Hardware and license information not the owner , for example:

processor Intel R Core TM 2 Duo CPU **E8200** 2.66GHz memory 512MiB System Memory eth0 network 82545EM Gigabit Ethernet Controller id: UTM...

lang:en **score:24** filesize: 6.84 M page_count: 652 document date: 2024-08-28




[\[pdf\]](#) Datasheet Warranty

HP E8200 zL Switch Series NetMarcom ProCurve 4AA2 7811ENW h17007 www1 hpe 80 docs mark |||

HP **E8200** zL Switch Series Data sheet Product overview Key features The HP **E8200**

zL Switch Series offers high performance, scalability, and a wide range of features in a high-availability platform that dramatically reduces complexity and provides reduced cost of ownership. As part of a unified wir...

lang:en **score:22** filesize: 6.33 M page_count: 13 document date: 2011-05-04



[\[pdf\]](#) User Manual Instructions Guide

Sophos UTM Administration Guide Limited Pdf Manual SophosUTM manual en docs sophos nsg utm 9

707 ||| ||| Sophos UTM Administration Guide Product version: 9.707 Contents Contents ii 1 Installation 18


1.1 Recommended Reading 18 1.2 System Requirements 18 1.2.1 UPS Device Support 19 1.2.

Sophos UTM Administration Guide Product version: 9.707 Contents Contents ii 1

Installation 18 ... Hardware and license information not the owner , for example:

processor Intel R Core TM 2 Duo CPU **E8200** 2.66GHz memory 512MiB System Memory eth0 network 82545EM Gigabit Ethernet Controller id: UTM...

lang:en **score:22** filesize: 7.46 M page_count: 622 document date: 2021-07-30



[\[pdf\]](#) Guide

CHANGE the rules of networking Series guide US English A4 3Com A E HP IntelliJack Intelligent Management Center S TippingPoint V advance enterprise essential family integrated portfolio router security services solutions standards based value 4AA1 4855ENN gregory j check@hp HPN Guide tcm 183 1079663 www8 hp uk en |||

the rules of networking. HP is changing the rules of networking with a full portfolio of standardsba ... ion Kit. 27 E-Series products Modular switches HP **E8200** zl Switch Series. 28 HP E5400 zl Switch Series....

lang:de **score:20** filesize: 8.24 M page_count: 108 document date: 2011-03-14




[\[pdf\]](#) Datasheet Warranty

HP E8200 zl Switch Series US English 10 GbE 4AA2 7811ENW J8715B ONE QoS connectivity distribution edge intelligent protection scalable series switch Gregory j check@hp Data sheet Product overview The offers high performance scalability and a wide range of features in availability platform that 8200zl alternativo cz img asp attid 40676 |||

HP **E8200** zl Switch Series Data sheet Product overview Key features The HP **E8200** zl Switch Series offers high performance, scalability, and a wide range of features in a high-availability platform that dramatically reduces complexity and provides reduced cost of ownership. As part of a unified wir...


lang:en **score:19** filesize: 472.95 K page_count: 9 document date: 2010-09-15



[\[pdf\]](#) Specifications Datasheet Warranty Borchure

HP 8200 zl Switch Series Product Bulletin QuickSpec 2007 Desktop Assistance LP All Rights Reserved Hewlett Packard Enterprise J9638A ABA Data Sheet Brochure HPE 8206 44G PoE 2XG SFP v2 L4 managed 44 x 10 100 1000 2 Gigabit rack mountable with E8200 Premium License ab41f749 61e7 4856 bcd2 83cd8a6dfd2 cdn cnetcontent ab 41 |||

QuickSpecs Overview HP 8200 zl Switch Series Product overview The HP 8200 zl Switch Series offers ... tandard Switch Chassis HP 8206 zl Switch w/Premium Software 1 Power Supply required 1 - J9092A - HP **E8200** zl Management Module Included 2 - J9093A - HP **E8200** zl Fabric Module Included 1 - J9095A - HP ... lang:en **score:18** filesize: 2.92 M page_count: 52 document date: 2014-02-17




[\[pdf\]](#) User Manual

Computer Organization and Design RISC V Edition The Hardware Software Interface Morgan Kaufmann Series in Architecture David A Patterson John L Hennessy manually by plugging cables setting switches data were entered on punched calculated from the instruction mix manual Although it might edition home usc.edu.cn ~louwenqi reference books tools

Computer Organization and Design The Hardware/Software Interface: RISC-V Edition David A. Patterson ... compiler can exploit. The Intel CPUs are a 3.2 GHz Extreme X9775 code named Penryn , a 2.66 GHz **E8200** code named Wolfdale , a desktop, pre-Penryn CPU, and a 1.83 GHz T2400 code named Yonah ,...

lang:en score:18 filesize: 33.72 M page_count: 1665 document date: 2018-03-06




[\[pdf\]](#) User Manual Specifications Documentation Guide Warranty

Sophos UTM Administration Guide Limited SophosUTM Contents 6 2 2Advanced 170 3QualityofService QoS 171 3 1Status 2TrafficSelectors 173 3BandwidthPools 176 4DownloadThrottling 178 utm9200 manual eng la en sophos.us/medialibrary/documentation

Sophos UTM administration guide Product version: 9.200 Document date: Tuesday, February 18, 2014 T ... Hardware and license information not the owner , for example: processor Intel R Core TM 2 Duo CPU **E8200** 2.66GHz memory 512MiB System Memory eth0 network 82545EM Gigabit Ethernet Controller id: UTM...

lang:en score:18 filesize: 8.76 M page_count: 616 document date: 2014-02-18



[\[pdf\]](#) Quick Start Guide Guide

HP 8200 zl Switches Installation and Getting Started Guide Hewlett Packard Development Company L P 3648723de60744c6dabfb663b8d999a0dc9b gzhls at blob ldb c a 4 1 |||

HP 8200 zl Switches Installation and Getting Started Guide Power over Ethernet HP 8200 zl Switches ... cognized by the switch and begin functioning immediately after they are installed. Caution The HP **E8200** zl switch and its components are sensitive to static discharge. Use an antistatic wrist strap ...

lang:en score:17 filesize: 13.46 M page_count: 144 document date: 2013-06-13



[\[pdf\]](#)

HP AllianceONE Services z1 Module with Avaya Aura Session Border Controller powered by Acme Packet US English 4AA3 0775ENW VoIP MGCP SCCP Gateway Control Protocol Connection Part User Datagram NAT UC C Core 2 Duo signaling E5400 E8200 switch SIP trunking infrastructure Unified Communications IP network borders PBX claudia.g.abramson@hp hp.hpinfo/newsroom/press_kits/2010/HPOptimizesAppDelivery |||

HP Services z1 Module for Avaya Aura Session Border Controller powered by Acme Packet Converge, sec ... rtified solution that combines Avaya Aura and SBC software on a module designed for HP E5400 z1 and **E8200** z1 switch series products. By consolidating equipment, centralizing services, and simplifying ...

lang:en score:16 filesize: 393.64 K page_count: 4 document date: 2010-09-16




[\[pdf\]](#) Guide

CHANGE the rules of networking Series guide US English 3Com 4AA1 4855ENW A E HP IntelliJack Intelligent Management Center S TippingPoint V advance enterprise essential family integrated portfolio router security services solutions standards based value gregory j check@hp Change The Rules hp hpinfo newsroom press kits 2011 InteropLasVegas2011 ||| the rules of networking. HP is changing the rules of networking with a full portfolio of standards-b 27 E-Series products Modular switches HP **E8200** zL Switch Series. 28 HP E5400 zL Switch Seri... lang:de **score:15** filesize: 7.91 M page_count: 108 document date: 2011-03-14




[\[pdf\]](#) User Manual Instructions

Computer Organization and Design The Hardware Software Interface ARM® Edition 2017 1074pp 978 0 12 801733 3 David A Patterson ARM edition architecture reference manual is 5400 pages long—we found a subset of ARMv8 instructions that similar in size nature to the MIPS core used prior home usc edu cn ~leedsong books tools In Praise of Computer Organization and Design: The Hardware/ Software Interface, ARM Edition Textb ... oblem sizes. GFLOPS N-Body Performance on Intel CPUs 2 1.8 1.6 1.4 1.2 1 0.8 0.6 0.4 0.2 0 T2400 **E8200** X9775 X9775-Cuda 512 768 1024 1536 2048 3072 4096 6144 8192 12,288 16,384 24,576 32,768 Numb... lang:en **score:15** filesize: 30.01 M page_count: 1074 document date: 2018-03-06



[\[pdf\]](#) User Manual Quick Start Guide Guide

HP 5400 zL Switches Installation and Getting Started Guide Hewlett Packard Development Company L P 4a9157d050c9e575808842255622754724db gzhls at blob ldb c 7 f 2 ||| HP 5400 zL Switches Installation and Getting Started Guide Power over Ethernet HP 5400 zL Switches ... J9536A, J9537A, J9549A, J9550A, J9547A, J9548A, J9637A * For use with HP Networking Switch Series **E8200** only conforms to the following Product Specifications and Regulations: EMC: Class A EN 55022:... lang:en **score:14** filesize: 9.96 M page_count: 134 document date: 2013-07-31



[HP 5400 zl Switches Installation and Getting Started Guide](#)

This guide provides comprehensive instructions for installing and getting started with HP 5400 zl switches, covering setup, configuration, and troubleshooting for high-speed networking.


lang:en score:14 filesize: 10.02 M page_count: 135 document date: 2013-06-14



[\[pdf\] User Manual Troubleshooting Guide](#)

Contents Manual installation I f the screen does not appear automatically when DVD is inserted it possible that auto run function may be deactivated In this case proceed as follows 1 Double click on Workspace icon Windows Desktop or open Explorer 2 EPILEPSY WARNING Please read before using video game allowing your children to use Some people are susceptible epileptic seizures loss of manual english t 1252697080 cdn akamai steamstatic steam apps 12640 manuals steampowered 80 Manuals M a nua l Contents Epilepsy warning 4 ... requirements Operating system: Windows XP with Service Pack 2, Vista Processor: Intel Core™ 2 Duo **E8200**, 2.6 GHz of comparable CPU RAM: 2048 MB for Windows XP, 2560 MB for Vista Graphics card: NVI...

lang:en score:14 filesize: 4.89 M page_count: 76 document date: 2009-03-12



[\[pdf\] Specifications Warranty](#)

HP 8200 zl Switch Series Product Bulletin QuickSpec 2007 Desktop Assistance LP All Rights Reserved 8212 switch dustinimages azureedge net media d200001003277160

QuickSpecs Overview HP 8200 zl Switch Series Product overview The HP 8200 zl Switch Series offers ... tandard Switch Chassis HP 8206 zl Switch w/Premium Software 1 Power Supply required 1 - J9092A - HP **E8200** zl Management Module Included 2 - J9093A - HP **E8200** zl Fabric Module Included 1 - J9095A - HP ...

lang:en score:13 filesize: 2.92 M page_count: 52 document date: 2013-12-08

QuickSpecs

HPE 8200 xl Switch Series

Overview


HPE 8200 zl Switch Series

Product overview

Product overview

The HPE 8200 4 Switch Series offers high performance, scalability, and a wide range of features in a high-availability platform that dramatically reduces complexity and the total cost of ownership. As part of a unified wired and wireless network infrastructure solution, the 8200 4 Switch Series provides platform technology, system software, system management, application integration, wired and wireless integration, network security, and support that are common across HPE modular and fixed-port switches. Together, these features deliver an agile, cost-effective, high-availability network solution.

With key technologies to provide solution longevity, the S200 at Switch Series delivers long-term investment protection without added complexity for network core, aggregation, and high-availability access layer deployments. In addition to all of these capabilities, this switch series comes with Limited Lifetime Warranty 2.0—making it a compelling switching solution.



- | Front of #306 at Switch 7063A | |
|--|---|
| 1 Power and Fault LEDs | 7 Management Module Reset button, and Status LEDs |
| 2 Locator LED | 8 Component Status LEDs Switch |
| 3 Reset and Clear buttons | 9 Console Port |
| 4 Self-test LED | 10 Auxiliary Port |
| 5 Status LEDs for the Fans, Power Supplies, and Switch Modules | 11 Switch Modules, and slots with Link and Mode LEDs for each port located on each module |
| 6 LED Mode Select button and indicator LEDs | |



Page 1

[\[pdf\]](#) Specifications

HPE 8200 zl Switch Series 30C18BE9CA5B0197877008C9072B298153CC3266 source cdn cnetcontent syndication feeds hp ent inline content 6H 3 0

RETIRED: Retired products sold prior to the November 1, 2015 separation of Hewlett-Packard Company i ... d Switch Chassis HP 8206 zl Switch with Premium Software 1 Power Supply required 1 - J9092A - HPE **E8200** zl Management Module Included 2 - J9093A - HPE **E8200** zl Fabric Module Included 1 - J9095A - ...

lang:en score:12 filesize: 844.51 K page count: 82 document date: 2018-08-11

QuickSpecs

HPE 8200 xl Switch Series

Overview


HPE 8200 xl Switch Series

Product overview

Product overview

The HPE 8200 4 Switch Series offers high performance, scalability, and a wide range of features in a high-availability platform that dramatically reduces complexity and the total cost of ownership. As part of a unified wired and wireless network infrastructure solution, the 8200 4 Switch Series provides platform technology, system software, system management, application integration, wired and wireless integration, network security, and support that are common across HPE modular and fixed-port switches. Together, these features deliver an agile, cost-effective, high-availability network solution.

With key technologies to provide solution longevity, the 8000 zl Switch Series delivers long-term investment protection without added complexity for network core, aggregation, and high-availability access layer deployments. In addition to all of these capabilities, this switch series comes with Limited Lifetime Warranty 2.0—making it a compelling switching solution.



- | Front of R306 at Switch J638A | |
|--|---|
| 1 Power and Fault LEDs | 7 Management Module Reset button, and Status LEDs |
| 2 Locator LED | 8 Component Status LEDs Switch |
| 3 Reset and Clear buttons | 9 Console Port |
| 4 Self-test LED | 10 Auxiliary Port |
| 5 Status LEDs for the Fans, Power Supplies, and Switch Modules | 11 Switch Modules, and slots with Link and Mode LEDs for each port located on each module |
| 6 LED Mode Select button and indicator LEDs | |



Hewlett Packard
Electronics

Page 1

[\[pdf\]](#) Specifications Datasheet

QuickSpecs hp 5400zl series switch c04111638 andovercg datasheets |||

RETIRED: Retired products sold prior to the November 1, 2015 separation of Hewlett-Packard Company i ... d Switch Chassis HP 8206 zL Switch with Premium Software 1 Power Supply required 1 - J9092A - HPE **E8200** zL Management Module Included 2 - J9093A - HPE **E8200** zL Fabric Module Included 1 - J9095A - ...

lang:en score:12 filesize: 844.51 K page_count: 82 document date: 2019-02-17

[\[pdf\]](#) Decleration of Conformity

Microsoft Word HP Networking Product FS final 041910 2 doc devich HPNetworkingProductFS hp hpinfo
newsroom press kits 2010 HPNetworkingRoadmap |||

FACT SHEET HP Networking Portfolio: Transforming the Industry HP introduced a comprehensive network ... cost of ownership 2 and lifetime warranty The E Series is made up of: -- HP ProCurve switch series **E8200**, E6200, E5400, E4200, E3500, E2910, E2610, E2810, E2520 and E2510 -- 3Com switch series E5500G...

lang:en score:11 filesize: 98.17 K page count: 3 document date: 2010-04-19

