

[Manuals.plus](#) /

› [DRONEEYE](#) /

› DRONEEYE 4DF9 GPS Drone User Manual

DRONEEYE 4DF9

DRONEEYE 4DF9 GPS Drone User Manual

Model: 4DF9

INTRODUCTION

Welcome to the world of aerial photography and exploration with your new DRONEEYE 4DF9 GPS Drone. This manual provides essential information for safe operation, setup, maintenance, and troubleshooting to ensure you get the most out of your drone. Please read this manual thoroughly before operating the drone.

SAFETY GUIDELINES

Operating a drone requires responsibility. Adhere to all local regulations and guidelines for drone usage. Failure to do so may result in property damage, injury, or legal penalties.

- **Pre-Flight Check:** Always inspect the drone, propellers, and batteries for any damage before each flight.
- **Weather Conditions:** Do not fly in strong winds, rain, snow, or fog. Optimal conditions are calm and clear.
- **Line of Sight:** Always maintain visual line of sight with your drone during flight.
- **No-Fly Zones:** Avoid flying near airports, military bases, power lines, or other restricted areas.
- **Battery Safety:** Use only approved chargers and batteries. Do not overcharge or puncture batteries. Store them in a cool, dry place.
- **Respect Privacy:** Be mindful of privacy when recording videos or taking photos.
- **Age Recommendation:** This product is recommended for users aged 14 years and up.

PACKAGE CONTENTS

Upon unboxing, please verify that all components are present. While the product is an RC Quadcopter, please refer to your specific product packaging for the exact inclusion of a remote control unit.

- DRONEEYE 4DF9 GPS Drone
- Remote Controller (typically included with RC models)
- 1080P HD Camera (integrated)
- 2 x Lithium Ion Batteries
- Propellers (spare set may be included)
- USB Charging Cable

- Carrying Case
- User Manual (this document)



Image: The DRONEEYE 4DF9 GPS Drone, its remote controller, two included batteries, and the convenient carrying case.

PRODUCT COMPONENTS

Familiarize yourself with the main parts of your DRONEEYE 4DF9 drone:



1080P HD Camera

Integrated camera capable of capturing crystal clear 1080p photos and videos at 16-25 frames per second. Features a wide 110° FOV (Field of View) Wi-Fi camera for immersive aerial views.



Brushless Motors

Equipped with powerful and durable brushless motors, providing high aerodynamic efficiency, quieter operation, and longer lifespan compared to brushed motors.



Intelligent Batteries

The drone comes with two Lithium Ion batteries, offering a combined flight time of approximately 50 minutes (25 minutes per battery) on a single charge. These are designed for safe and efficient charging via USB 3.0.

SETUP

1. Battery Installation and Charging

1. Insert the fully charged battery into the drone's battery compartment until it clicks into place.
2. To charge, connect the battery to the USB charging cable, then plug the cable into a USB power source (e.g., computer, USB wall adapter). The charging indicator will show progress.
3. Ensure batteries are fully charged before each flight for optimal performance and safety.

2. Propeller Attachment (if required)

The propellers are typically pre-installed. If replacement is needed, ensure correct propeller (A or B) is matched to the corresponding motor arm as indicated on the drone.

3. App Download and Connection

Download the official DRONEEYE app from your mobile device's app store (iOS/Android). This app is essential for FPV (First Person View) live video, advanced flight modes, and camera control.

1. Power on the drone and the remote controller.
2. On your mobile device, go to Wi-Fi settings and connect to the drone's Wi-Fi network (usually named "DRONEEYE-XXXXXX").
3. Open the DRONEEYE app. The live video feed should appear, indicating a successful connection.

4. GPS Calibration

For stable flight and accurate GPS functions (Return Home, Follow Me, Waypoint), GPS calibration is crucial before each flight outdoors.

1. Place the drone on a flat, open surface away from magnetic interference.
2. Follow the on-screen instructions in the DRONEEYE app or the remote controller's indicator lights for compass

calibration (horizontal and vertical rotations).

3. Wait for sufficient GPS satellites to be acquired (indicated by solid GPS signal lights on the drone/app).

OPERATING THE DRONE

Basic Flight Controls

Familiarize yourself with the remote controller's sticks and buttons. Refer to the remote controller diagram in the app or a separate quick start guide for specific button layouts.

- **One Key Take Off/Landing:** Press the dedicated button for automatic take-off to a safe altitude or gentle landing.
- **Throttle Stick (Left Stick, Mode 2):** Controls altitude (up/down) and yaw (rotation left/right).
- **Directional Stick (Right Stick, Mode 2):** Controls forward/backward (pitch) and left/right (roll) movement.
- **Auto Hovering Mode:** The drone will automatically maintain its altitude and position when sticks are centered, thanks to GPS and optical flow positioning.

INTELLIGENT FLIGHT



Image: Visual representation of One Key Start/Land, Headless Mode, and Orbit Flight capabilities.

Intelligent Flight Modes

The DRONEEYE 4DF9 offers several intelligent flight modes for enhanced user experience and creative shots, accessible via the mobile app:

- **Follow Me Mode:** The drone will automatically follow the user (or the mobile device) at a set distance and altitude, capturing dynamic footage.
- **Around Mode (Point of Interest):** Set a central point, and the drone will orbit around it at a specified radius and speed, keeping the camera focused on the point.
- **Waypoint Mode (TapFly):** Draw a path on the map within the app, and the drone will autonomously fly along the designated route, allowing you to focus on camera control.
- **Headless Mode:** Simplifies flight by eliminating the need to orient the drone. The drone's forward direction is relative to the pilot's position.
- **Gravity Control Mode:** Control the drone's movement by tilting your mobile device.



INTELLIGENT FLIGHT

MULTIPLE FLIGHT MODES ADD FUN TO THE PLAY



FOLLOW ME

CIRCLE FLY



WAYPOINT



Camera Operation and FPV

The integrated 1080P HD camera provides real-time FPV (First Person View) transmission to your connected mobile device.

- **Photo/Video Capture:** Use the dedicated buttons on the remote controller or the app interface to take photos or start/stop video recording.
- **FPV Live Video:** View the drone's camera feed directly on your smartphone screen.
- **Gesture Control:** Perform specific hand gestures in front of the camera to trigger photo or video capture.
- **App Functions:** The app allows for instant 50x magnification zoom, adding background music to videos, video rotation, multiple filter functions, VR Mode, and one-click sharing to social media.



Image: Demonstrates FPV real-time transmission, allowing users to share incredible views instantly.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the drone body and camera lens. Avoid using harsh chemicals.
- **Propeller Inspection:** Regularly check propellers for cracks, bends, or damage. Replace damaged propellers immediately.
- **Battery Care:** Store batteries in a cool, dry place. Do not store fully charged or completely depleted batteries for extended periods. Charge them to about 50-60% for long-term storage.
- **Storage:** When not in use, store the drone and its components in the provided carrying case to protect them from dust and physical damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Drone does not power on.	Battery not installed correctly or depleted.	Ensure battery is fully inserted and charged.
No FPV live video.	Wi-Fi not connected or app issue.	Verify Wi-Fi connection to drone. Restart app and drone.
Drone drifts during flight.	Improper calibration or strong winds.	Perform GPS and compass calibration. Fly in calm conditions.
GPS signal loss / Return Home issues.	Weak GPS signal or interference.	Ensure flight in open areas with clear sky. Recalibrate GPS.
Short flight time.	Battery not fully charged or aged battery.	Fully charge batteries. Consider replacing old batteries.

For further assistance, please refer to the official DRONEEYE support channels.

SPECIFICATIONS

Feature	Detail
Brand	DRONEEYE
Model Name	4DF9 (F9 Drone toys)
Camera Resolution	1080p HD (1920x1080 pixels)
Video Frame Rate	16-25 frames per second
Motor Type	Brushless Motor
Navigation System	GPS & GLONASS Dual Satellite Connectivity, Optical Flow Positioning
Flight Time	Approx. 50 minutes (with 2 batteries, 25 mins each)

Feature	Detail
Battery Type	Lithium Ion (2 included)
Connectivity	Wi-Fi (for FPV and app control)
Control Type	App Control, RC (Remote Control)
Recommended Age	14 years and up
Item Weight	1.82 pounds
Package Dimensions	10.91 x 8.27 x 3.7 inches

WARRANTY AND SUPPORT

For warranty information, technical support, or replacement parts, please contact DRONEEYE customer service through the official website or the contact information provided with your purchase. Keep your proof of purchase for warranty claims.

Online Resources:

- [DRONEEYE Official Store on Amazon](#)
- Check the product listing for updated FAQs or support contact details.

© 2024 DRONEEYE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B091Q646TQ>

More documents and user manuals: <https://manuals.plus/>