

[Manuals.plus](#) /

> [SKMEI](#) /

> SKMEI 1257 Digital Men's Sports Watch User Manual

**SKMEI 2724623043463.0**

# SKMEI 1257 Digital Men's Sports Watch User Manual

Model: 2724623043463.0

## INTRODUCTION

---

This manual provides detailed instructions for the operation and maintenance of your SKMEI 1257 Digital Men's Sports Watch. Please read this manual thoroughly before using your watch to ensure proper function and longevity.

The SKMEI 1257 is a versatile digital sports watch featuring dual time, countdown, alarm clock, day calendar, stopwatch timer, and luminous display. It is designed for active lifestyles with 50-meter water resistance.

## PRODUCT OVERVIEW AND KEY FUNCTIONS

---

## KEY FUNCTION



**Image:** Diagram illustrating the key functions of the SKMEI 1257 watch. Labels include "EL Light Button", "Mode Button", "Start/Stop Button", "Reset Button", and indicators for "Week", "Time", "24 Hours", "Date", "Second", and "Alarm On".

The SKMEI 1257 watch features several buttons and display indicators for its various functions:

- **LIGHT Button:** Activates the EL backlight for illumination in low-light conditions.
- **MODE Button:** Cycles through different modes: Time Display, Stopwatch, Alarm, and Dual Time.
- **START/STOP Button:** Used to start and stop the stopwatch, and to adjust settings in various modes.
- **RESET Button:** Used to reset the stopwatch, and to adjust settings in various modes.

## SETUP

### Setting Time and Date

1. From the normal time display mode, press the **MODE** button three times to enter the time setting mode. The seconds will begin to flash.

2. Press the **RESET** button to reset the seconds to 00.
3. Press the **START/STOP** button to move the flashing selection to the hour digits.
4. Press the **RESET** button to adjust the hour. Note the 12/24 hour format indicator.
5. Press the **START/STOP** button to move the flashing selection to the minute digits.
6. Press the **RESET** button to adjust the minutes.
7. Continue pressing the **START/STOP** button to cycle through setting the month, date, and day of the week, adjusting each with the **RESET** button.
8. Once all settings are complete, press the **MODE** button to return to the normal time display.

### 12/24 Hour Format

In the time setting mode (seconds flashing), press the **RESET** button while the hour digits are flashing to toggle between 12-hour (AM/PM indicator) and 24-hour formats.

## OPERATING INSTRUCTIONS

---

### Using the Stopwatch

1. From the normal time display, press the **MODE** button once to enter stopwatch mode. The display will show 00:00:00.
2. Press the **START/STOP** button to start the stopwatch.
3. Press the **START/STOP** button again to pause the stopwatch.
4. Press the **RESET** button to reset the stopwatch to 00:00:00.
5. To exit stopwatch mode, press the **MODE** button.

### Setting the Alarm

1. From the normal time display, press the **MODE** button twice to enter alarm setting mode. The hour digits will flash.
2. Press the **RESET** button to adjust the alarm hour.
3. Press the **START/STOP** button to move the flashing selection to the minute digits.
4. Press the **RESET** button to adjust the alarm minutes.
5. Press the **MODE** button to confirm the alarm setting and return to normal time display.

### Turning Alarm On/Off

In the alarm setting mode, press the **START/STOP** button to toggle the alarm on or off. An alarm icon will appear on the display when the alarm is active.

### Using the EL Backlight

Press the **LIGHT** button to illuminate the display. The backlight will remain on for a few seconds.

## MULTIFUNCTION



**Image:** The SKMEI 1257 watch display illuminated by its EL backlight, showing the time and date clearly in a dark setting.

## MAINTENANCE

---

### Water Resistance

The SKMEI 1257 watch is 50 meters (5 ATM) water resistant. This means it is suitable for swimming and bathing in cold water. **Important:** Do not press any buttons underwater. Avoid exposure to steam and hot water, as this can damage the waterproof seal.

### Cleaning

Clean the watch case and strap with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, which can damage the finish.

### Battery Replacement

When the display becomes dim or functions become erratic, the battery may need replacement. Battery replacement

should be performed by a qualified watch technician to ensure the water resistance is maintained.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Display is blank or dim.	Low battery.	Replace the battery.
Buttons are unresponsive.	Watch may be in a locked mode or internal malfunction.	Try pressing all buttons to see if any respond. If not, a reset may be required by a technician.
Water inside the watch.	Water resistance compromised (e.g., buttons pressed underwater, exposure to hot water/steam).	Immediately take the watch to a qualified technician for inspection and repair to prevent further damage.
Time is incorrect.	Time needs to be reset.	Follow the "Setting Time and Date" instructions in the Setup section.

## SPECIFICATIONS

---

**Brand:** SKMEI

**Model:** 1257

**Movement Type:** Electronic Digital

**Display Method:** Digital

**Case Material:** PC (Polycarbonate)

**Strap Material:** Silicone

**Buckle Style:** Pin Buckle

**Water Resistance Depth:** 50m (5 ATM)

**Dial Diameter:** 50mm

**Dial Thickness:** 15mm

**Strap Width:** 22mm

**Functions:** Dual Time, Countdown, Alarm Clock, Day Calendar, Stopwatch, Luminous Display, 12/24 Hour Format.

## WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the retailer or point of purchase. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance or technical inquiries, please contact SKMEI customer service through their official website or authorized service centers.