

[manuals.plus](#) /

› [Roku](#) /

› [Roku Express 4K 2022 Streaming Media Player User Manual](#)

Roku 3940CA2

Roku Express 4K 2022 Streaming Media Player User Manual

Model: 3940CA2

1. INTRODUCTION

The Roku Express 4K 2022 is a streaming media player designed to deliver HD, 4K, and HDR content to your television. It provides smooth wireless streaming and comes with a simple remote for easy navigation. This manual provides instructions for setting up, operating, and maintaining your Roku Express 4K device.

Incredible picture. Exceptional value.

Des images incroyables. Une valeur exceptionnelle.



4K picture
& HDR color

Images 4K &
couleurs HDR



Smooth
Wi-Fi®

Wi-Fi®
fluide



High speed
HDMI® Cable

Câble HDMI®
Premium



Channel shortcut buttons may vary
Le touches de raccourci vers les chaînes peuvent varier

Image 1.1: Roku Express 4K streaming device and its accompanying remote control.

2. WHAT'S IN THE Box

Before you begin, ensure all items are present in the package:

- Roku Express 4K streaming player
- Roku Simple Remote with TV Controls
- Two AAA batteries for the remote
- USB Power Cable
- Power Adapter
- Premium High Speed HDMI® Cable
- Removable adhesive strip (for mounting)




Image 2.1: Visual representation of the Roku Express 4K streaming player, remote, cables, power adapter, and batteries included in the product packaging.

3. SETUP

Follow these steps to set up your Roku Express 4K streaming media player:

- 1. Connect the Roku Player:** Plug one end of the Premium High Speed HDMI® Cable into the HDMI port on your Roku Express 4K player and the other end into an available HDMI port on your TV.
- 2. Connect Power:** Connect the USB Power Cable to the Roku player and then plug the Power Adapter into a wall outlet. Alternatively, you can plug the USB Power Cable directly into a USB port on your TV if available, ensuring it provides sufficient power.
- 3. Insert Batteries into Remote:** Open the battery compartment on the back of the Roku remote and insert the two AAA batteries, matching the polarity indicators.
- 4. Position the Player:** For optimal remote performance, ensure the front of the Roku player has a clear line of sight to your remote. You can use the included removable adhesive strip to mount the player to your TV or a flat surface.
- 5. Select HDMI Input:** Turn on your TV and use your TV remote to select the HDMI input that corresponds to the port where your Roku player is connected.
- 6. On-Screen Setup:** Follow the on-screen instructions to connect your Roku player to your wireless network and activate your Roku account.



Image 3.1: The rear of the Roku Express 4K device, highlighting the HDMI, USB power, and reset button connections.

What's in the box

Contenu de la boîte



Roku Express 4K streaming player
Lecteur de streaming
Roku Express 4K



Power adaptor
Adaptateur d'alimentation




Removable adhesive strip
Bande adhésive amovible



Remote
Télécommande



Two AAA batteries
Deux piles AAA



USB Power Cable
Câble d'alimentation USB



Premium High Speed HDMI® Cable
Câble HDMI® High Speed Premium

Image 3.2: The Roku Express 4K player positioned below a television, demonstrating a typical setup with connected cables.

4. OPERATING INSTRUCTIONS

Once set up, navigate your Roku Express 4K using the included remote control.

4.1 Remote Control Functions

- Directional Pad (Purple Cross):** Use the up, down, left, and right arrows to navigate menus and select items. The 'OK' button in the center confirms selections.
- Home Button:** Returns you to the Roku home screen.
- Back Button:** Returns to the previous screen or menu.
- Volume Buttons:** Control the volume of your TV.
- Mute Button:** Mutes or unmutes your TV audio.
- Power Button:** Turns your TV on or off.
- Instant Replay:** Jumps back a few seconds in video playback.

- **Playback Controls:** Play/Pause, Fast Forward, and Rewind buttons for media playback.
- **App Shortcut Buttons:** Dedicated buttons for popular streaming services like Netflix, Disney+, Apple TV+, and Hulu for quick access.




Image 4.1: The Roku remote control, showing the directional pad, home, back, playback, and dedicated app shortcut buttons.

4.2 Navigating the Roku Interface

The Roku home screen displays your installed streaming channels. You can:

- Browse and launch channels.
- Access the Streaming Store to add new channels.
- Search for movies, TV shows, actors, or directors across various channels.
- Adjust settings for your device, network, and display.

A perfect fit for any smart home



Works with
Apple AirPlay



Works with
Apple Home

works
with



works with
Google Home

Apple, Apple Home, AirPlay, HomeKit and Siri are trademarks of Apple Inc., registered in the U.S. and other countries and regions. Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates. Alexa enabled device is required to work with Alexa. Google and Google Home are trademarks of Google LLC. Third party features and services may be subject to change or removal without notice. Only supports English language.

Image 4.2: The Roku user interface on a TV screen, featuring a selection of streaming applications and navigation options.

4.3 Compatibility

The Roku Express 4K is designed to integrate with various smart home ecosystems:

- Works with Apple AirPlay for casting content from Apple devices.
- Compatible with Apple Home for smart home integration.
- Works with Alexa for voice control.
- Compatible with Google Home for smart home integration.

Le choix idéal pour une maison intelligente



Apple, Apple Home, AirPlay, HomeKit et Siri sont des marques de commerce d'Apple Inc. enregistrées aux États-Unis et dans d'autres pays et régions. Amazon, Alexa et tous les logos associés sont des marques commerciales d'Amazon.com, Inc. ou de ses filiales. Pour utiliser avec Alexa, un appareil compatible est nécessaire. Google et Google Home sont des marques de commerce de Google LLC. Les fonctions et les services tiers peuvent être modifiés ou supprimés sans préavis. La recherche vocale n'est possible qu'en anglais.

Image 4.3: Icons illustrating the Roku Express 4K's compatibility with Apple AirPlay, Apple Home, Alexa, and Google Home.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Roku Express 4K:

- Keep the device in a well-ventilated area to prevent overheating.
- Clean the device and remote with a soft, dry cloth. Avoid liquid cleaners.
- Replace remote batteries when performance degrades.
- Ensure the device's software is up to date by checking the settings menu.

6. TROUBLESHOOTING

If you encounter issues with your Roku Express 4K, try the following solutions:

6.1 No Power/Device Not Turning On

- Verify the power adapter is securely plugged into a working wall outlet and the USB cable is firmly connected to the Roku player.

- If using a TV USB port for power, ensure it provides sufficient power (check your TV's manual). Try using the included wall adapter.

6.2 No Picture on TV

- Ensure the HDMI cable is securely connected to both the Roku player and your TV.
- Confirm your TV is set to the correct HDMI input.
- Try a different HDMI port on your TV or a different HDMI cable.

6.3 Remote Not Responding

- Replace the batteries in the remote control.
- Ensure there are no obstructions between the remote and the Roku player.
- If the remote is paired via Wi-Fi Direct (some advanced Roku remotes), try re-pairing it by holding the pairing button inside the battery compartment.

6.4 Network Connection Issues

- Restart your wireless router and modem.
- Go to **Settings > Network > Check connection** on your Roku device to diagnose the issue.
- Ensure your Roku device is within range of your wireless router.

6.5 Poor Picture Quality

- Ensure you are using the included Premium High Speed HDMI® Cable.
- Check your TV's display settings and the Roku's display settings (**Settings > Display type**) to ensure they are configured for 4K/HDR if your TV supports it.
- Verify your internet connection speed meets the requirements for 4K streaming.

7. SPECIFICATIONS

Brand	Roku
Model Name	Express
Item Model Number	3940CA2
Resolution	4K, 720p
Special Feature	Support Dual WiFi
Connectivity Technology	USB
Connector Type	HDMI
Item Weight	1.6 ounces
Product Dimensions	1.7 x 5.6 x 0.8 inches

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Roku website or the documentation included with your product. You can also visit the Roku support pages online for FAQs and troubleshooting guides.

© 2022 Roku, Inc. All rights reserved.