

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [HP](#) /
- > [HP EliteOne 800 G5 24-inch All-in-One Touchscreen PC User Manual](#)

## HP EliteOne 800 G5

# HP EliteOne 800 G5 24-inch All-in-One Touchscreen PC User Manual

Model: EliteOne 800 G5 (2D9S5UW#ABA)

<a href="#">Introduction</a>	<a href="#">Package Contents</a>	<a href="#">Product Overview</a>	<a href="#">Setup</a>	<a href="#">Operating</a>	<a href="#">Maintenance</a>
	<a href="#">Troubleshooting</a>	<a href="#">Specifications</a>	<a href="#">Warranty &amp; Support</a>		

## 1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your HP EliteOne 800 G5 24-inch All-in-One Touchscreen PC. Please read this guide thoroughly before using your device to ensure proper functionality and longevity.



Figure 1: HP EliteOne 800 G5 All-in-One PC with included keyboard and mouse.

## 2. PACKAGE CONTENTS

Verify that all items are present in the package:

- HP EliteOne 800 G5 All-in-One PC
- HP USB Keyboard
- HP USB Mouse
- Power Cord
- Documentation (this manual, safety information)

## 3. PRODUCT OVERVIEW

### 3.1 Front View



Figure 2: Front view of the HP EliteOne 800 G5, showing the 24-inch touchscreen display and integrated speakers.

- **23.8-inch FHD IPS WLED-backlit Touchscreen Display:** Main interactive display area.
- **2 MP FHD Pop-up Webcam:** Located at the top center, retracts when not in use.
- **Integrated Dual Array Digital Microphone:** For clear audio input during calls or recordings.
- **Bang & Olufsen Speakers:** Located below the screen for high-quality audio output.

### 3.2 Side View (Right)

1. Optical Disk Drive
2. Disc drive eject button
3. Standard lock slot (10 mm)
4. Universal Audio Jack with CTIA headset support
5. Headphone connector




Figure 3: Right side view illustrating the optical disk drive and audio ports.


1. **Optical Disk Drive:** For reading and writing CDs/DVDs.
2. **Disc drive eject button:** To open the optical disk drive tray.
3. **Standard lock slot (10 mm):** For security cables.
4. **Universal Audio Jack with CTIA headset support:** For connecting headsets with a microphone.
5. **Headphone connector:** For connecting headphones.

### 3.3 Rear View and Ports



Figure 4: Detailed rear view showing all available ports and connections.

1. **USB 3.1 Gen 2 Type-A port:** High-speed USB connection.
2. **USB 3.1 Gen 2 Type-A port (charge support up to 5V/1.5A):** High-speed USB with charging capability.
3. **Audio line-out connector:** For connecting external speakers or audio systems.
4. **USB 3.1 Gen 1 Type-A ports (2):** Standard USB connections.
5. **RJ-45 (network) jack:** For wired Ethernet connection.
6. **Power connector:** For connecting the power cord.
7. **USB 3.1 Gen 2 Type-A ports (2) wake capable:** High-speed USB ports that can wake the system.
8. **Dual-Mode DisplayPort™ 1.2 (DP++):** For connecting external displays.
9. **HDMI 2.0a connector:** For connecting external displays.
10. **SD card reader 4.0 (NOT INCLUDED on all models):** For reading SD memory cards.
11. **USB 3.1 Type-C™ Gen 2 port (charge support up to 5V/3A):** Reversible USB-C port with charging capability.
12. **Dual-state power button:** To power on/off or put the system to sleep.
13. **Sure View Button (optional):** Activates HP Sure View integrated privacy screen.



- |   |   |
|---|---|
| 1. USB 3.1 Gen 2 Type-A port                                | 7. USB 3.1 Gen 2 Type-A ports (2) wake capable              |
| 2. USB 3.1 Gen 2 Type-A port (charge support up to 5V/1.5A) | 8. Dual-Mode DisplayPort™ 1.2 (DP++)                        |
| 3. Audio line-out connector                                 | 9. HDMI 2.0a connector                                      |
| 4. USB 3.1 Gen 1 Type-A ports (2)                           | 10. SD card reader 4.0 <b>NOT INCLUDED</b>                  |
| 5. RJ-45 (network) jack                                     | 11. USB 3.1 Type-C™ Gen 2 port (charge support up to 5V/3A) |
| 6. Power connector  | 12. Dual-state power button                                 |
|   | 13. Sure View Button (optional)                             |

Figure 5: Rear view highlighting the adjustable height stand and other features.

1. **Fingerprint sensor (NOT INCLUDED on all models):** For biometric authentication.
2. **Rear Port Cover:** Conceals and protects rear ports.
3. **Standard Lock Slot:** For security cables.
4. **Adjustable Height Stand:** Allows for ergonomic positioning of the display.

## 4. SETUP

Follow these steps to set up your HP EliteOne 800 G5 PC:

1. **Unpack the PC:** Carefully remove all components from the packaging.
2. **Position the PC:** Place the All-in-One PC on a stable, flat surface. Ensure adequate ventilation around the device.

3. **Connect Keyboard and Mouse:** Plug the USB keyboard and mouse into any available USB Type-A ports on the rear of the PC.
4. **Connect Power:** Connect the power cord to the power connector on the rear of the PC, then plug the other end into a grounded electrical outlet.
5. **Connect to Network (Optional):** For a wired internet connection, connect an Ethernet cable from your router or modem to the RJ-45 (network) jack on the rear of the PC.
6. **Power On:** Press the dual-state power button, located on the rear of the PC, to turn on the system.
7. **Initial Setup:** Follow the on-screen instructions to complete the Windows 10 Pro setup, including language, region, network connection (if not wired), and user account creation.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Power Management

- **Power On:** Press the power button on the rear of the PC.
- **Sleep Mode:** Briefly press the power button or select 'Sleep' from the Windows Start menu.
- **Shut Down:** Select 'Shut down' from the Windows Start menu.
- **Restart:** Select 'Restart' from the Windows Start menu.

### 5.2 Using the Touchscreen

The 24-inch display supports multi-touch gestures. Common gestures include:

- **Tap:** Equivalent to a mouse click.
- **Double-tap:** Equivalent to a double-click.
- **Press and hold:** Equivalent to a right-click.
- **Pinch/Stretch:** Zoom in or out.
- **Swipe:** Scroll through content or navigate.

### 5.3 Webcam and Audio

- **Webcam:** The 2 MP FHD pop-up webcam automatically extends when an application requires it (e.g., video calls). Gently push it down to retract when not in use for privacy.
- **Microphone:** The integrated dual array digital microphone is active when the webcam is in use or when voice input is required.
- **Speakers:** The Bang & Olufsen speakers provide audio output. Volume can be adjusted via Windows settings or keyboard shortcuts.

### 5.4 Optical Disk Drive

To use the DVD+/-RW SM DL 9.5mm slim tray:

1. Press the eject button on the right side of the PC.
2. Place a CD or DVD onto the tray, ensuring it is seated correctly.
3. Gently push the tray back into the PC until it clicks shut.

## 6. MAINTENANCE

---

### 6.1 Cleaning

- **Screen:** Use a soft, lint-free cloth slightly dampened with water or a screen-cleaning solution. Do not spray liquid directly onto the screen.
- **Chassis:** Wipe with a soft, dry cloth. Avoid abrasive cleaners.
- **Ventilation:** Ensure the ventilation openings are clear of dust and obstructions to prevent overheating.

## 6.2 Software Updates

Regularly update your operating system and drivers to ensure optimal performance and security:

- **Windows Updates:** Go to **Settings > Update & Security > Windows Update** to check for and install updates.
- **HP Support Assistant:** Use the pre-installed HP Support Assistant software to check for driver and firmware updates specific to your HP EliteOne PC.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
PC does not power on	No power, loose connection	Check power cord connection to PC and outlet. Ensure outlet is functional.
No display on screen	PC in sleep mode, display settings issue	Press any key or move mouse to wake. If connected to external display, check display input source.
Touchscreen unresponsive	Software glitch, dirty screen	Restart the PC. Clean the screen with a soft, lint-free cloth.
No audio from speakers	Volume muted, incorrect audio output device	Check volume levels in Windows. Ensure 'Speakers (Bang & Olufsen)' is selected as the default playback device.
Webcam not working	Webcam retracted, privacy settings, driver issue	Ensure webcam is extended. Check Windows privacy settings for camera access. Update webcam drivers via HP Support Assistant.

## 8. SPECIFICATIONS

Key technical specifications for the HP EliteOne 800 G5 24-inch All-in-One PC:

Feature	Detail
Model Number	2D9S5UW#ABA
Display	23.8" diagonal FHD IPS widescreen WLED-backlit touch screen (1920 x 1080)
Processor	Intel Core i5-9500 (9M Cache, up to 4.40 GHz)
Graphics	Intel UHD Graphics 630 (Integrated)
RAM	8 GB DDR4-2666 SDRAM
Storage	256 GB M.2 2280 PCIe NVMe TLC SSD

Feature	Detail
Operating System	Windows 10 Pro
Webcam	2 MP FHD pop-up webcam
Audio	Bang & Olufsen Speakers, Integrated Dual Array Digital Microphone
Optical Drive	DVD+/-RW SM DL 9.5mm slim tray
Ports (Rear)	USB 3.1 Gen 2 Type-A (x3), USB 3.1 Gen 1 Type-A (x2), USB 3.1 Type-C Gen 2 (x1), DisplayPort 1.2 (x1), HDMI 2.0a (x1), RJ-45 (x1), Audio line-out (x1), Power connector (x1)
Ports (Side)	Universal Audio Jack (x1), Headphone connector (x1)
Dimensions (LxWxH)	18.4 x 7.1 x 21.2 inches
Weight	19.24 pounds

## 9. WARRANTY AND SUPPORT

Your HP EliteOne 800 G5 PC comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including coverage duration and service options. For technical support, driver downloads, and additional product information, please visit the official HP support website:

[HP Official Support](#)

When contacting support, have your product model number (2D9S5UW#ABA) and serial number ready.