

[Manuals.plus](#) /

› [A-MIND](#) /

› A-MIND Screen Replacement Instruction Manual for VANKYO MatrixPad S20 10.1-inch Touch Screen Digitizer

A-MIND MatrixPad S20

A-MIND Screen Replacement Instruction Manual for VANKYO MatrixPad S20 10.1-inch Touch Screen Digitizer

Model: MatrixPad S20

INTRODUCTION

This instruction manual provides guidance for the proper installation and care of your A-MIND 10.1-inch touch screen digitizer replacement for the VANKYO MatrixPad S20 tablet. Please read all instructions carefully before beginning the installation process to ensure a successful repair and to prevent damage to your device or the new screen.

Important Safety Notice:

- Screen replacement requires technical skill and specialized tools. If you are not experienced in electronic device repair, it is highly recommended to seek professional assistance to avoid potential damage to your tablet or the replacement screen.
- The screen is made of glass and is fragile. Handle with extreme care during unpacking and installation to prevent breakage.
- Always disconnect the tablet's battery before beginning any repair work to prevent electrical shorts or damage to components.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1x A-MIND Touch Screen Digitizer Replacement for VANKYO MatrixPad S20 (10.1 inch)
- 1x Opening Tools Kit (includes screwdrivers, pry tools, suction cup)
- 1x Adhesive Tape




Image: Contents of the A-MIND screen replacement kit, including the digitizer, screwdrivers, pry tools, suction cup, and adhesive tape.

PRE-INSTALLATION CHECKS AND WARNINGS

1. **Model Verification:** Ensure the replacement screen is specifically for the VANKYO MatrixPad S20 10.1-inch model. Incorrect models may not fit or function properly.
2. **Professional Installation Recommended:** If you lack experience in electronic repairs, consider professional installation. Self-installation risks damaging the screen or tablet, which may void warranty.
3. **Pre-Test the Screen:** Before fully installing the screen with adhesive, connect the new screen's flex cable to the tablet's motherboard (with the battery disconnected). Reconnect the battery and power on the tablet to test touch functionality and display quality. Ensure there are no dead pixels, lines, or unresponsive touch areas. If the screen functions perfectly, proceed with full installation.

4. **Adhesive Warning:** Do not apply adhesive or fully install the screen until it has been thoroughly tested and confirmed to be working correctly. Once adhesive is applied, returns or refunds may not be accepted if issues arise.
5. **Handle with Care:** Screens are fragile. Exercise extreme caution when unpacking, handling, and installing to prevent damage.




Image: Front and back views of the replacement touch screen digitizer, highlighting the flex cable connection.

INSTALLATION GUIDE



This section outlines the general steps for replacing the touch screen digitizer. Specific details may vary based on your tablet's condition. Refer to online video tutorials for visual guidance if needed.

1. **Power Off and Disconnect Battery:** Completely power off your VANKYO MatrixPad S20 tablet. Use a pry tool to carefully open the tablet casing. Locate and disconnect the battery connector from the motherboard. This is a critical safety step.
2. **Remove Damaged Screen:**
 - Apply gentle heat (e.g., from a heat gun or hairdryer on a low setting) to the edges of the damaged screen. This softens the adhesive. Move the heat source continuously to avoid overheating any single area.
 - Carefully insert a thin pry tool or plastic card between the screen and the tablet frame. Work slowly around the

perimeter, gradually separating the old screen. Be extremely cautious if the screen is shattered to avoid injury from glass shards.

- Once the screen is mostly detached, carefully disconnect the flex cable(s) from the motherboard.

3. **Clean the Frame:** Thoroughly clean the tablet's frame, removing all old adhesive residue and any glass fragments. Use isopropyl alcohol and a lint-free cloth for best results. A clean surface is essential for proper adhesion of the new screen.
4. **Pre-Test New Screen (Reiterate):** Before applying adhesive, connect the new screen's flex cable to the motherboard. Reconnect the battery and power on the tablet to verify full functionality (touch response, display quality). If any issues are present, contact support before proceeding.
5. **Apply Adhesive:** Once the new screen is confirmed working, disconnect the battery again. Carefully remove the protective films from the new screen and apply the provided adhesive tape around the edges of the tablet frame. Ensure the adhesive is evenly distributed.
6. **Install New Screen:** Carefully align the new screen with the tablet frame. Ensure the flex cable is properly routed and connected to the motherboard. Gently press the screen into place, starting from one edge and working your way around, ensuring a secure fit.
7. **Reassembly:** Reconnect the battery. Close the tablet casing, ensuring all clips or screws are secured.
8. **Final Test:** Power on the tablet and perform a final test of the touch screen and display.



Flex cable of Touchscreen

Image: Detailed view of the digitizer's flex cable, which connects to the tablet's motherboard.

OPERATING THE NEW SCREEN

Once successfully installed, your new A-MIND touch screen digitizer will function identically to the original screen. It is designed to provide responsive touch input and clear display output for your VANKYO MatrixPad S20 tablet.

- **Touch Responsiveness:** The screen is engineered for accurate and smooth touch recognition.
- **Display Quality:** Expect clear visuals without dead pixels or color distortion.
- **Protective Features:** The screen features scratch-proof and high-definition properties for durability and clarity.



SCRATCH-PROOF

Fire-proof, durable
Scratch-proof



HD

High Definition makes it
clearly as the new



SCRATCH-PROOF

Fingerprint no where
to hide

Image: Icons illustrating the scratch-proof, high-definition, and fingerprint-resistant qualities of the replacement screen.

MAINTENANCE

To ensure the longevity and optimal performance of your new screen:

- **Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a screen-specific cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Protection:** Consider using a screen protector or a tablet case to guard against scratches and impacts.
- **Avoid Pressure:** Do not apply excessive pressure to the screen, as this can cause damage to the digitizer or LCD underneath.

TROUBLESHOOTING

If you encounter issues after installation, consider the following:

- **No Display or Partial Display:**
 - Ensure the flex cable is securely and correctly connected to the motherboard.

- Check for any bends or damage to the flex cable.
- Verify the battery is properly connected and charged.

- **Touch Not Responding or Inaccurate:**

- Ensure the flex cable is fully seated and locked in its connector.
- Check for any debris or foreign objects between the screen and the frame.
- Perform a tablet restart.
- If the issue persists, the screen may be faulty or damaged during installation. Re-test the screen before final adhesive application if possible.

- **Screen Lifting or Poor Adhesion:**

- Ensure the tablet frame was thoroughly cleaned of old adhesive before applying new tape.
- Apply even pressure around the edges after installation to ensure proper bonding.

If troubleshooting steps do not resolve the issue, please contact customer support.

SPECIFICATIONS

Model Number	VANKYO MatrixPad S20 (Replacement Part)
Screen Size	10.1 inch
Type	Touch Screen Panel Digitizer Glass
Color	Black
Manufacturer	A-MIND
Package Dimensions	10.87 x 8.58 x 1.3 inches
Item Weight	8.4 ounces

WARRANTY INFORMATION

A-MIND provides a **6-month warranty** for this screen replacement. This warranty covers manufacturing defects and functional issues under normal use. It does not cover damage caused by:

- Man-made damage (e.g., drops, impacts, improper handling).
- Physical damage (e.g., cracks, scratches, liquid exposure).
- Damage incurred during installation by the user.
- Damage resulting from the application of adhesive before proper testing.

If the screen fails to work normally within the warranty period and without man-made or physical damage, we will exchange it for a new one.

CUSTOMER SUPPORT

Should you encounter any problems with your order or require assistance with installation or troubleshooting, please do not hesitate to contact our customer service team. We are committed to providing support and will respond to your inquiries within 24 hours via Amazon message.

For further assistance, please refer to the contact information provided with your purchase or through the Amazon platform.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question