



Manuals.plus /

- › Continental Edison /
- › CONTINENTAL EDISON FRSH1350B Air Fryer Instruction Manual

Continental Edison FRSH1350B

CONTINENTAL EDISON FRSH1350B Air Fryer Instruction Manual

Model: FRSH1350B

INTRODUCTION

Thank you for choosing the CONTINENTAL EDISON FRSH1350B Air Fryer. This appliance uses rapid hot air circulation to cook your favorite foods with little to no oil, offering a healthier alternative to traditional frying. Please read this manual thoroughly before first use to ensure safe and optimal operation.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- Ensure the basket is properly inserted before operating.
- A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.

PRODUCT OVERVIEW

Familiarize yourself with the components of your CONTINENTAL EDISON FRSH1350B Air Fryer.



Image: Front view of the Continental Edison FRSH1350B Air Fryer. This image displays the sleek black exterior, the digital display panel with temperature and time controls, and the ergonomic handle of the removable basket. The top features ventilation grilles.

1. **Control Panel:** Digital display for temperature and time settings, with touch controls.
2. **Air Inlet:** Located at the top of the unit.
3. **Air Outlet Vents:** Located at the rear of the unit.

4. **Frying Basket:** Removable non-stick basket for holding food.
5. **Basket Handle:** For safe removal and insertion of the frying basket.
6. **Main Unit:** The primary housing of the air fryer.



Image: Close-up of the removable frying basket. This image highlights the non-stick interior and the sturdy handle, demonstrating how the basket detaches from the main unit for easy loading and cleaning.

BEFORE FIRST USE

1. **Unpacking:** Remove all packaging materials, stickers, and labels from the appliance.
2. **Cleaning:** Wipe the exterior of the appliance with a damp cloth. Clean the frying basket and pan thoroughly with hot water, dish soap, and a non-abrasive sponge. Rinse and dry completely.
3. **Placement:** Place the air fryer on a stable, horizontal, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of free space at the back and sides of the appliance, and 10 cm (4 inches) above it, to allow for proper air circulation.
4. **Initial Run (Optional):** Some users prefer to run the air fryer empty for about 10-15 minutes at 200°C (390°F) to eliminate any manufacturing odors. Ensure good ventilation during this process.

OPERATING INSTRUCTIONS

Follow these steps to operate your air fryer:

1. **Prepare Food:** Prepare your ingredients as desired. For best results, lightly coat foods like fresh potatoes with a small amount of oil.
2. **Place Food in Basket:** Pull the basket out of the air fryer. Place the food into the frying basket. Do not overfill the basket; ensure there is enough space for hot air to circulate.

3. **Insert Basket:** Slide the frying basket back into the air fryer until it clicks into place.
4. **Plug In:** Plug the main power cord into a grounded wall outlet. The display will light up.
5. **Set Temperature and Time:** Use the temperature and time control buttons on the digital panel to set your desired cooking temperature and time. Refer to a recipe or cooking guide for recommended settings.
6. **Start Cooking:** Press the Start/Stop button to begin the cooking process. The air fryer will start heating and the fan will operate.
7. **Shake Basket (Optional):** For even cooking, especially with smaller items like fries, pull out the basket halfway through the cooking time and shake it gently. Then slide it back in. The air fryer will resume cooking automatically.
8. **Check Doneness:** When the cooking time is complete, the air fryer will beep. Carefully pull out the basket and check if the food is cooked to your preference. If not, slide the basket back in and set additional time.
9. **Serve:** Carefully remove the cooked food from the basket using tongs. Place it on a plate. Be cautious of hot oil or juices that may have collected in the bottom of the pan.
10. **Unplug:** After use, unplug the appliance from the wall outlet.



Image: The Continental Edison FRS11350B Air Fryer in use, surrounded by plates of freshly cooked fried chicken, french fries, and small

pastries. This demonstrates the versatility of the appliance in preparing a variety of meals.

MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool down completely before cleaning.
2. **Clean Basket and Pan:** Remove the frying basket and pan. Wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn food residues, soak them in hot water with dish soap for about 10 minutes. They are generally dishwasher safe, but hand washing is recommended to preserve the non-stick coating.
3. **Clean Interior:** Wipe the interior of the appliance with a damp cloth. Do not use abrasive cleaners or steel wool.
4. **Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth.
5. **Heating Element:** If necessary, clean the heating element with a cleaning brush to remove any food residues.
6. **Storage:** Ensure all parts are completely dry before storing the appliance. Store it in a cool, dry place.



Image: The Continental Edison FRS1350B Air Fryer with its frying basket removed, revealing the interior heating chamber. This view is useful for understanding how to clean the inside of the appliance.

TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in. Basket not inserted correctly.	Ensure the power cord is securely plugged into a grounded outlet. Push the frying basket firmly into the appliance until it clicks.
Food is not cooked evenly.	Too much food in the basket. Food not shaken or turned.	Reduce the amount of food in the basket. Cook in smaller batches. Shake or turn food halfway through cooking time.
White smoke comes from the appliance.	Grease residue from previous use. Fatty ingredients being cooked.	Clean the basket and pan thoroughly after each use. Remove excess oil from food before air frying.
Fresh fries are not crispy.	Not enough oil used. Too much moisture.	Lightly coat fresh potatoes with 1/2 tablespoon of oil. Pat potatoes dry before adding oil.

SPECIFICATIONS

- **Model:** FRS1350B
- **Brand:** Continental Edison
- **Power:** 1350 Watts
- **Capacity:** 3.5 Liters
- **Material:** Stainless Steel, Plastic (exterior), Non-stick coating (basket)
- **Color:** Black, Silver
- **ASIN:** B0937DFYBT

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Continental Edison website. Do not attempt to repair the appliance yourself, as this will void the warranty.

For further assistance, please contact Continental Edison customer service.