

## JOYOUNG JY-570

# Joyoung JY-570 5.8 Quart Air Fryer Instruction Manual

Model: JY-570

### 1. PRODUCT OVERVIEW

The Joyoung JY-570 5.8 Quart Air Fryer is a versatile kitchen appliance designed for healthier cooking. It utilizes 360° airflow technology to cook food with significantly less oil, achieving a crispy texture. The appliance features a user-friendly LED touchscreen with 8 built-in smart programs for various cooking needs.



Image 1.1: The Joyoung JY-570 5.8 Quart Air Fryer, showcasing its stainless steel design, LED touchscreen, and a basket filled with crispy fries. Included accessories like a grill rack and supporting plate are also visible.

### Key Features:

- **Capacity:** 5.8 Quarts
- **Material:** Stainless Steel
- **Control:** LED Touchscreen
- **Preset Programs:** 8 (French Fries, Drumstick, Shrimp, Cake, Beef Steak, Fish, Rib, Keep Warm)
- **Temperature Range:** 180-400°F (adjustable every 5°F)
- **Timer:** 1-60 minutes (adjustable every 1 minute)
- **Technology:** 360° Airflow for rapid preheating and even cooking
- **Safety:** Automatic shut-off when basket is removed
- **Cleaning:** Fingerprint-resistant exterior, dishwasher-safe accessories

## 2. SETUP AND FIRST USE

---

### 2.1 Unboxing and Inspection

- Carefully remove the air fryer and all accessories from the packaging.
- Remove all plastic wrapping materials from the appliance and its internal cavity to prevent burning risk during

operation.

- Check that the crumb tray is properly in place and that no foreign objects are left inside the oven.
- Inspect the appliance for any signs of damage. Do not use if damaged.

Your browser does not support the video tag.

Video 2.1: An official Joyoung video demonstrating the unboxing process, removal of packaging materials, and checking internal components of the air fryer. This video also covers initial setup steps.

## 2.2 Initial Cleaning

- Wipe the exterior of the air fryer with a clean, damp cloth.
- Wash the removable basket, grill set, and supporting plate with warm, soapy water. Rinse thoroughly and dry completely.

## 2.3 First Use (Odor Removal)

Before cooking food for the first time, it is recommended to run the air fryer empty to eliminate any manufacturing odors:

1. Place the empty basket and supporting plate back into the air fryer.
2. Plug the appliance into a grounded electrical outlet.
3. Set the temperature to 400°F (200°C) and the timer to 15 minutes.
4. Allow the air fryer to run through the cycle. A slight odor may be present, which is normal.
5. Once complete, unplug the air fryer and let it cool down completely before wiping the interior with a damp cloth.

## 3. OPERATING INSTRUCTIONS

---

### 3.1 Power On/Off

- Plug the air fryer into a power outlet. The power button will illuminate.
- Press the power button to turn the appliance on. The LED touchscreen will display the default settings.
- Press and hold the power button to turn the appliance off.

### 3.2 Using Preset Programs

The Joyoung JY-570 comes with 8 convenient preset programs for common dishes:



# One Touch Operation With 8 Presets



Image 3.1: The LED touchscreen of the Joyoung JY-570 air fryer, showing the icons for its 8 preset cooking programs, including French fries, drumstick, shrimp, cake, beef steak, fish, rib, and keep warm.

1. Place your food in the air fryer basket.
2. Press the desired preset icon on the touchscreen. The air fryer will automatically set the optimal temperature and time for that food type.
3. Press the Start/Pause button to begin cooking.

### 3.3 Manual Temperature and Time Adjustment

For custom cooking, you can manually adjust the temperature and time:



## Wide Temperature Range and Precise Control



Image 3.2: The air fryer's control panel highlighting the wide temperature range from 180°F to 400°F and a timer from 1 to 60 minutes, demonstrating precise control over cooking settings.

1. Press the Temperature/Time button.
2. Use the '+' and '-' buttons to adjust the temperature (180-400°F, in 5°F increments).
3. Use the '+' and '-' buttons to adjust the cooking time (1-60 minutes, in 1-minute increments).
4. Press the Start/Pause button to begin cooking.

### 3.4 Preheating Function

Preheating helps achieve optimal cooking results, especially for crispy foods.

- Press the preheat icon on the touchscreen. The air fryer will heat up to a default temperature (e.g., 370°F) for a set time (e.g., 3 minutes).
- Once preheating is complete, the air fryer will beep, indicating it's ready for food.

### 3.5 Auto Shut-Off and Add Food Feature

- The air fryer automatically pauses operation when the basket is pulled out.
- This allows you to check, shake, or add ingredients to your food.



- Once the basket is reinserted, the air fryer will resume cooking from where it left off.



## Auto Shut Off & Add Food

When the basket is pulled out, air fryer will power off automatically and when put in the basket, the air fryer will work again.



Image 3.3: A hand demonstrating the auto shut-off feature by pulling out the air fryer basket, which automatically pauses the cooking cycle.

### 3.6 Memory Function

The air fryer features a two-hour memory function. In case of a power interruption, the appliance will resume cooking from the point it stopped if power is restored within two hours.

Your browser does not support the video tag.

Video 3.4: An overview of the Joyoung JY-570 Multi-tasker Air Fryer, demonstrating its various features including the touchscreen controls, cooking different foods, and the auto-pause function when the basket is removed.

## 4. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

### 4.1 Cleaning the Exterior

- Unplug the air fryer and allow it to cool completely before cleaning.
- Wipe the exterior with a clean, damp cloth. The stainless steel material is fingerprint-resistant for easy

maintenance.

- Do not immerse the main unit in water or any other liquid.



Image 4.1: A close-up of the air fryer's fingerprint-resistant stainless steel surface, indicating ease of cleaning.

## 4.2 Cleaning the Interior and Accessories

- The removable basket, grill set, and supporting plate are dishwasher safe.
- Alternatively, wash them with warm, soapy water using a non-abrasive sponge.
- For stubborn food residue, soak the basket and accessories in warm, soapy water for about 10 minutes before cleaning.
- Ensure all parts are thoroughly dry before reassembling or storing.



## Easy to Clean

All accessories are dishwasher safe



Image 4.2: Demonstration of cleaning the air fryer basket by rinsing it under a faucet and placing it in a dishwasher, highlighting its easy-to-clean and dishwasher-safe features.

## 5. TROUBLESHOOTING

If you encounter any issues with your Joyoung JY-570 Air Fryer, please refer to the following common troubleshooting steps:

- **Appliance not turning on:** Ensure the power cord is securely plugged into a grounded electrical outlet. Check if the outlet is functioning by plugging in another appliance.
- **Food not cooking evenly:** Ensure the basket is not overloaded. Shake the basket halfway through the cooking time for even browning.
- **White smoke coming from the air fryer:** This may be caused by grease from previous use. Clean the basket and heating element thoroughly. If cooking fatty foods, place a small amount of water in the bottom of the drawer to prevent smoke.
- **Food not crispy:** Ensure the temperature is set correctly and the food is not overcrowded. A light coating of oil can also help achieve crispiness.
- **Unusual noise during operation:** Check that the basket is properly inserted and secured. Ensure no foreign objects are inside the cooking cavity.



For further assistance, please contact Joyoung customer support.

## 6. SPECIFICATIONS


Feature	Specification
Brand	JOYOUNG
Model Number	JY-570
Capacity	5.8 Quarts
Product Dimensions	11"D x 11"W x 13"H
Item Weight	10.36 Pounds
Material	Stainless Steel
Output Wattage	1400 Watts
Voltage	120 Volts
Control Method	Touch
Temperature Range	180-400°F
Timer Range	1-60 Minutes
Nonstick Coating	Yes
Dishwasher Safe Accessories	Yes






## 7. WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please refer to the official Joyoung website or contact their customer service department. Keep your purchase receipt as proof of purchase for any warranty claims.

**Contact Information:** Please refer to the contact details provided in your product packaging or on the official Joyoung website.

### Related Documents - JY-570

	<p><a href="#">Joyoung DJ13E-ME Full-automatic Domestic Soy Milk Machine Operation Manual</a></p> <p>Comprehensive operation manual for the Joyoung DJ13E-ME Full-automatic Domestic Soy Milk Machine, covering safety precautions, parts identification, usage instructions, maintenance, and troubleshooting.</p>
---	---

	<p><a href="#">K08-WY601U</a></p> <p>K08-WY601U</p>
	<p><a href="#">DJ13U-G91</a></p> <p>DJ13U-G91</p>
	<p><a href="#">Joyoung DJ13B-D08D/DJ13B-D08EC</a></p> <p>Joyoung DJ13B-D08D DJ13B-D08EC</p>
	<p><a href="#">Joyoung DJ13B-D08D Soymilk Maker Operation Instruction Manual</a></p> <p>This manual provides detailed instructions for operating the Joyoung DJ13B-D08D automatic soymilk maker. It covers safety precautions, parts identification, usage methods for various functions like making soymilk, juice, and rice paste, maintenance, troubleshooting, and recipes.</p>
	<p><a href="#">Y1/Y966</a></p> <p>Y1/Y966</p>