

[Manuals.plus](#) /

› [Melchioni](#) /

› Melchioni Family ISABEL Air Fryer Instruction Manual

Melchioni AIR_FRYER

Melchioni Family ISABEL Air Fryer Instruction Manual

Model: AIR_FRYER

1. INTRODUCTION

The Melchioni Family ISABEL Air Fryer offers a healthy and effortless cooking experience. Prepare delicious and healthy meals with up to 85% fewer calories and minimal to no oil. Its gentle, all-around heating preserves vitamins and nutrients, ensuring flavorful results.

This manual provides essential information for the safe and efficient operation of your new air fryer. Please read it thoroughly before first use and keep it for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

3. PRODUCT OVERVIEW

The Melchioni Family ISABEL Air Fryer features a sleek design with intuitive controls and a large capacity for family-sized meals.

Components:

- **Main Unit:** Houses the heating element and control panel.
- **Non-stick Cooking Basket:** Large 9-liter capacity, designed for easy food placement and removal.
- **Handle:** Practical handle for safe removal of the cooking basket.
- **Touch Screen Display:** Clear and simple interface for setting temperature, time, and selecting pre-set programs.
- **Transparent Window:** Allows you to monitor cooking progress without opening the basket.



Figure 3.1: Touch Screen Display and Control Panel. The display shows temperature and time settings, along with icons for various pre-set cooking programs.



Figure 3.2: Melchioni Family ISABEL Air Fryer with dimensions. The appliance measures approximately 35cm (width) x 37cm (depth) x 41cm (height).

4. SETUP AND FIRST USE

Unpacking:

1. Carefully remove the air fryer and all packaging materials.
2. Remove any stickers or labels from the appliance.
3. Check that all parts are present and undamaged.

Cleaning Before First Use:

1. Wipe the main unit with a damp cloth.
2. Wash the cooking basket and any removable accessories with hot water, dish soap, and a non-abrasive sponge.

Rinse thoroughly and dry completely.

3. Do not immerse the main unit in water or any other liquid.

Placement:

- Place the air fryer on a stable, heat-resistant surface.
- Ensure there is adequate space (at least 10 cm) around the appliance for proper ventilation.
- Do not place the appliance against a wall or other appliances.

5. OPERATING INSTRUCTIONS

The ISABEL Air Fryer features a user-friendly touch screen display for easy operation.

Basic Operation:

1. **Power On:** Plug the appliance into a grounded electrical outlet. The power button will illuminate. Press the power button to turn on the display.
2. **Prepare Food:** Place your ingredients into the non-stick cooking basket. Do not overfill.
3. **Insert Basket:** Slide the cooking basket firmly back into the main unit.
4. **Set Temperature and Time:**
 - Use the temperature controls (up/down arrows) to set the desired cooking temperature (50-200°C).
 - Use the timer controls (up/down arrows) to set the desired cooking time (1-60 minutes).
5. **Start Cooking:** Press the start/pause button to begin the cooking cycle.
6. **Monitoring:** The transparent window allows you to check food progress. For even cooking, you may pause the cycle and shake the basket halfway through.
7. **Automatic Shut-off:** The air fryer will automatically stop when the set time is complete or when the basket is removed.
8. **Food Removal:** Carefully pull out the basket using the handle. Place it on a heat-resistant surface. Remove food using non-metal utensils.



Figure 5.1: The Melchioni Family ISABEL Air Fryer in operation, showing the digital display with temperature and time settings. The basket is inserted, and cooking is in progress.

Pre-set Cooking Programs:

The air fryer comes with 10 pre-set programs for common dishes, making cooking even simpler. Select the desired program by pressing the corresponding icon on the touch screen.

- Pre-heating
- French Fries
- Chicken
- Shrimp
- Meat
- Steaks
- Fish
- Cakes

- Vegetables
- Chicken Thighs

These programs automatically set optimal temperature and time, which can be adjusted manually if needed.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and optimal performance of your air fryer.

Cleaning the Cooking Basket:

- Always unplug the appliance and allow it to cool completely before cleaning.
- The non-stick coating of the basket allows for quick and easy cleaning. Food and oil residues do not stick to the surface.
- Wash the basket with hot water, dish soap, and a non-abrasive sponge.
- For stubborn residues, soak the basket in warm soapy water for about 10 minutes before cleaning.
- Rinse thoroughly and dry completely before storing or next use.

Cleaning the Main Unit:

- Wipe the exterior of the air fryer with a damp cloth.
- Never immerse the main unit in water or any other liquid.
- Clean the interior with a damp cloth and mild detergent if necessary. Ensure it is dry before use.

7. TROUBLESHOOTING

If you encounter any issues with your air fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet malfunction; power button not pressed.	Ensure the appliance is properly plugged in. Check the power outlet. Press the power button on the display.
Food is not cooked evenly.	Basket is overfilled; food not shaken or turned.	Do not overfill the basket. Shake or turn food halfway through cooking for best results.
White smoke coming from the appliance.	Greasy residues from previous use; excessive oil on food.	Clean the basket and interior thoroughly. Reduce the amount of oil used on food.
Food is not crispy.	Too much moisture in food; insufficient cooking time/temperature.	Pat food dry before cooking. Increase cooking time or temperature slightly.

8. TECHNICAL SPECIFICATIONS

- **Brand:** Melchioni
- **Model:** AIR_FRYER
- **Color:** Black
- **Product Dimensions:** 33 x 36 x 40 cm (approx. 35P x 37l x 41H cm)

- **Capacity:** 9 Liters
- **Wattage:** 1600-1800 W
- **Voltage:** 240 Volt
- **Material:** Stainless steel, Plastic
- **Temperature Range:** 50-200°C
- **Timer:** 1-60 minutes
- **Special Features:** Timer, Touchscreen
- **Item Weight:** 5 Kilograms

9. WARRANTY AND SUPPORT

This Melchioni Family appliance is covered by a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for detailed terms and conditions.

For technical support, service, or spare parts, please contact Melchioni customer service. You can find contact information on the official Melchioni website or on your product's packaging.

Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0954WZ5PJ>

More documents and user manuals: <https://manuals.plus/>