

[manuals.plus](#) /

- › [Rongta](#) /
- › [Rongta RP410 Thermal Label Printer User Manual](#)

Rongta RP410

Rongta RP410 Thermal Label Printer User Manual

Model: RP410 | Brand: Rongta

1. INTRODUCTION

The Rongta RP410 is a high-speed thermal label printer designed for efficient printing of shipping labels, barcode labels, and other thermal media. It supports both USB and Bluetooth connectivity, making it versatile for various operating environments including Windows and macOS systems. This manual provides comprehensive instructions for setting up, operating, and maintaining your RP410 printer.



Figure 1: Rongta RP410 Thermal Label Printer in operation, showing a printed shipping label.

2. PRODUCT FEATURES

- High-Speed Thermal Printing:** Utilizes direct thermal technology, eliminating the need for ink or toner.
- Dual Connectivity:** Supports both USB and Bluetooth connections for flexible setup.
- Wide System Compatibility:** Compatible with Windows, macOS, and Linux operating systems.
- Versatile Application:** Ideal for printing shipping labels (e.g., 4x6 inches), barcode labels, and other thermal media.
- Broad Platform Support:** Works seamlessly with popular shipping and selling platforms such as Amazon, eBay, Etsy, Shopify, FedEx, UPS, USPS, and more.
- Compact and Portable Design:** Suitable for home office and warehouse environments.

USB+Bluetooth



Figure 2: The RP410 printer demonstrating its USB and Bluetooth connectivity options with a laptop.

Support Multiple Systems/compatible with Windows/MacOS/Linux



Figure 3: The RP410 printer highlighting its compatibility with multiple operating systems including Windows, macOS, and Linux.



Figure 4: The RP410 printer shown in a setting compatible with numerous popular shipping and selling platforms.

3. PACKAGE CONTENTS

Please check the package contents upon unboxing to ensure all items are present:

- Rongta RP410 Thermal Label Printer
- Power Adapter and Cable
- USB Cable
- Quick Start Guide
- Label Roll Holder (if not pre-installed)

4. SETUP GUIDE

4.1 Connecting the Printer

1. Connect the power adapter to the printer's power port and plug it into a wall outlet.
2. Connect the USB cable from the printer to your computer's USB port.
3. Turn on the printer using the power switch located at the back. The indicator light on top should illuminate.

4.2 Loading Labels

1. Open the top cover of the printer by pressing the release buttons on the sides.
2. Place the label roll onto the label roll holder. Ensure the labels feed from the bottom of the roll.
3. Adjust the movable guides to fit the width of your labels snugly, without being too tight.
4. Feed the leading edge of the labels through the printer mechanism until it extends slightly past the print head.
5. Close the top cover firmly until it clicks into place.



Figure 5: Detailed view of the RP410 printer's interior, illustrating the correct method for loading thermal labels.

4.3 Driver Installation (Windows & macOS)

Drivers are essential for your computer to communicate with the printer. Please visit the official Rongta website to download the latest drivers for your operating system (Windows or macOS). Follow the on-screen instructions for installation.

- For Windows: Run the installer and follow the prompts. Select the correct printer model (RP410) and connection type (USB or Bluetooth).
- For macOS: Download the macOS driver package. Open the package and follow the installation steps. You may need to add the printer in System Preferences > Printers & Scanners.

4.4 Bluetooth Pairing

To use the Bluetooth feature:

1. Ensure the printer is powered on and within range of your device.
2. On your computer or mobile device, go to Bluetooth settings.
3. Search for available devices and select "Rongta RP410" (or similar name).
4. Follow any on-screen prompts to complete the pairing process. A passkey might be required (refer to your printer's quick start guide for default passkey, usually "0000" or "1234").

5. OPERATING INSTRUCTIONS

5.1 Printing a Test Page

After driver installation, it is recommended to print a test page to confirm proper setup:

- For Windows: Go to Control Panel > Devices and Printers. Right-click on "Rongta RP410" and select "Printer properties" > "Print Test Page".
- For macOS: Go to System Preferences > Printers & Scanners. Select "Rongta RP410" and click "Open Print Queue". From the menu bar, select "Printer" > "Print Test Page".

Your browser does not support the video tag.

Video 1: Demonstration of the Rongta Shipping Label Printer's paper capacity and printing process.

5.2 Adjusting Print Settings

To optimize print quality and label alignment, you may need to adjust settings in your printer preferences or the application you are printing from:

- **Label Size:** Ensure the label size in your software matches the physical labels loaded (e.g., 4x6 inches).
- **Print Density:** Adjust print density for darker or lighter prints. Higher density consumes more thermal energy.
- **Print Speed:** While the RP410 is high-speed, you can sometimes adjust speed for specific label types or quality needs.

5.3 Supported Label Sizes

The Rongta RP410 is optimized for standard shipping label sizes, commonly 4 inches by 6 inches. It supports various direct thermal labels.

6. MAINTENANCE

6.1 Cleaning the Print Head

Regular cleaning of the print head ensures optimal print quality and extends the printer's lifespan. It is suggested to clear the print head and rubber roller weekly.

- Turn off the printer and unplug the power cable.
- Open the top cover.
- Use an alcohol swab or a lint-free cloth lightly dampened with isopropyl alcohol to gently wipe the print head (the dark strip) and the rubber roller.
- Allow it to dry completely before closing the cover and powering on the printer.

6.2 General Care

- Keep the printer in a clean, dust-free environment.
- Avoid exposing the printer to direct sunlight or extreme temperatures.
- Do not use abrasive cleaners or solvents on the printer's exterior.

7. TROUBLESHOOTING

If you encounter issues with your Rongta RP410 printer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Printer not responding / Not printing	Power issue, loose cable, incorrect driver, printer offline.	Ensure power cable is securely connected and printer is on. Check USB/Bluetooth connection. Reinstall or update printer drivers from the official Rongta website. Check printer status in your computer's printer settings; ensure it's not paused or offline.
Blank labels / Faint print	Labels loaded incorrectly, print head dirty, low print density.	Ensure labels are thermal-sensitive and loaded correctly (print side up). Clean the print head as described in the Maintenance section. Increase print density in printer settings.
Labels skipping or feeding incorrectly	Label guides not adjusted, labels jammed, sensor issue.	Adjust label guides to fit the label roll snugly. Clear any jammed labels. Perform a label calibration (refer to quick start guide for specific steps).

Problem	Possible Cause	Solution
Bluetooth connection issues	Printer not in pairing mode, device not discoverable, interference.	Ensure printer is powered on and Bluetooth is enabled. Restart both the printer and your device. Try re-pairing the devices. Ensure no other devices are interfering with the Bluetooth signal.

8. SPECIFICATIONS

Feature	Detail
Model Number	RP410
Printing Technology	Thermal
Resolution	203 x 203 DPI
Hardware Interface	Bluetooth, USB
Control Method	App (iOS), Computer
Print Media	Labels
Max Copy Speed (Black & White)	8E+1 ppm
Sheet Size	4 inch x 6 Inches (Common shipping label size)
Product Dimensions	8.54 x 7.17 x 6.77 inches
Item Weight	5.19 pounds
UPC	610840367234, 610840367166

9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the contact details provided in your product packaging or visit the official Rongta website. Keep your purchase receipt as proof of purchase for warranty claims.

© 2024 Rongta. All rights reserved.