

## BEPER P102ROB050

# BEPER P102ROB050 USB Rechargeable Mini Food Chopper User Manual

Model: P102ROB050

## 1. PRODUCT OVERVIEW

The BEPER P102ROB050 is a compact and portable mini food chopper designed for quick and efficient preparation of various ingredients. Its wireless design, powered by a rechargeable USB battery, offers convenience and versatility in any kitchen setting.

### Key Features:

- **Compact and Practical:** Small footprint for easy storage and use.
- **USB Rechargeable:** Equipped with a 1500mAh lithium battery, rechargeable via USB cable in approximately 5 hours, providing up to 20 chopping cycles per charge.
- **Quality Materials:** Features durable stainless steel blades and non-toxic ABS and PP container materials, ensuring safe food contact.
- **Easy Operation:** Simple one-button control for quick on/off functionality.
- **Portable Design:** Ideal for home use, camping, or travel due to its lightweight and cordless nature.

### Components:

- Motor Unit (top part with power button)
- Lid
- 3-Blade Assembly (stainless steel)
- 250ml Transparent Container
- USB Charging Cable



The BEPER P102ROB050 Mini Food Chopper, ready to process a variety of ingredients.

 <p><b>LITIO LITHIUM</b></p>	 <p><b>RICARICABILE RECHARGEABLE</b></p>	
 <p><b>250 ml</b></p> <p><b>CAPACITÀ CAPACITY</b></p>	 <p><b>PULSE</b></p>	
 <p><b>3 LAME 3 BLADES</b></p>	 <p><b>INCLUSO INCLUDED</b></p>	

Visual representation of the chopper's main specifications and included accessories.

## 2. SAFETY INSTRUCTIONS

Please read all safety instructions carefully before using the appliance to prevent injury or damage.

- Always ensure the appliance is fully assembled and the lid is securely closed before operation.
- The blades are extremely sharp. Handle them with extreme care during assembly, disassembly, and cleaning.
- Do not immerse the motor unit (top part) in water or any other liquid. Clean it only with a damp cloth.
- Keep the appliance out of reach of children.
- Do not overfill the container beyond its 250ml capacity.
- Avoid processing extremely hard ingredients such as whole coffee beans, ice cubes, or very hard nuts, as this may damage the blades or motor.
- Do not operate the appliance continuously for extended periods. Use short pulses to prevent overheating.
- Ensure the USB charging port is dry before connecting the charging cable.
- Do not attempt to repair or modify the appliance yourself. Contact qualified service personnel for any repairs.

## 3. SETUP AND INITIAL USE

### Unpacking:

1. Carefully remove all components from the packaging.
2. Check for any damage during transit. Do not use if damaged.
3. Recycle packaging materials responsibly.

### Initial Charging:

Before first use, fully charge the appliance.

1. Connect the provided USB charging cable to the charging port on the motor unit.
2. Plug the other end of the USB cable into a suitable USB power source (e.g., computer USB port, USB wall adapter).
3. The indicator light will illuminate during charging. A full charge takes approximately 5 hours.
4. Once fully charged, disconnect the USB cable.

### Assembly:

1. Place the 3-blade assembly onto the central pin inside the transparent container. Ensure it sits securely.
2. Add your desired ingredients into the container. Do not exceed the MAX fill line (250ml).
3. Place the lid onto the container, aligning it properly.
4. Position the motor unit on top of the lid, ensuring it locks into place. The appliance has a safety lock mechanism; it will not operate unless correctly assembled.



All components of the BEPER Mini Food Chopper, including the USB charging cable.

## 4. OPERATING INSTRUCTIONS

The BEPER P102ROB050 is designed for simple, one-touch operation.

### Chopping Ingredients:

1. Ensure the chopper is assembled correctly with ingredients inside.
2. Press and hold the power button located on top of the motor unit. The blades will begin to rotate and chop the ingredients.
3. Release the button to stop the chopping action.
4. For best results and to achieve desired consistency, use short pulses rather than continuous operation. This allows ingredients to settle and ensures even chopping.
5. Once chopping is complete, carefully remove the motor unit, then the lid, and finally the blade assembly before emptying the container.

### Recommended Ingredients:

- Garlic, onions, shallots
- Herbs (parsley, cilantro, chives)



- Soft vegetables (bell peppers, carrots, zucchini - cut into smaller pieces)
- Cooked meats (cut into small cubes)
- Small amounts of soft cheese

### **Tips for Optimal Performance:**

- Cut larger ingredients into smaller, manageable pieces (approx. 1-2 cm) before placing them in the chopper.
- Do not overload the container. Overfilling can strain the motor and result in uneven chopping.
- For very fine chopping, use multiple short pulses.



Operating the chopper with a simple press of the button.



Examples of ingredients that can be processed, including cheese, almonds, and pumpkin for purees.  
For a visual demonstration of the product in use, you may refer to this official video: [BEPER Mini Food Chopper Demonstration](#)

## 5. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your BEPER Mini Food Chopper.

### Cleaning Procedure:

1. Always unplug the USB cable and ensure the appliance is turned off before cleaning.
2. Disassemble the chopper: remove the motor unit, then the lid, and carefully lift out the blade assembly.
3. **Container and Blades:** Wash the transparent container and the blade assembly with warm, soapy water. Rinse thoroughly and dry immediately. *Caution: The blades are very sharp. Handle with extreme care. Do not place the container or blades in a dishwasher, as high temperatures can cause material degradation or cracking.*
4. **Motor Unit:** Wipe the motor unit with a soft, damp cloth. Do not immerse it in water or rinse it under running water. Ensure it is completely dry before storing or recharging.
5. Ensure all parts are completely dry before reassembling or storing the appliance.

### Storage:

Store the assembled chopper in a clean, dry place, away from direct sunlight and out of reach of children.

## 6. TROUBLESHOOTING

If you encounter issues with your BEPER Mini Food Chopper, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Battery is low or depleted. Appliance not assembled correctly (safety lock).	Charge the battery fully. Ensure the motor unit is securely placed on the lid and the lid is properly aligned with the container.
Ingredients are not chopped evenly or remain large.	Container is overloaded. Ingredients are too large or too hard. Insufficient chopping time.	Reduce the amount of ingredients. Cut ingredients into smaller pieces. Avoid very hard items. Use short, repeated pulses.
Chopper stops during operation.	Battery is low. Motor overheating (automatic shut-off).	Recharge the battery. Allow the appliance to cool down for a few minutes before resuming operation. Avoid continuous use.
Charging indicator light does not turn on.	USB cable or power source issue. Charging port is dirty or damaged.	Try a different USB cable or power source. Ensure the charging port is clean and free of debris.

If the problem persists after trying these solutions, please contact customer support.

## 7. SPECIFICATIONS

Brand	BEPER
Model Number	P102ROB050
Capacity	250 Milliliters
Power	3.7V
Blades	3, Stainless Steel
Battery	1500mAh Lithium, USB Rechargeable
Charging Time	Approx. 5 hours
Dimensions (L x W x H)	9 x 9 x 12 cm
Item Weight	260 grams



Included in Box	USB Cable
-----------------	-----------



Product dimensions for the BEPER Mini Food Chopper.

## 8. WARRANTY AND SUPPORT

For information regarding the warranty period and terms for your BEPER P102ROB050 Mini Food Chopper, please refer to the documentation provided at the time of purchase or contact your retailer. Should you require technical assistance or have questions not covered in this manual, please contact BEPER customer support. Details can typically be found on the official BEPER website or on your product packaging.

© 2024 BEPER. All rights reserved.

### Related Documents - P102ROB050

	<p><a href="#">Beper P102ROB050 Tritatutto Ricaricabile USB: Manuale d'Uso e Avvertenze</a></p> <p>Manuale d'uso completo per il tritatutto ricaricabile USB Beper (modello P102ROB050). Include istruzioni dettagliate su sicurezza, utilizzo, pulizia, specifiche tecniche e garanzia. Perfetto per sminuzzare rapidamente ingredienti in cucina.</p>
--	---



