

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [WE](#) /

> WE Projection Alarm Clock Radio with Large Mirror Display and USB Charging Port - User Manual

WE WERADREVPROJECT2

WE Projection Alarm Clock Radio with Large Mirror Display and USB Charging Port - User Manual

INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your WE Projection Alarm Clock Radio. Please read this manual thoroughly before use and retain it for future reference.

SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Keep the device away from water and other liquids.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel.
- Use only the provided power adapter.
- Clean the device with a soft, dry cloth.

PACKAGE CONTENTS

- WE Projection Alarm Clock Radio
- Power Adapter
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the main components of your alarm clock radio:



The image shows the WE Projection Alarm Clock Radio from an angled front view. The large mirror-effect LED display shows '22:59' prominently, along with '23°C' and '20%'. Above the clock, a red digital time '22:59' is projected onto a surface, originating from a projector lens on the top right of the clock. A smartphone is connected via a USB cable to the side of the clock, indicating its charging capability.

- **Large LED Display:** 5-inch ultra-clear screen for easy readability.
- **180° Rotatable Projector:** Projects time onto your ceiling or wall.
- **USB Charging Port:** For charging external devices.
- **Control Buttons:** Various buttons for setting time, alarms, radio, and other functions (located on top/back, specific labels may vary).
- **FM Antenna:** Extendable antenna for improved radio reception.

SETUP

1. **Power Connection:** Connect the provided power adapter to the DC input port on the back of the alarm clock and plug it into a standard wall outlet. The display will light up.
2. **FM Antenna:** For optimal radio reception, fully extend the integrated FM antenna.

OPERATING INSTRUCTIONS

1. Time Setting

- Press the **'SET'** button to enter time setting mode.
- Use the **'UP'** and **'DOWN'** buttons to adjust the hours and minutes.
- Press **'SET'** again to confirm the time and exit setting mode.

2. Alarm Setting (Dual Alarms)

- Press the **'ALARM 1'** or **'ALARM 2'** button to select the alarm you wish to set.
- Use the **'UP'** and **'DOWN'** buttons to set the desired alarm time.
- Select from 5 available alarm sounds: Chord music, bird song, waves, beep, or FM radio.
- Adjust the alarm volume to one of the 3 available levels.
- Press the respective **'ALARM'** button again to confirm your settings.

3. Snooze Function

- When the alarm sounds, press the **'SNOOZE'** button to temporarily silence the alarm and get an additional 9 minutes of sleep.

4. FM Radio Operation

- Press the **'RADIO'** button to turn the FM radio on or off.
- Use the **'SCAN'** or **'TUNE'** buttons to manually find radio stations within the 87.5-108.0 MHz frequency range.
- Long press the **'SCAN'** button to automatically scan and save up to 30 preset FM stations.

5. Sleep Timer (for Radio)

- While the FM radio is playing, press the **'SLEEP'** button.
- Adjust the sleep timer duration between 5 and 90 minutes. The radio will automatically turn off after the specified time.

6. Projection Feature

- Press the **'PROJECTION'** button to turn the time projection on or off.
- Rotate the projector lens (-90° to 90°) to adjust the projection angle on your ceiling or wall.
- Long press the **'PROJECTION'** button to rotate the projected display 180° for optimal viewing.
- Adjust the projection brightness using the dedicated button (4 adjustable brightness levels). Optimal projection distance is 0.5-5 meters.

7. Display Dimmer

- Use the dimmer slider or button to adjust the screen brightness from 0% (off) to 100% (brightest). This allows for a brighter display during the day and a softer display at night.

8. USB Charging Port

- Connect your smartphone or other USB-powered device to the USB port on the side of the alarm clock for convenient charging.

MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners, solvents, or chemical

sprays.

- **Storage:** When not in use for extended periods, store the alarm clock in a cool, dry place, away from direct sunlight and moisture.

TROUBLESHOOTING

- **No Power:**
 - Ensure the power adapter is securely connected to both the alarm clock and a functional wall outlet.
- **Poor Radio Reception:**
 - Fully extend the FM antenna.
 - Try repositioning the alarm clock to a different location for better signal reception.
 - Perform an auto-scan for stations again.
- **Projection Unclear or Upside Down:**
 - Adjust the focus of the projector lens.
 - Long press the 'PROJECTION' button to rotate the projected display 180°.
 - Ensure the projection distance is within the optimal range of 0.5-5 meters.
- **Alarm Not Sounding:**
 - Verify that the alarm is enabled and the alarm volume is set to an audible level.
 - Check that the alarm time is correctly set.
- **USB Charging Not Working:**
 - Ensure your device is properly connected to the USB port.
 - Test with a different USB cable to rule out cable issues.

SPECIFICATIONS

Brand	WE
Model Number	WERADREVPROJECT2
Color	Black
Features	Large screen, Radio, Snooze
Item Weight	450 g
Display Type	Digital
Style	Modern
Special Feature	Large screen, Radio, Snooze
Power Source	Electric cable
Shape	Rectangular
Indoor/Outdoor Use	Indoor

Frame Material	Acrylonitrile Butadiene Styrene
Batteries Included	No

WARRANTY AND SUPPORT

WE products are guaranteed for 2 years from the date of purchase. For any inquiries, technical assistance, or warranty claims, please contact our customer service. Our support team aims to respond to all requests within 24 hours, Monday through Friday.