

[Manuals.plus](#) /

› [Super General](#) /

› Super General 7 kg Top Load Washing Machine User Manual

Super General KSGW724

Super General 7 kg Top Load Washing Machine User Manual

Model: KSGW724 | Brand: Super General

INTRODUCTION

This user manual provides essential information for the safe and efficient operation of your Super General 7 kg Top Load Washing Machine, Model KSGW724. Please read this manual thoroughly before using the appliance and keep it for future reference. Proper use and maintenance will ensure optimal performance and extend the lifespan of your washing machine.

SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Ensure the washing machine is properly grounded.
- Do not operate the machine with a damaged power cord or plug.
- Keep children and pets away from the appliance during operation. The child lock function should be activated when children are present.
- Do not wash items that are soiled with flammable liquids.
- Unplug the appliance before cleaning or performing any maintenance.
- Do not attempt to repair or replace any part of the washing machine unless specifically recommended in this manual.

PRODUCT OVERVIEW

The Super General KSGW724 is a 7 kg top load washing machine designed for efficient and convenient laundry care. It features 8 washing programs, a durable plastic lid, a drain pump, and a child safety lock function.



Figure 1: Overall view of the Super General 7 kg Top Load Washing Machine.



Figure 2: Front view of the washing machine, highlighting its sleek design and control panel placement.

Key Features:

- **7 kg Capacity:** Ideal for medium-sized households.
- **8 Washing Programs:** Versatile options for different fabric types and soil levels.
- **Drain Pump:** Ensures efficient water drainage.
- **Child Lock Function:** Prevents accidental changes to settings during operation.
- **LED Display:** Provides clear information on cycle status.
- **Durable Plastic Lid:** Robust and long-lasting.
- **Large Drum Opening:** Facilitates easy loading and unloading of laundry.

SETUP

1. Unpacking and Placement:

Carefully remove all packaging materials. Place the washing machine on a firm, level surface. Ensure there is adequate space around the machine for ventilation and access.

2. Water Connection:

Connect the water inlet hoses to the hot and cold water taps. Ensure connections are tight to prevent leaks. The machine features a dual water inlet for optimal temperature control.

3. Drain Hose Installation:

Position the drain hose into a suitable drain pipe or sink. Ensure the hose is securely fastened to prevent it from dislodging during the drain cycle.



Figure 3: Rear view of the washing machine, showing the hot and cold water inlets and the drain hose connection point.

4. Power Connection:

Plug the power cord into a grounded electrical outlet. Verify that the voltage and frequency match the specifications of your appliance (220-240V / 50Hz).

1. Control Panel Overview:

The control panel allows you to select programs, adjust settings, and start/pause cycles. Familiarize yourself with the buttons and their functions.



Figure 4: Detailed view of the control panel, showing program selection, water level, delay, function, rinse, and temperature controls.

2. Loading Laundry:

Open the top lid and place laundry loosely into the drum. Do not overload the machine. Ensure items are evenly distributed.



Figure 5: The washing machine with its lid open, revealing the spacious drum for easy loading and unloading.

3. Adding Detergent and Softener:

Pull out the detergent dispenser drawer. Add the appropriate amount of detergent to the main wash compartment and fabric softener to its designated compartment.



Figure 6: Close-up of the detergent dispenser drawer, indicating where to add detergent and fabric softener.

4. Program Selection:

Turn the program knob or press the program button to select one of the 8 available washing programs (e.g., Normal, Jeans, Soft, Strong, Quick Wash, etc.).

5. Adjusting Settings:

Use the respective buttons to adjust water level, rinse cycles, spin speed, or delay start time as needed for your laundry.

6. Child Lock Function:

To activate the child lock, press and hold the designated child lock button (often a combination of two buttons) for a few seconds until the indicator light appears. This prevents accidental changes to settings by children.

7. Starting the Wash Cycle:

Press the "Start/Pause" button to begin the selected wash cycle. The LED display will show the remaining time.

1. Cleaning the Exterior:

Wipe the exterior of the washing machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.

2. Cleaning the Drum:

Run a "Tub Clean" cycle (if available) or a hot wash cycle with a washing machine cleaner periodically to prevent odor and residue buildup.

3. Cleaning the Lint Filter:

Regularly clean the lint filter to ensure efficient operation and prevent lint from redepositing on clothes. Locate the lint filter inside the drum, remove it, clean out accumulated lint, and reinsert it securely.



Figure 7: The lint filter located inside the washing machine drum, which should be cleaned regularly.

4. Drain Pump Filter (if accessible):

Some models have an accessible drain pump filter. Refer to the diagram or specific instructions in your physical manual for its location and cleaning procedure. This helps prevent blockages.

TROUBLESHOOTING

Before contacting service, check the following common issues and solutions:

Problem	Possible Cause	Solution
Machine does not start	Power cord unplugged; Lid not closed properly; Program not selected.	Check power connection; Close lid firmly; Select a program and press Start.
No water filling	Water taps closed; Water inlet hose kinked; Water supply cut off.	Open water taps; Straighten hose; Check household water supply.
Water not draining	Drain hose kinked or blocked; Drain pump filter clogged.	Straighten or clear drain hose; Clean drain pump filter.
Excessive vibration/noise	Machine not level; Laundry unevenly distributed; Transit bolts not removed.	Adjust leveling feet; Redistribute laundry; Ensure transit bolts are removed (if applicable).

SPECIFICATIONS

Feature	Detail
Brand	Super General
Model	KSGW724
Capacity	7 kg
Dimensions (D x W x H)	62.5 x 63.5 x 102 cm
Weight	36 kg
Max Spin Speed	680 RPM
Noise Level	6 dB
Control Type	Touch
Programs	8 Standard Cycles
Access Location	Top Load
Voltage	240 Volts
Material	Metal
Special Features	High Efficiency, Child Lock, Drain Pump
Color	Silver

WARRANTY AND SUPPORT

Your Super General KSGW724 washing machine comes with a **two-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures reliable operation under normal use conditions.

For technical support, warranty claims, or service requests, please contact Super General customer service. Keep your purchase receipt and product model number (KSGW724) readily available when contacting support.

For further assistance, please visit the official Super General website or refer to the contact information provided with your purchase documentation.