



[Manuals.plus](#) /

› [Philips](#) /

› Philips Airfryer HD9270/96 User Manual

Philips HD9270.96

Philips Airfryer HD9270/96 User Manual

Essential Guide for Operation and Maintenance

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Philips Airfryer HD9270/96. Please read these instructions carefully before using the appliance and retain them for future reference.



Image: The Philips Airfryer HD9270/96, a black multi-cooker fryer, shown with chicken pieces cooking inside its pull-out basket. The digital display shows a temperature setting.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances.

- Do not immerse the appliance in water or any other liquid.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage.
- Keep the appliance and its cord out of reach of children.
- Do not operate the appliance if the plug, the mains cord, or the appliance itself is damaged.
- Always unplug the appliance after use and before cleaning.
- Allow the appliance to cool down before handling or cleaning.

SETUP AND FIRST USE

Unpacking

Carefully remove the Airfryer and all accessories from the packaging. Remove any packaging materials, stickers, or labels.

Cleaning Before First Use

Before first use, clean the basket and pan thoroughly with hot water, some dishwashing liquid, and a non-abrasive sponge. The removable parts are dishwasher-safe. Wipe the inside and outside of the appliance with a moist cloth.

Placement

Place the appliance on a stable, horizontal, and level surface. Do not place the appliance on non-heat-resistant surfaces. Ensure there is at least 10 cm (4 inches) of free space at the back and sides of the appliance and 10 cm (4 inches) of free space above it.

OPERATING INSTRUCTIONS

General Operation

1. Plug the mains plug into a grounded wall socket.
2. Pull the pan out of the Airfryer.
3. Put the ingredients in the basket. Do not exceed the MAX indication.
4. Slide the pan back into the Airfryer.
5. Use the touch screen controls to set the desired temperature and time. The appliance features 7 pre-settings for common dishes.
6. Press the start/pause button to begin cooking.
7. Some ingredients require shaking halfway through the preparation time. The Airfryer may beep to remind you.
8. When the cooking time has elapsed, the appliance will beep. Carefully pull out the pan and remove the food.

Using Accessories

The Philips Airfryer HD9270/96 comes with a double-tier grill with skewers accessories, allowing for versatile cooking options.



Image: A silver-colored double-tier grill rack, designed to fit inside the Airfryer, used for grilling and roasting with skewers.

Cooking Functions

- **Frying:** Utilizes Rapid Air technology for frying with up to 90% less fat.
- **Baking:** Ideal for cakes, muffins, and other baked goods.
- **Grilling:** Perfect for meats, fish, and vegetables using the grill accessory.
- **Roasting:** Suitable for roasting poultry, meat, or vegetables.
- **Keep Warm:** Maintains food at an optimal serving temperature after cooking.



Image: A person holding a smartphone displaying a recipe application, suggesting connectivity or recipe guidance for the Airfryer.



Image: A family gathered around a table, with a man serving a bowl of golden-brown fries, illustrating the healthy and convenient meals prepared with the Airfryer.

CARE AND MAINTENANCE

Cleaning

Clean the appliance after every use.

- Unplug the Airfryer and let it cool down completely.
- The pan and basket are dishwasher-safe. Alternatively, clean them with hot water, dishwashing liquid, and a non-abrasive sponge.
- For stubborn food residue, soak the pan and basket in hot water with some dishwashing liquid for approximately 10 minutes.
- Wipe the outside of the appliance with a moist cloth.
- Clean the heating element with a cleaning brush to remove any food residue.

Storage

Ensure the appliance is clean and dry before storing. Store the Airfryer in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
The Airfryer does not work.	The appliance is not plugged in.	Plug the mains plug into a grounded wall socket.
Food is not cooked evenly.	Too much food in the basket; food not shaken.	Reduce the amount of food; shake the basket halfway through cooking.
White smoke comes out of the appliance.	Fat from fatty ingredients; pan/basket not cleaned properly.	Wipe off excess oil from ingredients; clean the pan and basket thoroughly.
Fresh fries are not crispy.	Not soaked or dried properly; too much oil.	Soak potato sticks in water for 30 minutes, dry thoroughly; use only half a tablespoon of oil.

SPECIFICATIONS

Model: HD9270/96

Product Type: Deep Fryer / Multi-Cooker Fryer

Capacity: 6.2 Liters (Fryer food capacity: 1.2 kg)

Power: 2000 W

Technology: Rapid Air Technology

Control Type: Touch Screen

Display Type: LED

Pre-settings: 7 programs

Functions: Frying, Baking, Grilling, Roasting, Keep Warm

Dimensions (W x D x H): 403 mm x 315 mm x 307 mm (approx. 15.87"D x 12.4"W x 12.09"H)

Weight: 5.55 kg (approx. 1.1 pounds)

Cord Length: 0.8 m

Dishwasher Safe Parts: Yes (Pan and Basket)

Material: Plastic (Outer), Stainless Steel (Inner)

Color: Black / Colourless

Special Features: Temperature Regulation, Auto Power Off, Cool Wall Housing, On/Off Switch

Country of Origin: China

WARRANTY AND SUPPORT

Warranty Information

This Philips Airfryer HD9270/96 comes with a **2-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, neglect, accidents, alteration, or unauthorized repair.

Customer Support

For further assistance, troubleshooting, or to register your product, please visit the official Philips support website or contact their customer service.

www.philips.com/support

