

Cockatoo WP100

Cockatoo WP100 Ultra Slim DC Motorised Treadmill

User Manual

[Introduction](#)

[Safety Information](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Warranty &](#)

[Support](#)

[Specifications](#)

1. INTRODUCTION

Thank you for choosing the Cockatoo WP100 Ultra Slim DC Motorised Treadmill. This manual provides essential information for the safe and effective use, setup, operation, and maintenance of your new fitness equipment. Please read this manual thoroughly before using the treadmill and retain it for future reference.

2. IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of serious injury, read all instructions before using this treadmill.

- Ensure the treadmill is placed on a flat, stable surface with adequate clearance around it.
- Keep children and pets away from the treadmill during operation.
- The maximum user weight for walking is 120 kg, and for running is 90 kg. Do not exceed these limits.
- Always wear appropriate athletic footwear while using the treadmill.
- Stop exercising immediately if you feel faint, dizzy, or experience pain.
- A voltage stabilizer is advised for the safety of the motor and for better performance of the treadmill.
- Unplug the treadmill from the power outlet when not in use or before cleaning and maintenance.
- This treadmill does not feature an incline level.

3. SETUP AND ASSEMBLY

The Cockatoo WP100 treadmill comes 100% installed, requiring minimal setup before first use.

3.1 Package Contents

Verify that all components are present in the box:

- One Cockatoo WP100 Walking Pad Treadmill
- Wireless Remote Control
- Power Cord
- User Manual (this document)
- Tool Kit
- Warranty Card

3.2 Placement

Place the treadmill on a firm, level surface. Ensure there is at least 0.6 meters (2 feet) of clear space behind the treadmill and 0.3 meters (1 foot) on each side for safe operation and access.

The treadmill features a space-saving design with wheels for easy movement and storage.



This image illustrates the treadmill's space-saving design, shown stored neatly under a sofa. It emphasizes its lightweight, ultra-slim profile, and ease of movement facilitated by integrated wheels.

3.3 Power Connection

Connect the power cord to the treadmill's power input and then plug it into a grounded electrical outlet. It is recommended to use a voltage stabilizer for optimal performance and motor protection.

4. OPERATION

The Cockatoo WP100 treadmill is operated entirely via its wireless remote control.

4.1 Powering On/Off

- To power on, ensure the treadmill is plugged in and press the power button on the remote control. The display will illuminate.
- To power off, press and hold the power button on the remote control until the display turns off.

4.2 Using the Remote Control



WIRELESS REMOTE CONTROL

HANDS FEELS COMFORTABLE

A close-up view of the treadmill's integrated display, showing time, speed, distance, and calories. The wireless remote control, used for operating the treadmill, is also visible.

The remote control allows you to start, stop, and adjust the speed of the treadmill. Familiarize yourself with the buttons before starting your workout.

4.3 Adjusting Speed

The treadmill offers a speed range of 1 to 8 km/hour.

- Use the '+' button on the remote to increase speed.
- Use the '-' button on the remote to decrease speed.



SUPPORT VARIABLE SPEED RUNNING

SPEED RANGE
1-8 KM/HOUR

This image shows an individual walking on the Cockatoo WP100 treadmill, demonstrating its capability for variable speed running within a range of 1 to 8 km/hour.

4.4 Pre-set Workout Programs (P1-P12)

The treadmill includes 12 pre-set workout programs (P1 to P12) designed for effective exercise. Refer to the remote control instructions for selecting and changing these modes to plan your structured exercise routine.

4.5 Display Information

The integrated LCD display shows the following technical features during your workout:

- **Time:** Duration of your workout.
- **Speed:** Current speed in km/hour.
- **Distance:** Total distance covered.
- **Calorie:** Estimated calories burned.

4.6 Audio Connectivity

The treadmill features an auxiliary audio jack for connecting your phone to listen to music during your workout.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your treadmill.

5.1 Lubrication

The running belt requires regular lubrication with silicon oil to reduce friction and extend the life of the motor and belt. Consult the specific instructions provided with your silicon oil for application frequency and method. Generally, apply silicon oil every 30-50 hours of use or as needed.

5.2 Cleaning

- Wipe down the treadmill's surfaces with a damp cloth after each use to remove sweat and dust.
- Do not use abrasive cleaners or solvents, as they may damage the finish.
- Regularly vacuum underneath the treadmill to prevent dust and debris from accumulating in the motor area.

5.3 Storage

Due to its ultra-slim and portable design, the treadmill can be easily stored under furniture or in a closet when not in use. Utilize the integrated wheels for convenient relocation.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your treadmill.

6.1 Treadmill Not Starting

- Ensure the power cord is securely plugged into both the treadmill and a functional electrical outlet.
- Check if the main power switch (if present) is in the 'ON' position.
- Verify that the remote control has working batteries and is properly paired with the treadmill.

6.2 Remote Control Unresponsive

- Replace the batteries in the remote control.
- Ensure there are no obstructions between the remote control and the treadmill's receiver.
- Try re-pairing the remote control if instructions are provided in a separate guide.

6.3 Belt Slipping or Hesitating

- The running belt may require lubrication. Refer to the 'Lubrication' section.
- The belt tension might need adjustment. Consult the detailed user manual or contact customer support for guidance on belt tensioning.

6.4 Unusual Noises

- Check for any loose parts or debris under the belt.
- Ensure the treadmill is on a level surface.
- If the noise persists, discontinue use and contact customer support.

7. SPECIFICATIONS



This image displays the Cockatoo WP100 treadmill, highlighting its compact dimensions of 141cm length and 66cm width. It also indicates the maximum user weight capacity: 120 kg for walking and 90 kg for running.

Feature	Detail
Model Name	WP100
Motor Type	DC-Motorised
Motor Horsepower	4.5 HP Peak
Speed Range	1-8 km/hour
Incline Level	No Incline

Max User Weight (Walking)	120 kg
Max User Weight (Running)	90 kg
Running Surface (L x W)	1120 x 420 mm (44 x 16.5 inches)
Pre-set Programs	12 (P1 to P12)
Display Type	LCD
Metrics Measured	Time, Speed, Distance, Calories Burned
Control Method	Wireless Remote Control
Connectivity	Auxiliary Audio Jack
Material	Alloy Steel
Item Weight	28 kg
Item Dimensions (L x W x H)	141 x 66 x 15.5 cm
Special Features	Portable, Ultra Slim, Wheels for movement

POWERFUL AND QUIET MOTOR

4.5 HP MOTOR

LOW NOISE

HIGH TEMPERATURE RESISTANCE



This image provides an internal view of the treadmill, highlighting its 4.5 HP peak DC motor, emphasizing its powerful yet quiet operation and high temperature resistance.

8. WARRANTY & SUPPORT

8.1 Warranty Details

The Cockatoo WP100 Treadmill comes with the following warranty:

- **1 Year Motor Warranty**
- **1 Year Parts Warranty**

- **3 Years Frame Warranty**

Please retain your purchase receipt and warranty card for any warranty claims. The warranty covers manufacturing defects under normal use conditions. Damage due to improper use, lack of maintenance (e.g., insufficient lubrication), or unauthorized repairs is not covered.

8.2 Customer Support

For technical assistance, spare parts, or warranty claims, please contact Cockatoo Sports Pvt Ltd customer service. Refer to the contact information provided on your warranty card or the official Cockatoo website. When contacting support, please have your model number (WP100) and purchase details readily available.