



Manuals.plus /

- › Edihome /
- › Edihome Portable Blender User Manual - Model EDIH-0177-B

Edihome EDIH-0177-B

Edihome Portable Blender User Manual

MODEL: EDIH-0177-B

1. INTRODUCTION

Thank you for choosing the Edihome Portable Blender. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new appliance. Please read these instructions thoroughly before first use and retain them for future reference.

The Edihome Portable Blender is designed for preparing smoothies, juices, protein shakes, and baby food on the go. Its compact size and USB rechargeable battery make it a convenient companion for a healthy lifestyle.



Image 1.1: Edihome Portable Blender with strawberries, mango, and juice splashes.

2. SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Read all instructions before using the appliance.
- Keep the blender out of reach of children.
- Do not immerse the motor base in water or other liquids. Clean with a damp cloth only.
- Ensure the glass bottle is securely attached to the motor base before operation. The blender is equipped with a safety mechanism that prevents operation if the pitcher and base are separated.
- Avoid overfilling the blender. Do not exceed the maximum fill line. The blender will stop if too much food is loaded.
- Do not operate the blender continuously for more than 60 seconds to prevent overheating. The blender will automatically stop in case of overheating.
- Exercise caution when handling the sharp blades. Always clean the blades carefully.
- Only use the provided USB cable for charging.
- Do not attempt to blend hard ingredients such as whole nuts, coffee beans, or frozen solid fruits without sufficient liquid.

- In case of a short circuit, the blender will automatically shut off.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Edihome Portable Blender:

- **Glass Jug:** The main container for blending ingredients, made of borosilicate glass.
- **Blade Base:** Contains the stainless steel blades and connects to the motor base.
- **Motor Base:** Houses the motor, battery, and control switch.
- **Switch:** Power button to activate blending.
- **USB Charging Port:** For recharging the internal battery.



Image 3.1: Labeled components of the Edihome Portable Blender.

4. SETUP AND CHARGING

4.1 Initial Charging

Before first use, fully charge the blender's internal 4000mAh lithium battery. Connect the provided USB charging cable to the USB port on the motor base and plug the other end into a compatible USB power source (e.g., laptop, power bank, USB wall adapter).

PORTABLE JUICER-DRINKING

FRESH JUICE IN ANY TIME



USB CHARGING
PORT



EASY
INSTALLATION

Image 4.1: Edihome Portable Blender highlighting the USB charging port.

4.2 Assembly

1. Ensure the blender is clean and dry.
2. Place the blade base onto the motor base and twist clockwise until securely locked.
3. Place the glass jug onto the blade base and twist clockwise until securely locked.

5. OPERATING INSTRUCTIONS

Follow these steps to prepare your beverages:

1. **Prepare Ingredients:** Cut food into small pieces, approximately 1.0-1.5 cm (0.4-0.6 inches). Remove any hard skins or pits.
2. **Add Ingredients:** Pour water, milk, or other liquids into the container first, then add your prepared fruits and vegetables. Do not exceed the maximum fill line.

3. **Secure Assembly:** Ensure the glass jug and blade base are securely twisted onto the motor base.
4. **Start Blending:** Incline the blender to an angle of approximately 45 degrees. Press the power switch to begin blending.
5. **Optimize Blending:** During the blending process, gently shake the blender 4-8 times for about 30-40 seconds to help the ingredients mix thoroughly and prevent them from sticking to the blades.
6. **Finish:** Once desired consistency is reached, release the power switch.



1. Cut food to several pieces, remove skin and nut. (around 1.5-1.0cm)



2. Pour water and milk into the container.



3. Incline the machine to the angle of 45°, and then turn on the machine.



4. During blender, to help food blend, shake 4-8 times during the blend of around 30-40 seconds.

Image 5.1: Step-by-step guide for preparing and blending ingredients.



Image 5.2: Demonstrating the recommended shaking motion during blending.

5.1 Usage Examples

The Edihome Portable Blender is versatile and can be used for various preparations:

- **Smoothies:** Blend fresh or frozen fruits with yogurt, milk, or juice.
- **Protein Shakes:** Mix protein powder with liquid for a quick post-workout drink.
- **Baby Food:** Puree cooked fruits and vegetables for homemade baby food.
- **Cocktails:** Prepare blended cocktails (ensure ice is crushed or small).



Image 5.3: Examples of beverages and foods that can be prepared with the blender.

6. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your blender:

- **Disassembly:** After use, unscrew the glass jug from the blade base, and then unscrew the blade base from the motor base.
- **Cleaning the Jug and Blade Base:** Wash the glass jug and blade base with warm, soapy water. Use a brush to carefully clean around the blades. Rinse thoroughly. These parts are generally dishwasher safe, but hand washing is recommended for longevity.
- **Cleaning the Motor Base:** Wipe the motor base with a damp cloth. **Do not immerse the motor base in water or any other liquid.**
- **Drying:** Ensure all parts are completely dry before reassembling or storing.
- **Storage:** Store the blender in a clean, dry place away from direct sunlight.

7. TROUBLESHOOTING

If you encounter any issues with your Edihome Portable Blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not start.	Battery is low or depleted.	Charge the blender fully using the USB cable.
Blender does not start.	Glass jug or blade base not securely attached.	Ensure all components are twisted and locked into place. The safety mechanism prevents operation if not properly assembled.
Blender stops during operation.	Overheating.	Turn off the blender and allow it to cool down for at least 15-20 minutes before resuming use.
Blender stops during operation.	Too much food or ingredients are too large/hard.	Reduce the amount of ingredients, cut them into smaller pieces, or add more liquid.
Blades are not spinning effectively.	Ingredients are stuck.	Turn off the blender, gently shake it, or add more liquid. If necessary, disassemble and clear the obstruction carefully.

8. SPECIFICATIONS

Feature	Specification
Brand	Edihome
Model Number	EDIH-0177-B
Color	Blue
Capacity	380 Milliliters
Power	67 Watts
Voltage	7.4 Volts
Material	Borosilicate Glass
Battery	1 Lithium-ion (4000mAh)
Charging	USB Rechargeable
Product Dimensions (L x W x H)	11.99 x 11.99 x 30 cm
Item Weight	720 grams
Special Feature	Portable
Automatic Shut-off Function	Yes (for overheating, separation, short circuit, overfilling)

9. WARRANTY AND SUPPORT

Edihome products are covered by a European warranty. If you experience any issues with your Edihome Portable Blender, please contact customer support for assistance. Details regarding warranty claims and service can typically be found on the Edihome official website or through your point of purchase.

For further inquiries or technical support, please refer to the contact information provided with your product

packaging or visit the official Edihome website.