



[Manuals.plus](#) /

› [POWWA](#) /

› POWWA One-Touch Electric Garlic Chopper User Manual

## POWWA CP-4402

# POWWA One-Touch Electric Garlic Chopper User Manual

Model: CP-4402

## INTRODUCTION

---

Thank you for choosing the POWWA One-Touch Electric Garlic Chopper. This compact and powerful food processor is designed to simplify your food preparation tasks, from mincing garlic and onions to preparing baby food. Please read this manual thoroughly before first use to ensure safe and optimal operation of your device.



Image: The POWWA One-Touch Electric Garlic Chopper, showcasing its sleek design, included USB charging cable, and the sharp S-shaped blade. Surrounding the chopper are examples of ingredients it can process, such as minced meat, chopped tomatoes, garlic, onions, and chili, demonstrating its versatility.

## PRODUCT OVERVIEW

---

### Components

The POWWA Electric Garlic Chopper consists of the following main parts:

- **Motor Unit:** Contains the powerful 45W motor and the one-touch switch button.
- **Lid:** Features a safety mechanism that prevents operation unless properly closed.
- **Stainless Steel Blades:** Food-grade 402 stainless steel S-shaped 3-blade for efficient chopping.
- **Food Container (Bowl):** Transparent 200ml capacity bowl with a MAX fill line.
- **USB Type-C Charging Port:** For convenient recharging.

- **Anti-slip Rubber Pad:** Located at the base of the food container for stability.



Image: An exploded diagram illustrating all the individual components of the POWWA Electric Garlic Chopper, including the motor unit with its switch button and Type-C charging port, the overflow cover, the stainless steel blades, the food container, and the anti-slip rubber pad, providing a clear view of each part.

## SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the food container, lid, and blades with warm soapy water. Rinse thoroughly and dry completely. The motor unit should only be wiped clean with a damp cloth; do not immerse it in water.
3. **Assemble Blades:** Carefully place the stainless steel blades onto the central pin inside the food container. Ensure they are securely seated.
4. **Charge Battery:** Ensure the device is fully charged before initial use. Refer to the 'Charging' section for instructions.

## CHARGING

The POWWA Electric Garlic Chopper features a built-in rechargeable battery for cordless operation.

- Locate the Type-C charging port on the motor unit.
- Connect the provided USB charging cable to the port and the other end to a compatible USB power adapter (not included) or a computer USB port.
- The indicator light on the motor unit will illuminate during charging.
- A full charge typically takes 2-3 hours. Once fully charged, the device can be used approximately 50 times.
- Do not operate the chopper while it is charging.



Image: The POWWA Electric Garlic Chopper connected to a USB power source via its Type-C charging port, illustrating the fast charging capability and highlighting the 2-3 hour charging time and approximately 50 uses per full charge.

## OPERATION

Using your POWWA Electric Garlic Chopper is simple and intuitive:

1. **Prepare Ingredients:** Cut ingredients into small pieces (approximately 1-2 cm) before placing them into the food container. This ensures optimal chopping results and prevents strain on the motor.
2. **Add Ingredients:** Place the prepared ingredients into the food container. Do not exceed the "MAX" fill line (200ml) to prevent overfilling and ensure proper operation.
3. **Secure Lid:** Place the lid onto the food container, ensuring it is properly aligned and securely closed. The chopper will not operate if the lid is not closed tightly due to its safety protection feature.
4. **Attach Motor Unit:** Place the motor unit on top of the lid, aligning it correctly.
5. **One-Touch Operation:** Press and hold the button on top of the motor unit to begin chopping. Release the button to stop. Control the chopping consistency by pulsing the button for short bursts or holding it down for a finer chop.
6. **Remove Ingredients:** Once desired consistency is achieved, remove the motor unit, then the lid, and carefully take out the chopped ingredients.



Add the ingredients



Close the lid



Press the button



Take out the ingredients

Image: A visual step-by-step guide demonstrating the use of the POWWA Electric Garlic Chopper: 1. Add ingredients (e.g., garlic cloves). 2.

Close the lid securely. 3. Press the button on the motor unit to chop. 4. Take out the finely chopped ingredients.

## Chopping Performance

The 45W motor and sharp S-shaped blades allow for quick and efficient chopping:

- Garlic: Approximately 5 seconds for mincing.
- Onion: Approximately 5 seconds for chopping.
- Chili: Approximately 5 seconds for chopping.
- Lean Meat: Approximately 6 seconds for mincing.



Image: A graphic illustrating the rapid chopping capabilities of the POWWA Electric Garlic Chopper, showing how chili, garlic, onion, and lean meat can be processed to desired consistencies in just 5-6 seconds.

## Versatile Applications

This mini chopper is ideal for a variety of uses:

- Mincing garlic, ginger, chili, and herbs.
- Chopping onions and other vegetables.
- Preparing minced meat.
- Making homemade baby food purees (e.g., broccoli, pumpkin, potato).
- Chopping nuts for baking.



Image: A baby happily eating pureed food, demonstrating one of the key applications of the POWWA Electric Garlic Chopper for preparing healthy baby food from ingredients like broccoli, pumpkin, and potato.

## CLEANING & MAINTENANCE

---

Proper cleaning and maintenance will extend the life of your chopper:

- **Disassemble:** Always unplug the motor unit (if charging) and disassemble the chopper before cleaning.
- **Wash Components:** The food container, lid, and blades are IPX5 waterproof and can be rinsed directly under running water or placed in the dishwasher.
- **Clean Motor Unit:** The motor unit should **never** be immersed in water. Wipe it clean with a damp cloth.
- **Caution with Blades:** The blades are very sharp. Handle them with extreme care during cleaning to avoid injury. Use a brush if necessary.
- **Dry Thoroughly:** Ensure all parts are completely dry before reassembling or storing to prevent rust or mold.
- **Storage:** Store the chopper in a dry, cool place, away from direct sunlight.

## SAFETY LID DESIGN

Safety Lid Design ensuring safety prevents blades from flying out and Avoid motor cleaning and soaking in water to extend the service life



## EASY TO CLEAN



Image: A visual representation of the POWWA Electric Garlic Chopper's safety lid design, which prevents blades from flying out, and the ease of cleaning the bowl and lid under running water, highlighting its IPX5 waterproof rating.

## SAFETY PRECAUTIONS

To ensure safe operation and prevent injury or damage, please adhere to the following safety guidelines:

- Always keep the chopper out of reach of children.
- Ensure the lid is securely closed before operating the device. The safety mechanism prevents operation if the lid is not properly engaged.
- Do not touch the blades with your hands, especially when the device is assembled or operating. Blades are extremely sharp.
- Do not overfill the food container beyond the "MAX" mark.
- Do not attempt to chop extremely hard ingredients like ice cubes or unpeeled nuts, as this may damage the blades or motor.
- Only use the provided USB cable for charging.

- Do not immerse the motor unit in water or any other liquid.
- If the device malfunctions or is damaged, do not attempt to repair it yourself. Contact customer support.



Image: A red banner with important notes for the POWWA Electric Garlic Chopper, emphasizing cutting food into small pieces, checking installation and power supply if it doesn't work, and not exceeding the MAX mark on the cup.

## TROUBLESHOOTING

If you encounter issues with your POWWA Electric Garlic Chopper, please refer to the following common problems and solutions:

- **Device does not turn on:**
  - Ensure the motor unit is fully charged. Connect it to a power source and allow it to charge for 2-3 hours.
  - Verify that the lid is securely closed and the motor unit is properly aligned on top of the lid. The safety mechanism prevents operation if not correctly assembled.
- **Chopping is inefficient or uneven:**
  - Ensure ingredients are cut into small, manageable pieces (approx. 1-2 cm) before adding them to the container.
  - Do not overfill the container. Ensure ingredients are below the "MAX" line.
  - The blades may be dull. If the device has been used extensively, consider contacting customer support for replacement parts if available.
- **Device stops during operation:**
  - The battery may be low. Recharge the device.
  - The motor may have overheated due to continuous operation or processing overly hard ingredients. Allow the device to cool down for 10-15 minutes before attempting to use it again.

If the problem persists after trying these solutions, please contact customer support for further assistance.

## SPECIFICATIONS

Feature	Detail
Brand	POWWA
Model Number	CP-4402

Product Dimensions	3.5"D x 3.5"W x 5.51"H
Color	Black
Bowl Capacity	200 Milliliters
Recommended Uses	Chop, Mince
Number of Speeds	1
Product Care Instructions	Dishwasher Safe (Bowl, Lid, Blades)
Included Components	Chopping Blade, Container, Lid
Blade Material	Stainless Steel
Item Weight	14.1 ounces
Special Features	Baby Food Maker, Garlic Masher Crusher, Garlic Mincer Crusher, Garlic Press, Onion Grinder, Rechargeable Vegetable Chopper, Small Food Processor

## WARRANTY & SUPPORT

---

POWWA products are manufactured with quality and reliability in mind. For any questions, concerns, or technical support regarding your One-Touch Electric Garlic Chopper, please refer to the contact information provided with your purchase or visit the official POWWA website. Please retain your proof of purchase for warranty claims.