

DAVITU XC2-48T-E

XINJE XC2-48T-E PLC Controller User Manual

Model: XC2-48T-E | Brand: DAVITU

1. INTRODUCTION

This user manual provides comprehensive instructions for the installation, operation, maintenance, and troubleshooting of the XINJE XC2-48T-E Programmable Logic Controller (PLC). Please read this manual thoroughly before using the device to ensure proper and safe operation.

2. PRODUCT OVERVIEW

The XINJE XC2-48T-E is a robust and reliable PLC designed for industrial automation applications. It features multiple input/output terminals for connecting various sensors and actuators.



Figure 2.1: Front view of the XINJE XC2-48T-E PLC Controller, showing the main unit with its transparent cover over the screw terminal blocks for wiring connections. The model number 'XC2-48T-E' is visible on the label.

Key components include:

- **Input/Output Terminals:** Screw terminals for connecting field devices.
- **Status Indicators:** LEDs to show power, run, and error status.
- **Communication Ports:** For programming and data exchange (e.g., RS232, RS485).
- **Mounting Rails:** Designed for DIN rail mounting in control cabinets.

3. SPECIFICATIONS

Feature	Detail
Model Number	XC2-48T-E
Manufacturer	XINJE
Condition	New and Genuine
ASIN	B09FSWHGHV
Part Number	DVT-9E3E8019647526F223E486075F213F51

4. SETUP AND INSTALLATION

Follow these steps for proper installation of the PLC:

1. **Mounting:** Securely mount the XC2-48T-E PLC onto a standard DIN rail within a control cabinet. Ensure adequate ventilation space around the unit.
2. **Power Wiring:** Connect the appropriate power supply to the designated power terminals. Refer to the wiring diagram provided with the product for correct voltage and polarity.
3. **Input Wiring:** Connect input devices (e.g., sensors, switches) to the input terminals. Ensure all connections are secure and correctly assigned according to your application's logic.
4. **Output Wiring:** Connect output devices (e.g., relays, contactors) to the output terminals. Verify that output loads do not exceed the PLC's specified current ratings.
5. **Communication Setup:** Connect the PLC to a programming device (e.g., PC) using the appropriate communication cable (e.g., RS232). Install the necessary programming software and drivers.

Warning: Ensure all power is disconnected before performing any wiring to prevent electrical shock or damage to the device.

5. OPERATING INSTRUCTIONS

Once the PLC is installed and wired, follow these steps to operate it:

1. **Program Download:** Use the programming software to create or load your control program. Download the program to the PLC.
2. **Mode Selection:** Set the PLC to RUN mode. This can typically be done via the programming software or a physical switch on the PLC (if available).
3. **Monitoring:** Monitor the PLC's status indicators (e.g., RUN, STOP, ERROR LEDs) and the status of inputs and outputs through the programming software.
4. **Testing:** Thoroughly test the programmed logic by simulating input conditions and observing output responses.
5. **Safe Shutdown:** To power off the PLC, first switch it to STOP mode (if applicable), then disconnect the power supply.

6. MAINTENANCE

Regular maintenance ensures the longevity and reliable operation of your PLC:

- **Cleaning:** Periodically clean the PLC and its surrounding area to prevent dust and debris accumulation, which can affect cooling and performance. Use a soft, dry cloth.
- **Connection Check:** Routinely inspect all wiring connections for looseness or corrosion. Tighten any loose terminals.
- **Environmental Control:** Ensure the operating environment remains within the specified temperature and humidity ranges to prevent damage.
- **Firmware Updates:** Check the manufacturer's website for any available firmware updates that may improve performance or address known issues.

7. TROUBLESHOOTING

This section provides solutions to common issues you might encounter:

- **PLC Not Powering On:**
 - Check power supply connections and voltage.
 - Verify the power source is active.

- **PLC Not Running Program:**

- Ensure the PLC is in RUN mode.
- Check for error indicators (LEDs) and consult the programming software for error codes.
- Verify the program has been successfully downloaded.

- **Input/Output Not Responding:**

- Check wiring for correct connections and continuity.
- Verify the input/output device is functioning correctly.
- Confirm the PLC program logic is correctly addressing the I/O.

- **Communication Issues:**

- Ensure the correct communication cable is used and properly connected.
- Verify communication settings (baud rate, parity, data bits) match between the PLC and the programming device.
- Check if the correct drivers are installed.

8. WARRANTY INFORMATION

All XINJE XC2-48T-E PLC Controllers come with a **1-year warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by improper installation, misuse, unauthorized modifications, or external factors.

9. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding the XINJE XC2-48T-E PLC Controller, please contact the manufacturer, XINJE, or your authorized distributor. Refer to the product packaging or manufacturer's official website for contact details.

© 2024 DAVITU. All rights reserved.
This manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question