

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [ECOVACS](#) /

> [ECOVACS DEEBOT OZMO U2 Robot Vacuum Cleaner 2 in1 Vacuum and Mop User Manual](#)

ECOVACS DEEBOT U2

ECOVACS DEEBOT OZMO U2 Robot Vacuum Cleaner

USER MANUAL

Introduction

The ECOVACS DEEBOT OZMO U2 is a versatile 2-in-1 robot vacuum and mop designed to provide efficient floor cleaning. It features simultaneous vacuuming and mopping capabilities, a systematic cleaning pattern, and an enhanced Max+ Mode for increased suction. Control the DEEBOT OZMO U2 conveniently via its dedicated mobile application or through voice commands with compatible smart assistants like Amazon Alexa or Google Assistant. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your device.

Setup

Follow these steps to set up your DEEBOT OZMO U2 for the first time.

- Unpacking and Component Check:** Carefully remove the DEEBOT OZMO U2 and all accessories from the packaging. Ensure all components listed in the packing list are present.
- Charging Dock Placement:** Place the charging dock against a wall in an open, uncluttered area. Ensure there is at least 0.5 meters (1.6 feet) of clear space on both sides of the dock and 1.5 meters (4.9 feet) in front of it. Plug the power adapter into the charging dock and then into a wall outlet.
- Initial Charging:** Place the DEEBOT onto the charging dock, ensuring the charging pins align. The robot will begin charging automatically. For optimal battery life, fully charge the robot before its first use. A full charge typically takes approximately 4.5 hours.
- App Download and Connection:** Download the ECOVACS HOME app from your mobile device's app store. Follow the in-app instructions to register an account and connect your DEEBOT OZMO U2 to your home Wi-Fi network. The app allows for advanced control and scheduling.



Figure 1: Top view of the DEEBOT OZMO U2 robot vacuum cleaner. This image shows the sleek, circular design of the robot with the power button and 'DEEBOT' branding visible on its top surface.



Figure 2: The DEEBOT OZMO U2 operating on a hard floor, with a smartphone displaying the ECOVACS HOME app interface. The app shows cleaning progress and available cleaning modes like Auto, Edge, and Spot.

Operating Instructions

Understand the various cleaning modes and control options for your DEEBOT OZMO U2.

- **Cleaning Modes:**
 - **Auto Mode:** The DEEBOT cleans in a systematic pattern, covering the entire accessible area.
 - **Spot Mode:** The DEEBOT focuses on a specific dirty area, cleaning in a spiral pattern.
 - **Edge Mode:** The DEEBOT cleans along the edges of rooms.
- **Vacuuming and Mopping:** The DEEBOT OZMO U2 can vacuum and mop simultaneously. Ensure the water reservoir is filled and the mop pad is attached for mopping functions. Adjust water level settings via the app if needed.
- **Max+ Mode:** Activate Max+ Mode through the app to increase suction power by approximately 2.5 times for deeper cleaning on carpets or heavily soiled areas.
- **Control Methods:** Control your DEEBOT using the ECOVACS HOME app for scheduling, mode selection, and monitoring. Voice control is also available through Amazon Alexa or Google Assistant by linking your ECOVACS account.
- **Stair Safety:** The DEEBOT is equipped with anti-drop sensors to detect stairs and avoid falling. Ensure sensors are clean for proper function.



Figure 3: This image displays both the top and bottom views of the DEEBOT OZMO U2, highlighting its main brush, side brushes, and mop pad attachment. A smartphone showing the ECOVACS HOME app is also visible, illustrating the integrated control system.

Maintenance

Regular maintenance ensures your DEEBOT OZMO U2 operates efficiently and extends its lifespan.

- **Emptying the Dust Bin:** The dust bin capacity is 400ml. It should be emptied regularly, ideally after each cleaning cycle, especially in homes with pets. Press the release button to remove the dust bin, open it, and discard collected debris.
- **Cleaning the Main Brush:** Remove the main brush cover and then the main brush. Use the cleaning tool provided to cut and remove any hair or debris tangled around the brush. Reinstall the brush and cover securely.
- **Cleaning Side Brushes:** Periodically check the side brushes for tangled hair or debris. Gently pull them off to clean and reattach. Replace worn brushes as needed.
- **Cleaning Sensors:** Wipe the anti-drop sensors (located on the bottom of the robot) and the bumper sensors (on the front bumper) with a clean, dry cloth. Keep them free of dust and dirt to ensure proper navigation and safety.
- **Cleaning the Mop Pad and Water Reservoir:** After mopping, remove the mop pad and wash it thoroughly. Empty any remaining water from the reservoir and allow it to air dry to prevent mold or odors.



Figure 4: A side view of the DEEBOT OZMO U2, illustrating the integrated dustbin and the water reservoir for mopping. This view highlights the compact design that allows for both vacuuming and mopping functions.

Troubleshooting

If you encounter issues with your DEEBOT OZMO U2, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
DEEBOT does not turn on or charge.	Not properly placed on charging dock; power adapter not connected; battery depleted.	Ensure DEEBOT is correctly aligned with charging pins. Check power adapter connection to dock and wall outlet. Allow DEEBOT to charge for several hours.
DEEBOT gets stuck or navigates erratically.	Sensors are dirty; obstacles in cleaning path; robot is on a dark surface.	Clean all sensors with a dry cloth. Remove cables, toys, or other obstacles. Dark surfaces may trigger anti-drop sensors; consider using virtual boundaries if available.
Poor cleaning performance.	Dust bin full; brushes tangled; filter clogged.	Empty the dust bin. Clean the main brush and side brushes. Clean or replace the filter.
App connection issues.	Incorrect Wi-Fi password; router too far; network interference.	Verify Wi-Fi password. Move DEEBOT closer to the router. Restart router and DEEBOT. Ensure you are connecting to a 2.4GHz Wi-Fi network.

Specifications

Key technical specifications for the ECOVACS DEEBOT OZMO U2.

Feature	Specification
Brand	ECOVACS
Model Number	DEEBOT U2
Color	Black
Product Dimensions (L x W x H)	13.35" x 13.27" x 3.11" (337 x 339 x 79 mm)

Feature	Specification
Item Weight	11.68 pounds
Battery Type	Li-ion 2600mAh
Working Time	110 minutes
Charging Time	4.5 hours
Rated Power	26 W
Working Voltage	14.4 V
Dust Bin Capacity	400 ml
Control Method	Voice, App
Compatible Devices	Amazon Echo (Alexa), Google Assistant
Navigation Type	Random + Hard Floor Mode
Filter Type	Cloth

Support

For further assistance or if issues persist, please refer to the ECOVACS official support channels. The ECOVACS HOME app often provides direct access to customer service and detailed troubleshooting guides. Keep your product's model number and purchase information ready when contacting support.