

Hishine SWING-110-BLUE

Hishine 43-inch Saucer Tree Swing Instruction Manual

Model: SWING-110-BLUE

INTRODUCTION

This manual provides essential information for the safe assembly, installation, operation, and maintenance of your Hishine 43-inch Saucer Tree Swing. Please read all instructions carefully before use to ensure proper function and safety. Retain this manual for future reference.

SAFETY INFORMATION

Your safety and the safety of others are paramount. Failure to follow these instructions may result in serious injury. Always supervise children during use.

- **Weight Limit:** The swing is designed to support a maximum of 220 pounds (100 kg). Do not exceed this weight limit.
- **Age Recommendation:** Suitable for children under adult supervision.
- **Installation Surface:** Install the swing over a soft, level surface such as grass, sand, or wood chips. Avoid concrete or asphalt surfaces.
- **Clearance:** Ensure adequate clearance around the swing. Maintain a minimum of 6 feet (1.8 meters) from walls, fences, and other obstacles.
- **Regular Inspection:** Before each use, inspect all components for wear, damage, or loose connections. Do not use if any part is compromised.
- **Weather Conditions:** Avoid using the swing during strong winds, rain, or other adverse weather conditions.
- **Tree Attachment:** When attaching to a tree, ensure the branch is healthy, strong, and at least 8 inches (20 cm) in diameter. Use tree protector straps to prevent damage to the tree bark.

PART LIST

Before assembly, verify that all components are present and undamaged. Refer to the image below for identification.



Image: Components included with the Hishine 43-inch Saucer Tree Swing. This includes the heavy-duty fabric seat, foam-padded steel tubes, adjustable ropes, carabiners, swivel hook, and hanging straps.

1. Heavy-Duty Fabric Seat (1)
2. Foam-Padded Steel Tubes (4)
3. Adjustable Ropes (2)
4. Carabiners (2)
5. Swivel Hook (1)
6. Hanging Straps (2)

SETUP AND INSTALLATION

Follow these steps for proper assembly and installation of your saucer tree swing.

1. Assembling the Swing Frame

1. Unpack all components and lay them out on a clean, flat surface.
2. Connect the four foam-padded steel tubes to form a circular frame. The tubes feature metal clip buttons for secure connection. Ensure each button snaps firmly into place.
3. Insert the assembled circular frame into the fabric seat's perimeter sleeves.
4. Secure the fabric seat to the frame using the integrated fasteners (e.g., Velcro straps or clips) to ensure a taut and stable surface.



Image: Close-up view of the swing's construction, highlighting strong plastic connectors, Textilene fabric, and metal clip buttons for secure assembly.

2. Attaching the Ropes

1. Locate the four attachment points on the fabric seat.
2. Thread each adjustable rope through the designated loops on the swing frame.
3. Securely fasten the ropes to the frame using the integrated plastic connectors at the rope ends. Ensure these connectors are fully engaged.

3. Adjusting Rope Length

The ropes can be adjusted from 44 inches to 91 inches (110 cm to 231 cm) to suit your installation height.



Image: Step-by-step guide illustrating how to adjust the length of the swing ropes by looping and securing them through the metal rings.

1. To adjust the rope length, manipulate the rope through the metal ring as shown in the diagram.
2. Pull the rope to the desired length, ensuring both ropes are adjusted evenly to keep the swing level.
3. Double-check that the rope is securely looped and tightened around the ring to prevent slippage during use.

4. Hanging the Swing

The swing offers two primary hanging options: two-point suspension for back-and-forth swinging, or single-point suspension with a swivel for 360-degree rotation.



Image: Diagram illustrating the two hanging configurations: 360-degree free rotation using a single swivel point, and traditional back-and-forth swinging using two suspension points.

- **Two-Point Suspension:** Attach each of the two adjustable ropes directly to separate hanging points (e.g., a swing set frame or two sturdy tree branches) using the provided carabiners and hanging straps. Ensure the hanging points are parallel and spaced appropriately for stable swinging.
- **Single-Point Suspension (with Swivel):** Connect both adjustable ropes to the included swivel hook using the carabiners. Then, attach the swivel hook to a single sturdy hanging point (e.g., a tree branch or a single swing set hook) using a hanging strap. This allows for 360-degree rotation.

Important Note on Hanging Straps: When using hanging straps on a tree, wrap a loop around the strap to secure it and prevent excessive abrasion. Regularly inspect straps for wear, especially when used on rough surfaces like tree branches.

OPERATING INSTRUCTIONS

Once installed, the Hishine Saucer Tree Swing provides a versatile play experience.

- **Seating:** The large 43-inch seat can accommodate multiple children or adults, up to the 220-pound weight limit. Ensure users are seated centrally and evenly distributed.

- **Swinging Motion:** For back-and-forth swinging, gently push the swing. For 360-degree rotation, apply a rotational force.
- **Supervision:** Always ensure children are supervised by an adult during play.



Image: An adult and child sitting on the Hishine Saucer Tree Swing, illustrating its capacity and the stated weight limit of 220 lbs (100 kg).

MAINTENANCE

Regular maintenance will extend the life of your swing and ensure continued safety.

- **Cleaning:** The Textilene fabric seat is waterproof and easy to clean. Wipe down with a damp cloth and mild soap as needed. Rinse thoroughly and allow to air dry.
- **Inspection:** Periodically check all ropes, straps, carabiners, and the swivel for signs of wear, fraying, rust, or damage. Ensure all connections are tight and secure.
- **Frame:** The galvanized steel frame is anti-rust and weather-resistant. Inspect for any signs of corrosion or structural compromise.
- **Storage:** During prolonged periods of non-use or harsh weather conditions (e.g., winter), it is recommended to disassemble and store the swing indoors to protect it from elements and extend its

lifespan.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- Swing Sags Excessively:**
Cause: Ropes may not be adjusted evenly or the weight limit is exceeded.
Solution: Re-adjust ropes to ensure even tension. Verify that the total weight on the swing does not exceed 220 pounds.
- Squeaking Noise During Use:**
Cause: Friction at connection points or the swivel.
Solution: Apply a small amount of silicone-based lubricant to the carabiners and swivel mechanism. Ensure ropes are not rubbing against the hanging structure.
- Ropes or Straps Showing Wear:**
Cause: Prolonged exposure to elements, friction, or exceeding weight limits.
Solution: Immediately discontinue use. Replace worn or damaged ropes/straps with genuine Hishine replacement parts. Regular inspection can prevent this.
- Difficulty Assembling Frame:**
Cause: Metal clip buttons not fully engaged.
Solution: Ensure each steel tube is fully inserted and the metal clip button snaps securely into the corresponding hole. Some force may be required.

SPECIFICATIONS

Brand	Hishine
Model Number	SWING-110-BLUE
Product Dimensions	91"D x 43"W x 43"H (Installed)
Seat Depth	43 inches
Frame Material	Galvanized Steel
Seat Material	Textilene Fabric
Weight Capacity	220 pounds (100 kg)
Adjustable Rope Length	44" - 91" (110 cm - 231 cm)
Item Weight	9.5 pounds
Assembly Required	Yes

WARRANTY AND SUPPORT

Hishine is committed to providing quality products and customer satisfaction.

- Replacement Parts:** Hishine offers lifetime replacement parts for this product.
- Customer Service:** For any product-related issues, questions, or to request spare parts, please contact Hishine customer service through the Amazon messaging system for prompt assistance.

- **Returns:** Prepaid return labels and full refunds are guaranteed for returns, subject to Amazon's return policy.