



Manuals.plus /

› [Lenovo](#) /

› [Lenovo Ideapad 5 Pro User Manual](#)

Lenovo Ideapad 5 Pro

Lenovo Ideapad 5 Pro 16" Laptop User Manual

Model: Ideapad 5 Pro | Brand: Lenovo

PRODUCT OVERVIEW

The Lenovo Ideapad 5 Pro 16" is a high-performance laptop designed for productivity and entertainment. It features a stunning 2.5K QHD IPS display, powered by an AMD Ryzen 5 5600H processor and AMD Radeon RX Vega6 graphics. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.

Key Features

- Up to 8GB high-bandwidth DDR4 RAM for smooth multitasking.
- Up to 1024GB SSD for fast bootup and ample storage.
- AMD Ryzen 5 5600H 6-Core Processor (3.3 GHz to 4.2 GHz) for powerful performance.
- 16-inch 2.5K QHD (2560x1600) IPS Anti-glare display with 60Hz refresh rate and 100% sRGB.
- Integrated AMD Radeon RX Vega6 Graphics.
- 75WH 4-cell Lithium Polymer battery for extended use.
- Bluetooth 5 and 802.11ax Wi-Fi for robust connectivity.
- Backlit Keyboard for comfortable typing in various lighting conditions.
- Pre-installed Windows 11 Home operating system.

Package Contents

- Lenovo Ideapad 5 Pro 16" Laptop
- Power Adapter
- USB 3.0 Hub
- Quick Start Guide (refer to this manual for detailed instructions)

INITIAL SETUP

Follow these steps to set up your new Lenovo Ideapad 5 Pro laptop for the first time.

1. **Unpack the Laptop:** Carefully remove the laptop and all accessories from the packaging. Ensure all components listed in the "Package Contents" section are present.
2. **Connect Power:** Connect the power adapter to the laptop's power port and then plug it into a wall outlet. It is recommended to fully charge the battery before first use.
3. **First Boot:** Open the laptop lid. The laptop may power on automatically, or you may need to press the power button (usually located on the side or top right of the keyboard).
4. **Windows Setup:** Follow the on-screen instructions to complete the Windows 11 Home setup process. This includes selecting your region, language, connecting to a Wi-Fi network, and creating a user account.
5. **Install Updates:** After initial setup, connect to the internet and check for Windows updates to ensure your system has the latest security patches and features.



Image: The Lenovo Ideapad 5 Pro laptop, open and displaying the Windows 11 operating system desktop. This shows the sleek design and the vibrant display.

OPERATING YOUR LENOVO IDEAPAD 5 PRO

Power Management

- **Power On/Off:** Press the power button to turn the laptop on. To turn off, click the Start button in Windows, then Power > Shut down.
- **Sleep Mode:** Close the lid or select Sleep from the Power menu to put the laptop into sleep mode, conserving battery while keeping your work open.
- **Battery Life:** The laptop features a 75WH 4-cell Lithium Polymer battery. Battery life varies based on usage. Adjust screen brightness and close unused applications to extend battery life.

Keyboard and Touchpad

- **Backlit Keyboard:** Press **Fn + Spacebar** to cycle through backlight brightness levels (off, low, high).
- **Function Keys:** Use the **Fn** key in combination with the F1-F12 keys for various functions like volume control, screen brightness, and Wi-Fi toggle.
- **Touchpad:** The precision touchpad supports multi-touch gestures for navigation. Refer to Windows settings for customization options.

Connecting Peripherals

Your Ideapad 5 Pro comes with a variety of ports for connecting external devices.

- **USB 3.0 Ports:** Connect USB devices such as external hard drives, mice, or keyboards. The included USB 3.0 Hub expands your connectivity options.
- **USB Type-C Ports:** Versatile ports for data transfer, power delivery, and display output (depending on specific port capabilities).
- **HDMI Port:** Connect to external monitors or projectors for a larger display.
- **Headphone/Speaker/Line-Out Jack:** Connect headphones or external speakers.



Image: Left side of the laptop, displaying USB-C, HDMI, and audio jack ports.



Image: Right side of the laptop, displaying USB 3.0 ports and an SD card reader slot.



Image: The Lenovo Ideapad 5 Pro laptop shown alongside the included USB 3.0 Hub, illustrating the expanded connectivity.

MAINTENANCE AND CARE

Proper care and maintenance will ensure the longevity and optimal performance of your laptop.

- **Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a screen cleaner to clean the display. For the keyboard and chassis, use a soft, dry cloth. Avoid harsh chemicals.
- **Battery Care:** To prolong battery life, avoid extreme temperatures. If storing the laptop for an extended period, ensure the battery is charged to about 50-60%.
- **Software Updates:** Regularly check for and install Windows updates and driver updates from the Lenovo support website to ensure system stability and security.
- **Ventilation:** Ensure the laptop's ventilation openings are not blocked to prevent overheating. Use the laptop on a hard, flat surface.

TROUBLESHOOTING COMMON ISSUES

This section provides solutions to common problems you might encounter.

Problem	Possible Cause	Solution
Laptop does not power on.	Battery drained, power adapter issue, or hardware fault.	Ensure power adapter is securely connected and wall outlet is working. Try a different outlet. If battery is completely drained, allow it to charge for a few minutes before attempting to power on.
Wi-Fi connection issues.	Wi-Fi disabled, incorrect password, router issue, or driver problem.	Check if Wi-Fi is enabled in Windows settings. Verify Wi-Fi password. Restart your router and modem. Update Wi-Fi drivers from Lenovo support website.
Screen is dim or black.	Brightness setting, display cable issue (if external), or sleep mode.	Press Fn + F5/F6 (brightness keys) to adjust brightness. Press any key or move the mouse to wake from sleep. If connected to an external monitor, ensure the cable is secure.
Laptop is running slow.	Too many applications open, low storage, or malware.	Close unnecessary applications. Free up disk space. Run a full system scan for malware. Check for and install Windows updates.

TECHNICAL SPECIFICATIONS

Detailed specifications for the Lenovo Ideapad 5 Pro 16" Laptop.

Feature	Specification
Model Name	Ideapad 5 Pro
Processor	AMD Ryzen 5 5600H (6 Cores, 12 Threads, 3.3 GHz base, up to 4.2 GHz max boost)
Graphics	AMD Radeon RX Vega6 Graphics
Display	16" 2.5K QHD (2560 x 1440) IPS, Anti-glare, 60Hz, 100% sRGB
RAM	8GB DDR4 SDRAM
Storage	512GB SSD
Operating System	Windows 11 Home
Wireless Connectivity	802.11ax Wi-Fi, Bluetooth 5
Ports	2 x USB 3.0, 1 x USB Type-C, 1 x HDMI, 1 x Headphone/Speaker/Line-Out Jack
Battery	75WH 4-cell Lithium Polymer (Approx. 8 hours average battery life)
Dimensions (L x W x H)	14.26 x 9.98 x 0.78 inches
Weight	3.74 pounds
Color	Storm Gray / Black

WARRANTY AND SUPPORT

Your Lenovo Ideapad 5 Pro laptop comes with a standard manufacturer's warranty. Please refer to the warranty card included with your product or visit the official Lenovo support website for detailed warranty terms and conditions specific to your region.

For technical assistance, driver downloads, or further support, please visit the official Lenovo Support website:

support.lenovo.com

When contacting support, please have your laptop's serial number ready. The serial number is typically located on a sticker on the bottom of the laptop or can be found in the system information within Windows.