

Elgin 42AFR2001000

Elgin Cuisine Fry Gourmet 5.5L Air Fryer 110V Instruction Manual

Model: 42AFR2001000

IMPORTANT SAFETY INFORMATION

Please read this manual carefully before using the appliance. Keep it for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is connected to a grounded power outlet with the correct voltage (110V for this model).
- Do not immerse the main unit, cord, or plug in water or any other liquid.
- Supervise children closely when the appliance is in use.
- Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- Keep the appliance and its cord out of reach of children.
- Do not block the air intake or outlet vents during operation.
- Do not place the appliance against a wall or other appliances. Leave at least 10 cm (4 inches) free space on the back and sides and 10 cm (4 inches) free space above the appliance.
- Do not place anything on top of the appliance.
- Use only original accessories and parts.
- Unplug the appliance from the outlet when not in use and before cleaning. Allow it to cool down completely before handling.
- The appliance operates at high temperatures. Be careful when handling hot surfaces and components.
- This appliance is intended for household use only.

PRODUCT OVERVIEW

The Elgin Cuisine Fry Gourmet Air Fryer is designed for oil-free frying, roasting, and grilling, offering a healthier way to prepare your favorite foods. It features a 5.5-liter capacity, 1700W power, and a rapid air circulation system for efficient cooking.

Components

- Main Fryer Body
- Fryer Bowl (removable)
- Frying Tray with 4 rubber locks (removable, non-stick)
- Temperature Control Dial
- Timer Dial
- Power Indicator Light
- Heating Indicator Light
- Cool-Touch Handle
- Air Intake and Outlet Vents
- Non-slip Base

Fritadeira Elétrica Cuisine Fry Gourmet Preta 220V

3 em 1 Frita, Assa e Gratina



elgin

Figure 1: Front view of the Elgin Cuisine Fry Gourmet Air Fryer, showing the control dials and handle.

Dimensões



Figure 2: Dimensions of the Elgin Cuisine Fry Gourmet Air Fryer, indicating its compact size.

SETUP AND FIRST USE

1. **Unpacking:** Carefully remove all packaging materials and promotional labels. Keep packaging for storage or disposal.
2. **Cleaning:** Before first use, clean the fryer bowl and frying tray with hot water, dish soap, and a non-abrasive sponge. Wipe the main unit with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Placement:** Place the air fryer on a stable, heat-resistant, and level surface. Ensure there is at least 10 cm (4 inches) of clear space around the appliance for proper ventilation.
4. **Power Connection:** Plug the power cord into a grounded 110V electrical outlet.
5. **Initial Run (Optional but Recommended):** To eliminate any manufacturing odors, run the air fryer empty for about 10-15 minutes at 180°C (356°F). Ensure the area is well-ventilated during this process.

OPERATING INSTRUCTIONS

General Operation

1. **Prepare Food:** Place the food you wish to cook into the frying basket. Do not overfill the basket to allow for proper air circulation.
2. **Insert Basket:** Slide the frying basket back into the main unit until it clicks securely into place.
3. **Set Temperature:** Turn the temperature control dial to your desired cooking temperature, ranging from 80°C to 200°C (176°F to 392°F).
4. **Set Timer:** Turn the timer dial to the required cooking time, up to 60 minutes. The appliance will automatically start heating. The power indicator light and heating indicator light will illuminate.
5. **Cooking Process:** During cooking, the heating indicator light may turn on and off, indicating that the appliance is maintaining the set temperature.
6. **Shaking/Turning Food:** For even cooking, especially for smaller items, pull out the basket halfway through the cooking time and gently shake or turn the food. Then, slide the basket back in. The air fryer will resume cooking.
7. **Completion:** When the timer reaches zero, an audible alert will sound, and the appliance will automatically shut off. The power indicator light will turn off.
8. **Remove Food:** Carefully pull out the frying basket using the cool-touch handle. Place it on a heat-resistant surface. Use tongs to remove the cooked food.
9. **Cool Down:** Allow the appliance to cool down completely before cleaning or storing.

Fácil de limpar e pode
ir na lava louças



Figure 3: Close-up of the control panel, showing the temperature and timer dials for setting cooking parameters.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool down completely before cleaning.
2. **Clean Fryer Bowl and Tray:** The removable frying basket and tray are non-stick and dishwasher safe. For manual cleaning, use hot water, dish soap, and a non-abrasive sponge. Do not use metal scouring pads or harsh abrasive cleaners.

3. **Clean Interior:** Wipe the interior of the appliance with a damp cloth. For stubborn food residue, use a mild detergent.
4. **Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners.
5. **Heating Element:** If necessary, gently clean the heating element with a soft brush to remove any food particles.
6. **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.



Figure 4: Illustration highlighting the removable, easy-to-clean basket and non-stick grill.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; Timer not set; Basket not fully inserted.	Ensure the power cord is securely plugged into a 110V outlet. Set the timer. Push the frying basket firmly until it clicks into place.
Food is not cooked evenly.	Basket is overfilled; Food not shaken/turned.	Do not overfill the basket. Shake or turn food halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; Fatty ingredients.	Clean the basket and tray thoroughly after each use. For fatty foods, absorb excess oil before cooking.
Appliance smells during first use.	New appliance odor.	This is normal. Run the air fryer empty for 10-15 minutes at 180°C in a well-ventilated area. The smell will dissipate.
Food is not crispy.	Too much moisture in food; Not enough oil (for certain recipes).	Pat food dry before cooking. For some recipes, a light spray of oil can help achieve crispiness.

SPECIFICATIONS

Brand: Elgin

Model: 42AFR2001000 (CT120)

Color: Black

Capacity: 5.5 Liters

Power: 1700 Watts

Voltage: 110 Volts

Temperature Control: 80°C - 200°C (176°F - 392°F)

Timer: Up to 60 minutes with automatic shut-off and audible alert

Special Features: Overheat protection, non-stick removable basket, ultra-fast air circulation system, cool-touch handle, non-slip base.

Product Dimensions: 35 cm (D) x 37.4 cm (W) x 29 cm (H)

Weight: 4.82 kg

EAN: 7908412506987

WARRANTY AND SUPPORT

This Elgin Cuisine Fry Gourmet Air Fryer comes with a **1-year express warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims. For technical assistance, warranty claims, or further inquiries, please contact Elgin customer support. Refer to the official Elgin website or your purchase documentation for contact details.

Manufacturer: ELGIN