



Manuals.plus /

› Necchi /

› Necchi NK8021 Air Fryer User Manual

## Necchi NK8021

# Necchi NK8021 Air Fryer User Manual

Model: NK8021 | Brand: Necchi

## IMPORTANT SAFETY INSTRUCTIONS

---

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully before using the appliance.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure adequate ventilation around the appliance during use.

## PRODUCT OVERVIEW

---

The Necchi NK8021 Air Fryer is designed for healthy cooking with rapid air circulation technology. Familiarize yourself with its components before use.



Image 1: Front view of the Necchi NK8021 Air Fryer, showing the red exterior, black top, and digital display with touch controls.



Image 2: Angled view of the Necchi NK8021 Air Fryer, highlighting its compact design and handle.

### Components:

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** Digital touch screen for setting temperature and time.
- **Frying Basket:** Non-stick, removable basket for holding food.
- **Food Tray/Grille:** Anti-adhesive tray inside the basket.
- **Handle:** For safely pulling out and inserting the frying basket.

### SETUP

---

1. **Unpack:** Remove all packaging materials, stickers, and labels from the appliance.
2. **Clean Components:** Wash the frying basket and food tray thoroughly with hot water, dish soap, and a non-abrasive sponge. Rinse and dry completely. Wipe the inside and outside of the main unit with a damp cloth.
3. **Placement:** Place the appliance on a stable, horizontal, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of free space on the back and sides, and above the appliance, to allow for proper air circulation.
4. **First Use (Burn-in):** It is recommended to run the air fryer empty for about 10-15 minutes at 180°C (350°F) before first use to eliminate any manufacturing odors. A slight smell or smoke may occur, which is normal. Ensure the area

is well-ventilated.

## OPERATING INSTRUCTIONS

---

Follow these steps for safe and effective operation of your Necchi NK8021 Air Fryer.

- 1. Plug In:** Insert the main plug into a grounded wall socket. The appliance will beep, and the digital display will illuminate briefly.
- 2. Prepare Food:** Place the ingredients into the frying basket. Do not overfill the basket beyond the MAX indication.
- 3. Insert Basket:** Slide the frying basket back into the main unit. Ensure it clicks securely into place.
- 4. Set Temperature and Time:**
  - Use the temperature control buttons (usually '+' and '-') to set the desired cooking temperature between 80°C and 200°C.
  - Use the timer control buttons (usually '+' and '-') to set the desired cooking time, up to 30 minutes.
- 5. Start Cooking:** Press the start/pause button (often a power icon or play icon) to begin the cooking process. The fan and heating element will activate.
- 6. Shake Basket (Optional):** For some foods, it may be necessary to shake the ingredients halfway through the cooking time to ensure even cooking. Carefully pull out the basket by its handle, shake it, and then slide it back into the appliance. The air fryer will resume cooking automatically.
- 7. Cooking Completion:** When the set cooking time has elapsed, the appliance will beep, and the heating element will turn off. The fan may continue to run for a short period to cool down the unit.
- 8. Remove Food:** Carefully pull out the frying basket. Use heat-resistant tongs to remove the cooked food from the basket. Do not tip the basket directly to avoid dripping excess oil from the bottom of the pan onto the food.
- 9. Unplug:** After use, unplug the appliance from the wall socket.



*Image 3: The Necchi NK8021 Air Fryer with its basket partially pulled out, showing a batch of fries ready for cooking or already cooked.*

## MAINTENANCE AND CLEANING

---

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool down completely before cleaning.
2. **Clean Basket and Tray:**
  - Remove the frying basket and food tray.
  - Wash them in hot water with a mild dishwashing liquid and a non-abrasive sponge. The non-stick coating allows for easy cleaning.
  - For stubborn food residues, soak the basket and tray in hot water with dish soap for about 10 minutes before cleaning.
  - Rinse thoroughly and dry completely before reassembling.
3. **Clean Interior:** Wipe the inside of the appliance with a damp cloth. Avoid using abrasive cleaners or metal scouring

pads.

- Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth. Do not use harsh chemicals or abrasive materials.
- Heating Element:** If necessary, gently clean the heating element with a cleaning brush to remove any food residues. Ensure the appliance is unplugged and completely cool.
- Storage:** Store the cleaned and dried air fryer in a cool, dry place.

## TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
The air fryer does not turn on.	The appliance is not plugged in. The basket is not inserted correctly.	Ensure the power plug is securely inserted into a grounded wall socket. Push the frying basket into the main unit until it clicks into place.
Food is not cooked evenly.	Too much food in the basket. Food not shaken during cooking.	Reduce the amount of food per batch. Shake the basket halfway through cooking for even results.
Food is not crispy.	Temperature too low or cooking time too short. Certain foods require a light oil coating.	Increase the temperature or cooking time. Lightly brush or spray food with oil before air frying.
White smoke comes out of the appliance.	Fat residues from previous use. Excess oil from fatty ingredients.	Clean the basket and pan thoroughly after each use. Remove excess oil from fatty foods before cooking.

## SPECIFICATIONS

<b>Model</b>	NK8021
<b>Brand</b>	Necchi
<b>Power</b>	1500 Watts
<b>Capacity</b>	4.6 Liters
<b>Voltage</b>	230 Volts
<b>Temperature Control</b>	80-200°C
<b>Timer</b>	Up to 30 minutes
<b>Material</b>	Metal (non-stick coating on basket/tray)
<b>Automatic Shut-off</b>	Yes
<b>Weight</b>	5 Kilograms
<b>Dimensions (Package)</b>	35.4 x 32.6 x 32.2 cm

## WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries regarding your Necchi NK8021 Air Fryer, please refer to the warranty card included with your purchase or contact Necchi customer service directly. Contact details can typically be found on the official Necchi website or on the product packaging.

Please have your model number (NK8021) and proof of purchase ready when contacting support.

