



Manuals.plus /

› Skirfy /

› Skirfy Shaking Swing Balls Game Set Instruction Manual

Skirfy B09QPD59FH

Skirfy Shaking Swing Balls Game Set Instruction Manual

Model: B09QPD59FH

INTRODUCTION

The Skirfy Shaking Swing Balls Game Set is designed for active fun for both children and adults. This manual provides essential information for setting up, operating, and maintaining your game set to ensure a safe and enjoyable experience.

PRODUCT COMPONENTS

Before assembly, please ensure all components are present and undamaged. The package typically includes:

- Shaking ball containers (typically two, red and blue)
- Adjustable belts
- Small plastic balls (approx. 40)
- Instruction manual



Figure 1: Overview of the Skirfy Shaking Swing Balls Game Set components.

SETUP INSTRUCTIONS

1. **Attach the Belt:** Thread the adjustable belt through the loops on the back of the shaking ball container. Ensure the buckle is facing outwards for easy fastening.
2. **Secure to Waist:** Fasten the belt around the player's waist. Adjust the strap to ensure a snug but comfortable fit. The container should rest securely on the lower back.
3. **Fill with Balls:** Open the top of the container and fill it with the provided plastic balls. The number of balls can be adjusted to vary game difficulty.



Figure 2: Detail of belt attachment and hole size adjustment on the game container.

OPERATING THE GAME

The objective of the game is to shake all the balls out of your container as quickly as possible using body movements without using your hands. Here's how to play:

1. Each player wears a filled shaking ball container around their waist.
2. On a signal, players begin to shake, twist, and jump to dislodge the balls from their container.
3. The first player to empty their container wins the round.
4. Encourage creative movements like jumping, twisting, and wiggling to enhance the fun and physical activity.



Figure 3: Family enjoying the Shaking Swing Balls game.



Figure 4: Players demonstrating various movements to play the game.

Video 1: Demonstration of the Skirfy Shaking Swing Balls game in action, showing players actively shaking to release balls.

SAFETY INFORMATION

For external use only. Ensure adequate space for playing to avoid collisions. Supervise young children during play. The game is recommended for ages 6 years and up.

MAINTENANCE

- **Cleaning:** Wipe the plastic containers and balls with a damp cloth and mild soap if necessary. Ensure all parts are dry before storage.
- **Storage:** Store the game set in a cool, dry place away from direct sunlight to prevent material degradation.
- **Inspection:** Periodically check the belts and containers for any signs of wear or damage. Discontinue use if any part

is broken or compromised.

TROUBLESHOOTING

- **Balls not coming out easily:** Ensure the container is not overfilled. Adjust the hole size if applicable (refer to Figure 2). Encourage more vigorous or varied body movements.
- **Belt slipping:** Tighten the adjustable belt to ensure a snug fit around the waist.
- **Missing parts:** If any components are missing upon arrival, please contact Skirfy customer support immediately.

SPECIFICATIONS

Feature	Detail
Product Dimensions	9.25 x 9.57 x 4.09 inches
Item Weight	1.32 ounces
Recommended Age	6 years and up
Material	ABS material (for shaking ball set)
Players	2+ players

WARRANTY AND SUPPORT

For warranty information or customer support, please contact Skirfy Toy directly. You can visit the official Skirfy Store on Amazon for more product details and contact options:

Visit the Skirfy Store

