

Casio GA-2100

Casio GA-2100-1A2ER Watch User Manual

Model: GA-2100-1A2ER

1. INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your Casio GA-2100-1A2ER watch. Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your timepiece. The GA-2100 series combines a slim profile with the renowned G-SHOCK toughness, featuring a Carbon Core Guard structure.



Figure 1: Front view of the Casio GA-2100-1A2ER watch, showcasing its analog-digital display and octagonal bezel.

Package Contents

- Casio GA-2100-1A2ER Watch
- User Manual (this document)
- Warranty Card (may be separate)

2. INITIAL SETUP

Before using your watch, it is recommended to set the current time and date. The GA-2100 features both analog hands and a digital display.

2.1 Button Functions



Figure 2: Close-up view of the watch face, indicating the four main buttons: **ADJUST** (top left), **LIGHT** (top right), **MODE** (bottom left), and **START** (bottom right).

- **ADJUST (A)**: Used to enter and exit setting modes, and to confirm selections.
- **LIGHT (B)**: Activates the LED backlight. In setting modes, it can be used to change values.
- **MODE (C)**: Cycles through the watch's various modes (Timekeeping, Stopwatch, Timer, Alarm, World Time).
- **START (D)**: Used to start/stop stopwatch/timer, and to change values in setting modes.

2.2 Setting the Time and Date

1. In Timekeeping Mode, hold down the **ADJUST (A)** button for approximately two seconds until the city code starts to flash. This indicates you are in the setting mode.
2. Press the **MODE (C)** button to cycle through the settings: City Code → DST (Daylight Saving Time) → 12/24-hour format → Seconds → Hour → Minute → Year → Month → Day.
3. Use the **LIGHT (B)** and **START (D)** buttons to change the flashing value. **LIGHT (B)** typically decreases the value, and **START (D)** increases it.
4. Once all settings are configured, press the **ADJUST (A)** button to exit the setting mode. The digital display will return to the Timekeeping Mode.

The analog hands will automatically adjust to match the digital time setting.

2.3 Hand Home Position Correction

If the analog hands do not match the digital time, you may need to correct their home positions.

1. In Timekeeping Mode, hold down the **ADJUST (A)** button for approximately five seconds until "H.SET" appears on the digital display, and the hour and minute hands move to the 12 o'clock position.
2. If the hands are not at 12 o'clock, use the **LIGHT (B)** and **START (D)** buttons to adjust them.
3. Press **ADJUST (A)** to confirm and exit.

3. OPERATING MODES

Press the **MODE (C)** button to cycle through the watch's various functions:

- **Timekeeping Mode:** Displays the current time and date.
- **Stopwatch Mode (STW):** Measures elapsed time.
- **Timer Mode (TMR):** Counts down from a preset time.
- **Alarm Mode (ALM):** Sets daily alarms.
- **World Time Mode (WT):** Displays the current time in 48 cities (31 time zones).

3.1 Stopwatch Mode

1. From Timekeeping Mode, press **MODE (C)** until "STW" appears.
2. Press **START (D)** to start the stopwatch.
3. Press **START (D)** again to stop.
4. Press **ADJUST (A)** to reset the stopwatch to zero.

3.2 Timer Mode

1. From Timekeeping Mode, press **MODE (C)** until "TMR" appears.
2. Hold down **ADJUST (A)** until the timer setting starts to flash.
3. Use **LIGHT (B)** and **START (D)** to set the desired countdown time.
4. Press **ADJUST (A)** to confirm the setting.
5. Press **START (D)** to begin the countdown.
6. Press **START (D)** again to pause/resume.
7. When paused, press **ADJUST (A)** to reset the timer.

3.3 Alarm Mode

1. From Timekeeping Mode, press **MODE (C)** until "ALM" appears.
2. Press **MODE (C)** to cycle through the alarms (AL1, AL2, AL3, AL4, AL5, SNZ, SIG).
3. Hold down **ADJUST (A)** on the desired alarm until the hour setting flashes.
4. Use **LIGHT (B)** and **START (D)** to set the alarm hour and minute.
5. Press **ADJUST (A)** to confirm the alarm setting.
6. To turn an alarm ON/OFF, press **START (D)** while the alarm is displayed (not in setting mode).
7. "SNZ" is the Snooze alarm, and "SIG" is the Hourly Time Signal.

3.4 World Time Mode

1. From Timekeeping Mode, press **MODE (C)** until "WT" appears.
2. Use **START (D)** to scroll through the different city codes/time zones.
3. The digital display will show the current time for the selected city.

3.5 Illumination (Light)

Press the **LIGHT (B)** button to illuminate the watch face for easy viewing in low-light conditions. The illumination duration can typically be adjusted in the Timekeeping Mode settings.

4. MAINTENANCE

4.1 Water Resistance

The Casio GA-2100-1A2ER watch is water-resistant to 20 BAR (200 meters). This means it is suitable for showering, swimming, and diving without scuba gear. Do not operate buttons while the watch is wet or submerged to prevent water ingress.



Figure 3: Rear view of the watch, displaying the "WATER RESIST 20BAR" engraving on the stainless steel case back.

4.2 Cleaning

Wipe the watch regularly with a soft, dry cloth to remove dirt and moisture. For stubborn dirt, use a soft brush with mild soap and water, then rinse thoroughly and dry. Avoid using chemical cleaners or solvents.

4.3 Battery Information

The watch is powered by 1 Lithium Metal battery, which is included. Battery life varies depending on usage, especially frequent use of the backlight and alarms. When the display becomes dim or functions become erratic, it is an indication that the battery needs replacement. Battery replacement should be performed by a qualified technician to maintain water resistance.

5. TROUBLESHOOTING

- **Incorrect Time/Date:** Ensure the correct city code is selected for your home city. Perform the "Setting the Time and Date" procedure (Section 2.2).
- **Analog Hands Do Not Match Digital Time:** Perform the "Hand Home Position Correction" procedure (Section 2.3).
- **Digital Display is Dim or Hard to Read** This can be a characteristic of negative LCD displays in certain lighting conditions. Ensure the watch is viewed at an optimal angle. If the display remains unusually dim, the battery may be low.
- **No Sound from Alarm/Hourly Signal:** Check if the MUTE function is active. In Timekeeping Mode, press **MODE** (**C**) until "MUTE" is not displayed on the digital screen. Also, ensure the alarm or hourly signal is turned ON in Alarm Mode.

6. SPECIFICATIONS

Model Number	GA-2100-1A2ER
Manufacturer	Casio
Material	Acrylic (Crystal), Resin (Case/Band)
Water Resistance	20 BAR (200 meters)
Battery Type	1 Lithium Metal battery (included)
Dimensions	(Refer to product packaging for exact dimensions)
Weight	(Refer to product packaging for exact weight)



Figure 4: Side profile of the Casio GA-2100-1A2ER watch, illustrating its slim case design.

7. WARRANTY AND SUPPORT





Your Casio watch is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details. For technical support, repairs, or further assistance, please contact Casio customer service or visit the official Casio website.

You can find more information and support resources on the official Casio website www.casio.com



© 2023 Casio Computer Co., Ltd. All rights reserved.

Related Documents - GA-2100

	<p>Casio G-Shock Watch Guide: History, Models, and Time Setting</p> <p>Explore the history and evolution of Casio G-Shock watches, discover key models like the Gravitymaster and Rangeman, and learn how to set the time on your digital or analog G-Shock timepiece.</p>
	<p>Casio LAW-21 Модуль 2789: Руководство пользователя и характеристики</p> <p>Полное руководство пользователя для часов Casio LAW-21 (Модуль 2789). Содержит инструкции по эксплуатации, уходу, описания режимов работы (текущее время, мировое время, таймер, секундомер, будильник) и технические характеристики.</p>
	<p>Casio BG-2100 Digital Watch Instruction Manual - Module 3097</p> <p>Comprehensive guide for the Casio BG-2100 digital watch (Module 3097). Learn how to set time, date, alarms, use the stopwatch, and understand water resistance features. Includes manufacturer details.</p>
	<p>Руководство пользователя CASIO GW-1401</p> <p>Подробное руководство пользователя для часов CASIO GW-1401 (Модуль 3357). Узнайте о водонепроницаемости, функциях, настройке времени, будильника, секундомера, подсветки, питания и уходе за вашими часами Casio.</p>
	<p>Casio BG-2200 Watch: User Manual and Specifications</p> <p>Comprehensive guide to the Casio BG-2200 digital watch (Module 3128), detailing water resistance, time setting, stopwatch, alarm, and general operation.</p>
	<p>CASIO G-SHOCK GA-400 Watch Instruction Manual</p> <p>Comprehensive instruction manual for the CASIO G-SHOCK GA-400 watch, module 5398, covering features, operation, and maintenance. Includes details on timekeeping, alarms, stopwatch, world time, and water resistance.</p>