

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Tefal](#) /
- › [Tefal Convenient Series Deluxe Steamer User Manual](#)

## Tefal VC502D

# Tefal Convenient Series Deluxe Steamer User Manual

Model: VC502D

## INTRODUCTION

---

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Tefal Convenient Series Deluxe Steamer. Please read it thoroughly before first use and keep it for future reference.

The Tefal Convenient Series Deluxe Steamer is designed for healthy and convenient cooking, featuring a simple touch screen, 8 cooking programs, and a multi-level design for preparing various dishes simultaneously. Its durable stainless steel containers ensure quality and taste.

## PRODUCT OVERVIEW

---



Figure 1: Complete Steamer Unit with Rice Bowl. This image shows the Tefal Convenient Series Deluxe Steamer assembled with its three stainless steel steaming levels, glass lid, and the base unit. A separate rice bowl is shown next to it.



Figure 2: Front View of Steamer. This image provides a clear view of the steamer's front, highlighting the control panel and the water level indicator on the side.

## Components:

- **Base Unit:** Contains the heating element and water reservoir.
- **Water Reservoir:** For holding water for steaming.
- **Control Panel:** Digital touch screen for program selection and settings.
- **Steaming Baskets (3 levels):** Stainless steel containers for food.
- **Lid:** Glass lid to cover the top steaming basket.
- **Rice Bowl:** Accessory for cooking rice or other grains.

## SETUP

---

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wash all removable parts (steaming baskets, lid, rice bowl) with warm soapy water. Wipe the base unit with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Placement:** Place the steamer on a stable, flat, heat-resistant surface, away from walls and other appliances to allow for proper ventilation.
4. **Assembly:**
  - Place the base unit on the counter.
  - Fill the water reservoir with clean water up to the MAX fill line. Do not overfill.
  - Stack the steaming baskets onto the base unit. You can use one, two, or all three baskets depending on your cooking needs.
  - Place the lid securely on the top steaming basket.

5. **Power Connection:** Plug the power cord into a grounded electrical outlet.

## OPERATING INSTRUCTIONS

### General Operation:

- Ensure the water reservoir is filled before starting.
- Place food in the steaming baskets. For multi-level cooking, place foods requiring longer cooking times in the lower baskets.
- Close the lid securely.
- Use the digital touch screen to select one of the 8 pre-programmed settings or manually adjust cooking time.
- Press the "Start/Stop" button to begin steaming.
- The steamer will automatically shut off when the cooking cycle is complete and emit an audible signal.
- For extended cooking, the steamer can operate for up to 45 minutes without refilling the water tank. Water can be refilled during operation if needed.



Figure 3: Digital Touch Screen Control Panel. This image highlights the intuitive touch screen with program selections (P1-P8), time adjustment buttons (+/-), and the Start/Stop button.

# PLATZSPARENDE AUFBEWAHRUNG



Figure 4: Steamer in Operation. This image shows the steamer actively cooking, with steam visible and prepared food (salmon, broccoli, rice) displayed next to it, demonstrating its multi-level cooking capability.

## Cooking Programs:

The steamer features 8 pre-set programs for various food types. Refer to the downloadable recipe book for detailed guidance on specific cooking times and food preparation.

**Table 1: Example Cooking Programs (Consult recipe book for full list)**

Program No.	Food Type	Typical Cooking Time
P1	Vegetables	10-20 minutes
P2	Fish	8-15 minutes
P3	Poultry	20-30 minutes
P4	Rice	25-35 minutes

*Note: Cooking times are approximate and may vary based on food quantity, size, and desired doneness.*

### Cleaning:

- Always unplug the steamer and allow it to cool completely before cleaning.
- The stainless steel containers and lid are dishwasher-safe for easy cleaning.
- Wipe the base unit with a damp cloth. Do not immerse the base unit in water or any other liquid.
- For stubborn food residue, soak the baskets in warm soapy water before cleaning.



Figure 5: Dishwasher-Safe Components. This image illustrates the ease of cleaning, showing the stainless steel steaming baskets and other removable parts placed inside a dishwasher.

### Descaling:

Over time, mineral deposits (limescale) may build up in the water reservoir, especially in areas with hard water. Regular descaling is recommended to maintain optimal performance.

1. Mix a solution of equal parts white vinegar and water.
2. Pour the solution into the water reservoir up to the MAX fill line.
3. Run the steamer for approximately 20-30 minutes without food.
4. Unplug the steamer, allow it to cool, and then empty the reservoir.
5. Rinse the reservoir thoroughly with clean water several times to remove any vinegar odor.
6. Wipe the exterior of the base unit.

## Storage:

The steamer features a space-saving design with stackable containers for easy storage. Ensure all parts are clean and dry before storing.

# EINFACHE REINIGUNG



Figure 6: Compact Storage. This image demonstrates how the steamer's components can be stacked and stored efficiently within a kitchen cabinet, highlighting its space-saving design.

## TROUBLESHOOTING

Table 2: Troubleshooting Guide

Problem	Possible Cause	Solution
Steamer does not turn on.	Not plugged in; Power outlet issue; Unit malfunction.	Ensure power cord is securely plugged into a working outlet. Check household circuit breaker. If problem persists, contact customer support.

Problem	Possible Cause	Solution
No steam produced.	Insufficient water in reservoir; Heating element issue.	Fill water reservoir to the appropriate level. Ensure the unit is powered on and a program is selected.
Food not cooking evenly or taking too long.	Overloaded baskets; Incorrect cooking time; Limescale buildup.	Do not overload baskets; ensure food pieces are similar in size. Adjust cooking time as needed. Perform descaling if necessary.
Water leaking from base.	Overfilled reservoir; Improper assembly of baskets.	Do not fill water above the MAX line. Ensure steaming baskets are correctly seated on the base unit.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact Tefal customer support.

## SPECIFICATIONS

---

Feature	Detail
Model Number	VC502D
Power	900 W
Capacity	9 Liters
Material	Stainless Steel (baskets), Plastic (base)
Color	Stainless Steel/White
Product Dimensions (L x W x H)	12.91" x 12.91" x 12.64" (approx. 32.8 cm x 32.8 cm x 32.1 cm)
Item Weight	3.35 Kilograms (7.37 pounds)
Control Type	Digital Touch Screen
Programs	8 Pre-set Programs



Figure 7: Product Dimensions. This image provides a visual representation of the steamer's height (41 cm), width (31 cm), and depth (28 cm), aiding in understanding its physical footprint.

## WARRANTY AND SUPPORT

Tefal products are designed for durability and quality. This product is backed by a commitment to 15 years of repairability. For warranty claims, technical support, or to inquire about repairs, please visit the official Tefal website or contact their customer service department. Keep your proof of purchase for warranty validation.

### Online Resources:

- Official Tefal Website: [www.tefal.com](http://www.tefal.com)
- T-Fal Store on Amazon: [T-Fal Store](#)