

DOGNESS B09TVMDDWR

DOGNESS App Wi-Fi Control Automatic Pet Feeder Instruction Manual

Model: B09TVMDDWR

INTRODUCTION

Thank you for choosing the DOGNESS App Wi-Fi Control Automatic Pet Feeder. This device is designed to provide convenient and reliable feeding for your cat or small dog, ensuring they receive their meals on time, even when you are away. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to help you get the most out of your new feeder.



Image: The DOGNESS Automatic Pet Feeder, showcasing its design, a full food bowl, and the accompanying mobile application for remote control.

KEY FEATURES

- **Wi-Fi App Control:** Schedule feedings, adjust portions, and monitor feeding history remotely via the DOGNESS app.
- **Timed Feeding:** Dispense up to 6 meals per day with up to 15 portions per meal.
- **Voice Recorder:** Record a 10-second message to call your pet at meal times.
- **Dual Power Supply:** Operates with a power adapter and can use 3 x D batteries (not included) for backup during power outages.
- **Clog-Free Design:** Engineered to prevent food blockages.
- **Suitable for:** Cats and small dogs.

Customized Voice Recording



Image: Diagram illustrating the dual power supply capability of the feeder, highlighting both AC adapter and battery backup options.

SETUP GUIDE

1. Unpacking and Assembly


1. Carefully remove all components from the packaging.
2. Place the stainless steel food bowl into the designated slot at the base of the feeder.
3. Open the lid of the food storage compartment and ensure it is clean and dry before adding dry pet food.

2. Powering the Feeder

- **Primary Power:** Connect the power adapter to the feeder's power port and plug it into a standard wall outlet.
- **Battery Backup (Optional):** For power outage protection, insert 3 x D-size batteries (not included) into the battery compartment at the bottom of the feeder. Ensure correct polarity.


3. Connecting to the DOGNESS App

How to Connect the DOGNESS App Feeder Mini?



STEP 1: Download App

- Search and download the DOGNESS APP
- Open the App, register your account
- Log in your account



STEP 2: Add Device in the APP

- Plug in to power on the device
- Click the "+" button
- "Add manually" to find "App Feeder Mini F05"



App Feeder Mini F05

"Reset" Button



STEP 3: Connect the Feeder

- When plugged in, the light on the front of the feeder will start flashing green.
- Press and hold the "Reset" button for 6 seconds until you hear it "beep" three times.
- Enter Wifi name and password.

NOTE: Make sure your App connects to 2.4GHz wifi network during App setup (only support 2.4GHz wifi network, not compatible with 5 GHz wifi network, If the Wi-Fi router supports both 5GHz and 2.4GHz, please turn off 5GHz and keep the router only working for 2.4GHZ.)

- After successful connection, it is ready to use. If you have an issue please contact customer service at support@dogness.com



Wifi indicator light in the feeder (Green):

Slow flashing -It means that the feeder is ready to connect to wifi (Configurable status);

Fast flashing -It means that the feeder is connecting to wifi network;

Solid light -It means the wifi network is connected successfully;

Image: Visual guide for connecting the feeder to the DOGNESS mobile application, detailing app download, device pairing, and Wi-Fi setup.

1. **Download the DOGNESS App:** Search for "DOGNESS" in the Apple App Store or Google Play Store and download the application.
2. **Register/Log In:** Open the app and create a new account or log in if you already have one.
3. **Add Device:**
 - In the app, click the "+" button to add a new device.
 - Select "Feeder Mini F05" or similar model from the list.
 - **Reset Button:** Press and hold the "Reset" button on the feeder for 6 seconds until you hear a "beep" three three times. The Wi-Fi indicator light will flash green.
 - Enter your **2.4GHz Wi-Fi network name and password** *Note: The app only supports 2.4GHz Wi-Fi networks. If you have a 5GHz router, ensure your 2.4GHz band is enabled and connect your phone to it during setup.*
 - Follow the on-screen prompts to complete the connection. The Wi-Fi indicator light will turn solid green once connected successfully.

If you encounter issues during setup, please refer to the Troubleshooting section or contact customer support at support@dogness.com.

OPERATING INSTRUCTIONS

1. Filling the Food Hopper

- Open the top lid of the feeder.
- Pour dry pet food into the hopper. Ensure the food is suitable for automatic feeders (kibble size should be appropriate to prevent clogging).
- Close the lid securely to maintain food freshness.

2. Scheduling Feedings via App

- Open the DOGNESS app and select your feeder.
- Navigate to the "Feeding Schedule" or "Timer" section.
- Set the desired feeding times (up to 6 meals per day).
- Choose the number of portions for each meal (up to 15 portions). One portion is approximately 10g of dry food.
- Save your settings. The feeder will now dispense food automatically at the scheduled times.

3. Manual Feeding

- From the app's main screen for your feeder, you can manually dispense food by tapping the "Feed Now" or similar button.
- You can usually select the number of portions to dispense manually.

4. Voice Recording

Feed Your Pet On Time



Work



Business Trip



Travel



Image: Depiction of the feeder's voice recording function, showing a pet responding to a recorded message.

- In the DOGNESS app, find the "Voice Recording" or "Record Message" option.
- Press and hold the record button in the app to record a 10-second message.
- This message will play automatically at each scheduled feeding time to call your pet.

MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your pet feeder.

- **Food Bowl:** The stainless steel food bowl is removable and can be hand-washed with mild soap and water. Rinse thoroughly and dry completely before reattaching.
- **Food Hopper:** Wipe the inside of the food hopper with a damp cloth. Ensure it is completely dry before refilling with food. Do not immerse the main unit in water.
- **Dispenser Mechanism:** Periodically check the dispenser mechanism for any food residue or blockages. Use a soft brush or cloth to clean.

- **Exterior:** Wipe the exterior of the feeder with a soft, dry cloth.
- **Battery Replacement:** If using battery backup, replace batteries when the low battery indicator appears or if the feeder stops functioning during a power outage.

Care Instructions: Hand Wash Only for removable parts. Do not put any electronic components in the dishwasher.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Feeder not dispensing food.	<ul style="list-style-type: none"> • Food hopper is empty. • Food blockage in dispenser. • No power or low battery. • Incorrect schedule settings. 	<ul style="list-style-type: none"> • Refill food hopper. • Check and clear any blockages. • Ensure power adapter is connected or replace batteries. • Verify schedule settings in the app.
Cannot connect to Wi-Fi.	<ul style="list-style-type: none"> • Incorrect Wi-Fi password. • Not connected to 2.4GHz network. • Feeder too far from router. • Feeder not in pairing mode. 	<ul style="list-style-type: none"> • Double-check Wi-Fi password. • Ensure your phone is connected to a 2.4GHz Wi-Fi network during setup. • Move feeder closer to the router. • Perform a factory reset (hold reset button for 6 seconds) and try pairing again.
Voice recording not playing.	<ul style="list-style-type: none"> • No recording saved. • Volume too low. 	<ul style="list-style-type: none"> • Record a new message in the app. • Check app settings for volume control (if available).

If the problem persists, please contact DOGNESS customer support for further assistance.

SPECIFICATIONS

Model	B09TVMDDWR
Dimensions (LxWxH)	9 x 8 x 12 inches
Weight	3.84 Pounds
Material	Plastic, Stainless Steel
Power Supply	Power Adapter, 3 x D Batteries (not included)
Wi-Fi Frequency	2.4GHz only
Max Meals/Day	6
Max Portions/Meal	15
Voice Recording	10 seconds
Target Species	Cat, Dog (Small to Medium Breeds)

WARRANTY AND SUPPORT




DOGNESS products come with a standard manufacturer's warranty. Please refer to the warranty card included with your product or visit the official DOGNESS website for detailed warranty terms and conditions.

For technical support, product inquiries, or warranty claims, please contact DOGNESS customer service:

- **Email:** support@dogness.com
- **Website:** www.dogness.com (Please check the official website for the most current contact information.)

When contacting support, please have your product model number (B09TVMDDWR) and purchase information ready.

Related Documents

	<p>Dogness App Feeder F03 Instruction Manual</p> <p>Comprehensive instruction manual for the Dogness App Feeder F03, covering setup, app connection, troubleshooting, and safety precautions for automated pet feeding.</p>
	<p>Dogness Smart Cam Feeder F01 User Manual</p> <p>User manual for the Dogness Smart Cam Feeder F01, detailing specifications, installation, and usage instructions for this smart pet feeder.</p>
	<p>Dogness App Feeder F03 FCC Compliance Information</p> <p>FCC compliance details for the Dogness App Feeder Model F03, manufactured by Dongguan Jiasheng Enterprise Co., Ltd. Includes FCC ID and operating conditions.</p>