

[Manuals.plus](#) /

› [Lamshaw](#) /

› Lamshaw Magnetic USB Charging Cable for MorePro HM08 / FITVII HM08 Fitness Trackers User Manual

Lamshaw Magnetic USB Charging Cable

Lamshaw Magnetic USB Charging Cable User Manual for MorePro HM08 / FITVII HM08 Fitness Trackers

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Lamshaw Magnetic USB Charging Cable. This cable is specifically designed for compatibility with MorePro HM08 and FITVII HM08 fitness trackers. Please read this manual thoroughly before use to ensure proper operation and longevity of your product.

PRODUCT OVERVIEW

The Lamshaw Magnetic USB Charging Cable is a replacement charging solution for your compatible fitness tracker. It features a magnetic connector for easy attachment to your device and a standard USB-A plug for connecting to a power source.



Image 1: Two Lamshaw Magnetic USB Charging Cables. Each cable features a USB-A connector on one end and a magnetic charging puck with two contact pins on the other end. The cables are black.

Key features include:

- **Magnetic Connection:** Ensures a secure and stable connection to your fitness tracker.
- **USB-A Compatibility:** Plugs into any standard USB power adapter, computer USB port, or power bank.
- **Built-in Protection:** Includes short-circuit protection to prevent overvoltage and overcurrent, enhancing charging safety.
- **Durable Design:** Constructed with ABS+PC materials and a flexible PVC cable for durability and ease of storage.



Image 2: Diagram illustrating the components of the charging cable. It highlights the durable ABS+PC material for the magnetic head, pure copper probes for stable conduction, and a flexible PVC cable for easy storage. The cable length is indicated as 3.3 feet / 1 meter.

SETUP

1. **Unpack the Cable:** Carefully remove the charging cable from its packaging.
2. **Identify Components:** Locate the magnetic charging end and the USB-A plug end of the cable.
3. **Prepare Power Source:** Ensure you have a compatible USB power source, such as a wall adapter (5V/1A recommended), a computer USB port, or a power bank.

OPERATING INSTRUCTIONS: CHARGING YOUR DEVICE

Follow these steps to charge your MorePro HM08 or FITVII HM08 fitness tracker:

1. **Connect to Power:** Insert the USB-A end of the charging cable into a powered USB port.
2. **Attach to Tracker:** Align the magnetic charging end of the cable with the charging contacts on the back of

your fitness tracker. The magnets will automatically snap the connector into place. Ensure the pins on the charger align correctly with the contacts on the tracker.

3. **Verify Charging:** Once connected, your fitness tracker should display a charging indicator on its screen. If no indicator appears, adjust the magnetic connector to ensure proper contact.
4. **Charging Time:** A full charge typically takes approximately 2.5 hours when using a 1A output current power source.



Image 3: A black fitness tracker with a screen displaying time and activity metrics, connected to the magnetic charging cable. The magnetic end of the cable is attached to the side of the tracker, showing the charging connection.

ORIGINAL HIGH-SPEED CHARGING



Image 4: An illustration depicting a fitness tracker being charged by the magnetic cable. A clock icon indicates "2.5 Hours" for a full charge with a 1A output current, emphasizing efficient charging.

Safety Feature:

The charger includes a built-in short-circuit protection IC. This integrated circuit automatically cuts off power in case of a short circuit, preventing damage from overvoltage or overcurrent. This feature also helps maintain safety if the charger remains plugged in after the device is fully charged.

MAINTENANCE

- **Cleaning:** Gently wipe the cable and magnetic contacts with a dry, soft cloth to remove dust or debris. Do not use liquid cleaners.
- **Storage:** Store the cable in a cool, dry place away from direct sunlight and extreme temperatures. The flexible PVC cable allows for easy coiling and storage.
- **Handling:** Avoid bending the cable sharply or applying excessive force to the connectors, as this can damage internal wires.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging.	• Improper connection. • Faulty USB power source. • Incompatible device. • Damaged cable.	• Ensure the magnetic connector is firmly attached and aligned with the tracker's charging contacts. • Try a different USB port or power adapter. • Verify your fitness tracker is a MorePro HM08 or FITVII HM08 model. • Inspect the cable for visible damage. If damaged, discontinue use.
Slow charging.	• Low-power USB port. • Background processes on tracker.	• Use a dedicated wall adapter (e.g., 5V/1A) instead of a computer USB port. • Ensure the tracker's screen is off and no intensive activities are running during charging.
Magnetic connection is weak.	• Debris on contacts. • Wear and tear.	• Clean the magnetic contacts on both the cable and the tracker. • If the issue persists, the cable may need replacement.

SPECIFICATIONS

- **Brand:** Lamshaw
- **Model Compatibility:** MorePro HM08, FITVII HM08 Fitness Trackers
- **Connector Type:** USB-A (input), Magnetic (output)
- **Cable Type:** USB
- **Special Features:** Magnetic connection, Short-circuit protection, Travel-friendly
- **Material:** ABS+PC (connector housing), Flexible PVC (cable), Pure Copper (probes)
- **Cable Length:** Approximately 3.3 feet (1 meter)
- **Item Weight:** Approximately 0.04 Kilograms (1.23 ounces)
- **Recommended Use:** Charging and powering portable electronic devices (fitness trackers)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your original purchase or contact the seller directly. Keep your purchase receipt for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09TVVYMWG>

More documents and user manuals: <https://manuals.plus/>