

Manuals.plus /

› Telituny /

› Telituny DT9205A Digital Multimeter User Manual

Telituny DT9205A

Telituny DT9205A Digital Multimeter User Manual

Model: DT9205A | Brand: Telituny

1. INTRODUCTION AND PRODUCT OVERVIEW

The Telituny DT9205A is a versatile and multifunctional digital multimeter designed for both industrial and home use. It provides accurate measurements for various electrical parameters, making it an essential tool for electricians, DIY enthusiasts, and technicians.

Key functions include:

- AC/DC Current and Voltage testing
- Resistance measurement
- Capacitance testing
- Continuity and Diode testing
- hFE (transistor gain) measurement
- Active and neutral wire identification






Figure 1: Telituny DT9205A Digital Multimeter. This image displays the front view of the multimeter, showcasing its large LCD screen, rotary dial, and input jacks.

2. SAFETY INFORMATION

Always observe basic safety precautions when using this multimeter to prevent personal injury or damage to the meter or equipment under test. Read the following safety information carefully before operation.

- **Do not** exceed the maximum input value of any range.
- **Do not** use the meter if it or the test leads appear damaged.
- **Do not** use the meter if the battery cover is not properly closed.

- Always turn off the power to the circuit and discharge all high-voltage capacitors before testing resistance, continuity, diodes, or capacitance.
- Use caution when working with voltages above 30V AC RMS, 42V peak, or 60V DC. These voltages pose a shock hazard.
- Remove test leads from the meter before opening the battery cover.
- Ensure the function switch is in the correct position for the desired measurement before connecting the test leads to the circuit.

3. PRODUCT COMPONENTS AND FEATURES

Familiarize yourself with the different parts of your DT9205A Digital Multimeter for effective and safe operation.



Figure 2: Labeled diagram of the DT9205A Multimeter. This image highlights key components such as the HD screen, silicone sheath, data retention button, indicator light, range dial, hFE jack, and various input jacks (20A current, mA current, COM, VΩ, Red test lead, Black test lead).

- **HD Screen:** Large digital display for clear readings.
- **Silicone Sheath:** Protective cover to prevent damage from drops and scratches.

- **HOLD Button:** Freezes the current reading on the display.
- **Indicator Light:** Provides visual feedback during certain tests.
- **Range Dial:** Rotary switch to select measurement functions and ranges.
- **Input Jacks:**
 - **VΩmA:** Input for voltage, resistance, and small current measurements.
 - **COM:** Common (negative) input jack for all measurements.
 - **10A/20A:** Input for high current measurements (up to 20A).
 - **hFE Jack:** Socket for testing transistor hFE.

4. SETUP

4.1 Battery Installation

The DT9205A Multimeter requires a 9V battery for operation. Follow these steps to install or replace the battery:

1. Ensure the multimeter is turned OFF and disconnect all test leads from the input jacks.
2. Locate the battery compartment on the back of the multimeter.
3. Use a screwdriver to open the battery cover.
4. Insert a new 9V battery, observing the correct polarity (+ and -) as indicated inside the compartment.
5. Replace the battery cover and secure it with the screw.

RANDOM SHIPMENTS

Two models are sold randomly, both of which are the same product with consistent quality assurance

Battery Model: AAA*2

AAA Battery Slot

As shown in the figure, follow the correct polarity according to the icon in the battery slot



Battery Model: 6F22 9V

9V Battery Slot

Correctly install the positive and negative poles of the battery according to the 9V cable



Figure 3: Battery installation. This image illustrates the process of installing a 9V battery into the multimeter's battery compartment, showing the correct polarity connection.

4.2 Connecting Test Leads

Proper connection of test leads is crucial for accurate and safe measurements.

- Insert the black test lead into the **COM** (common) jack.
- For most measurements (voltage, resistance, capacitance, diode, continuity, hFE, and small current), insert the red test lead into the **VΩmA** jack.
- For high current measurements (up to 20A), insert the red test lead into the **10A/20A** jack.

5. OPERATING INSTRUCTIONS

This section details how to perform various measurements using your DT9205A Multimeter.

5.1 General Measurement Procedure

1. Connect the test leads correctly to the multimeter's input jacks.

2. Turn the rotary dial to the desired measurement function and range. If unsure of the range, start with the highest range and work downwards.
3. Connect the test leads to the circuit or component under test.
4. Read the measurement value on the LCD screen.
5. Disconnect the test leads from the circuit before changing the function or range.

Digital Multimeter

32-Bit Function Range

New Upgrade, More Complete Functions, Novices Can Easily Measure




Figure 4: Close-up of the DT9205A Multimeter's range dial. This image shows the various measurement functions and ranges available on the rotary switch, including resistance, hFE, capacitance, AC/DC voltage, and AC/DC current.

5.2 Specific Measurement Modes

- **AC/DC Voltage Measurement:**

Set the rotary dial to the desired ACV (V~) or DCV (V--) range. Connect the test leads in parallel with the circuit or component to measure voltage. Ensure the red lead is connected to the positive side and the black lead to the negative side for DC voltage.

- **AC/DC Current Measurement:**

Set the rotary dial to the desired ACA (A~) or DCA (A--) range. Connect the multimeter in series with the circuit. For currents up to 200mA, use the VΩmA jack. For currents up to 20A, use the 10A/20A jack. Always ensure the

circuit is de-energized before connecting the multimeter in series.

- **Resistance Measurement (Ω):**

Set the rotary dial to the desired Ω range. Ensure the circuit is de-energized and all capacitors are discharged. Connect the test leads across the component to measure its resistance.

- **Capacitance Measurement (F):**

Set the rotary dial to the desired F range. Ensure the capacitor is fully discharged before connecting the test leads. Connect the test leads across the capacitor terminals.

- **Diode Test:**

Set the rotary dial to the diode test symbol. Connect the red lead to the anode and the black lead to the cathode of the diode. The display will show the forward voltage drop. Reverse the leads to check for open circuit (OL) in reverse bias.

- **Continuity Test:**

Set the rotary dial to the continuity test symbol. If the resistance between the two points is below approximately 70Ω , the built-in buzzer will sound, indicating continuity.

- **hFE Test (Transistor Gain):**

Set the rotary dial to the hFE position. Insert the NPN or PNP transistor leads into the corresponding holes in the hFE jack. The display will show the hFE value (0-1000).



AC Voltage Measurement



DC Voltage Measurement



Diode Measurement



Buzzer Measurement

Figure 5: Examples of multimeter measurements. This image demonstrates the multimeter being used for AC Voltage Measurement, DC Voltage Measurement, Diode Measurement, and Buzzer Measurement, showing typical setups and readings.

6. APPLICATIONS

The Telituny DT9205A Digital Multimeter is a versatile tool suitable for a wide range of applications:

- **Home Electrical Work:** Testing household electrical outlets, troubleshooting wiring, and checking fuses.
- **Automotive Diagnostics:** Checking car battery voltage, troubleshooting automotive circuits, and testing charging systems.
- **Electronics Repair:** Testing components like resistors, capacitors, diodes, and transistors in electronic circuits.
- **DIY Projects:** Essential for various do-it-yourself electrical and electronic projects.
- **Educational Purposes:** Ideal for students and hobbyists learning about electronics and electrical principles.

Versatile Usability


One device for home, school, laboratory or industrial uses!




Car Battery Test



Appliances Repair



Laboratory



DIY Tool

Figure 6: Versatile usability of the DT9205A Multimeter. This image shows the multimeter being used in various scenarios: Car Battery Test, Appliances Repair, Laboratory settings, and as a general DIY Tool.

7. MAINTENANCE

Proper maintenance ensures the longevity and accuracy of your multimeter.

7.1 Cleaning

Wipe the case with a damp cloth and mild detergent. Do not use abrasives or solvents. Periodically clean the input jacks with a cotton swab and alcohol to ensure good contact.

7.2 Battery Replacement

When the battery indicator appears on the display, replace the 9V battery as described in Section 4.1. Prompt battery replacement ensures accurate readings and prevents potential damage from a low battery.

7.3 Fuse Replacement

The multimeter is protected by internal fuses. If the current measurement function stops working, the fuse may need

replacement. This typically requires opening the back casing of the multimeter. Refer to the specifications for the correct fuse type and rating. It is recommended that fuse replacement be performed by qualified personnel.

EXPLODED VIEW

Smart motherboard, internal parts, high-definition screen, product layering makes your vision more intuitive



Figure 7: Exploded view of the DT9205A Multimeter. This image provides an internal look at the multimeter, showing its smart motherboard, internal components, and high-definition screen, illustrating the product's layered design.

7.4 Storage

If the meter is not to be used for a long period, remove the battery to prevent leakage and damage to the meter.

8. TROUBLESHOOTING

If you encounter issues with your DT9205A Multimeter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No display or dim display	Low or dead battery; Incorrect battery installation	Replace battery; Check battery polarity
"OL" (Overload) displayed	Measurement exceeds selected range; Open circuit (for continuity/resistance)	Select a higher range; Check circuit connection
Incorrect readings	Incorrect function/range selected; Poor test lead connection; Damaged test leads	Verify function/range; Ensure secure connections; Replace test leads if damaged
Current measurement not working	Blown fuse	Replace internal fuse (refer to Maintenance section)

9. SPECIFICATIONS

The following table provides detailed technical specifications for the DT9205A Digital Multimeter:



Features	Range	Resolution	Accuracy
AC voltage	2V-750V	1mV-1V	$\pm(1.2\% \text{ of rdg} + 3 \text{ dgts})$
DC voltage	20mV-1000V	100 μ V-1V	$\pm(1.2\% \text{ of rdg} + 5 \text{ dgts})$
DC current	2mA-20A	1 μ A-100mA	$\pm(2.5\% \text{ of rdg} + 5 \text{ dgts})$
AC current	2mA-20A	1 μ A-10mA	$\pm(3\% \text{ of rdg} + 5 \text{ dgts})$
Resistance	200 Ω	0.1 Ω	$\pm(1.0\% \text{ of rdg} + 10 \text{ dgts})$
	2k Ω -2M Ω	1 Ω -1k Ω	$\pm(0.8\% \text{ of rdg} + 3 \text{ dgts})$
	20M Ω	10k Ω	$\pm(1.2\% \text{ of rdg} + 8 \text{ dgts})$
	200m Ω	100K Ω	$\pm 5\%$ (reading-10 words) ± 10 words
Capacitance	2nF-2 μ F	1pF-1nF	$\pm(4\% \text{ of rdg} + 3 \text{ dgts})$
	200 μ F	110nF	$\pm(5\% \text{ of rdg} + 5 \text{ dgts})$
Buzzer	When the measured voltage is about $<70\Omega$, the buzzer will sound		
Triode	Can measure the hFE parameters of NPN or PNP transistors (0-1000)		
Data retention			
Diode			
Battery	9V battery	Weight	158.6g
Maximum display	1999	Material	ABS

Figure 8: DT9205A Multimeter specifications table. This image provides a detailed table outlining the features, ranges, resolutions, and accuracies for AC voltage, DC voltage, DC current, AC current, resistance, and capacitance measurements, along with information on

buzzer, triode, data retention, diode, battery, weight, and material.

Feature	Range	Resolution	Accuracy
AC Voltage	2V-750V	1mV-1V	$\pm(1.2\% \text{ of rdg}+3\text{dgts})$
DC Voltage	20mV-1000V	100 μ V-1V	$\pm(1.2\% \text{ of rdg}+5\text{dgts})$
DC Current	2mA-20A	1 μ A-100mA	$\pm(2.5\% \text{ of rdg}+5\text{dgts})$
AC Current	2mA-20A	1 μ A-10mA	$\pm(3\% \text{ of rdg}+5\text{dgts})$
Resistance	200 Ω -20M Ω	0.1 Ω -10k Ω	Varies by range
Capacitance	2nF-200 μ F	1pF-110nF	Varies by range
Battery	9V battery		
Weight	158.6g		
Material	ABS		
Maximum Display	1999 counts		

9.1 Dimensions



Figure 9: DT9205A Multimeter dimensions. This image provides a visual representation of the multimeter's physical dimensions, including its length (172.9mm / 6.8in), width (87.7mm / 3.45in), and thickness (33.9mm / 1.33in).

10. WARRANTY AND SUPPORT

Telituny stands behind the quality of its products. This multimeter comes with a product guarantee. For any issues or inquiries regarding your DT9205A Multimeter, please contact Telituny customer support via email. We are committed to providing the best customer assistance and will respond to your concerns within 24 hours.

Please refer to your purchase documentation or the seller's information for specific warranty terms and contact details.

