

KitchenAid KFCB529Q

KitchenAid Cordless 5 Cup Food Chopper KFCB529Q User Manual

Model: KFCB529Q

1. INTRODUCTION

Thank you for choosing the KitchenAid Cordless 5 Cup Food Chopper. This appliance is designed for convenient food preparation, offering the flexibility of cordless operation. Powered by a rechargeable Lithium Ion battery, it allows you to chop, whip, and puree ingredients without being tethered to an outlet. This manual provides essential information for safe and effective use of your food chopper.

2. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before using the food chopper.
- To protect against risk of electrical shock, do not immerse the motor base, charger, or electrical cord in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact KitchenAid for examination, repair, or adjustment.
- The use of attachments not recommended or sold by KitchenAid may cause fire, electric shock, or injury.
- Do not use outdoors. For indoor use only.
- Do not let cord hang over edge of table or counter.
- Do not let cord contact hot surfaces.
- Be careful when handling the sharp processing blades, emptying the bowl, and during cleaning.
- Always ensure the lid is securely locked in place before operating the appliance.

3. PARTS AND FEATURES

Familiarize yourself with the components of your KitchenAid Cordless 5 Cup Food Chopper.

- **Motor Base:** Contains the rechargeable battery and motor.
- **5-Cup Work Bowl:** Transparent bowl for processing ingredients.

- **Lid:** Secures the work bowl and contains the lid handle.
- **Multi-Purpose Blade:** Stainless steel blade for chopping and pureeing.
- **Whisk Accessory:** For whipping ingredients.
- **Charger:** Universal charger for the battery.



Image 1: The KitchenAid Cordless 5 Cup Food Chopper, showing the main unit, work bowl, lid, and the included charger.



Image 2: Side view of the KitchenAid Cordless 5 Cup Food Chopper, highlighting its cordless design.

4. SETUP

4.1 Charging the Battery

1. Connect the charger to a power outlet.
2. Plug the charger into the charging port located on the motor base of the food chopper.
3. The battery indicator lights on the motor base will illuminate to show the charging status. A full charge allows for chopping up to 40 onions (based on 90-110 gram onions). A quick 10-minute charge can process up to 11 onions.
4. Once fully charged, disconnect the charger.

4.2 Assembly

1. Place the motor base on a clean, dry, flat surface.
2. Carefully place the multi-purpose blade or whisk accessory onto the drive pin inside the work bowl.
3. Add your ingredients to the work bowl. Do not overfill.
4. Place the lid onto the work bowl, aligning the lid tab with the handle of the work bowl. Twist the lid clockwise until it locks securely into place.
5. Place the assembled work bowl and lid onto the motor base, ensuring it is seated correctly.

5. OPERATING INSTRUCTIONS

The KitchenAid Cordless 5 Cup Food Chopper features a simple control dial for operation.



Image 3: A user operating the KitchenAid Cordless 5 Cup Food Chopper to chop onions, demonstrating its portability.

5.1 General Operation

1. Ensure the food chopper is properly assembled and the lid is locked.
2. Turn the control dial to the desired speed setting (1 or 2).
3. Process ingredients until the desired consistency is achieved. For coarse chopping, use short pulses. For finer results, process continuously.
4. Once finished, turn the control dial to '0' (Off) and wait for the blade to stop completely before removing the lid.

5.2 Chopping, Whipping, and Pureeing

The multi-purpose blade is ideal for chopping vegetables, nuts, and herbs, as well as pureeing fruits and cooked foods. The whisk accessory is designed for whipping cream or eggs.

Chop, Whip and Puree to perfection



Chop

For salsa, dips and more



Whip

For homemade whipped cream



Puree

For sauces, soups and more

Image 4: Visual examples of results from chopping (salsa), whipping (whipped cream), and pureeing (sauce) using the food chopper.

- **Chopping:** Use the multi-purpose blade. Cut larger ingredients into 1-inch pieces before adding to the bowl. Use pulse action for best control over consistency.
- **Whipping:** Use the whisk accessory. This is suitable for whipping cream or egg whites. Ensure the bowl is clean and dry for optimal results.
- **Pureeing:** Use the multi-purpose blade. Add liquids as needed to achieve desired puree consistency.

6. CARE AND CLEANING

Proper cleaning ensures the longevity and hygiene of your food chopper.

1. Always unplug the charger and ensure the unit is off before cleaning.
2. The work bowl, lid, multi-purpose blade, and whisk accessory are dishwasher-safe (top rack recommended).
3. To clean the motor base, wipe it with a damp cloth. Do not immerse the motor base in water or any other liquid.
4. Ensure all parts are thoroughly dry before reassembling or storing.

7. TROUBLESHOOTING

If you experience issues with your food chopper, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Chopper does not turn on.	Battery is depleted. Unit not assembled correctly.	Charge the battery. Ensure the work bowl and lid are securely locked onto the motor base.
Food is not chopping evenly.	Work bowl is overfilled. Ingredients are too large.	Reduce the amount of food in the bowl. Cut ingredients into smaller, uniform pieces. Use pulse action.
Battery is not charging.	Charger not properly connected. Faulty outlet.	Ensure the charger is firmly plugged into both the unit and a working electrical outlet. Try a different outlet.
Lid is difficult to remove or attach.	Lid or bowl not aligned correctly.	Ensure the lid tab aligns with the work bowl handle before twisting to lock or unlock.

8. SPECIFICATIONS

Technical details for the KitchenAid Cordless 5 Cup Food Chopper.


- **Model:** KFCB529Q
- **Capacity:** 5 Cups
- **Power Source:** Rechargeable Lithium Ion Battery
- **Blade Material:** Stainless Steel
- **Product Dimensions:** 6.61"D x 5.51"W x 10.39"H
- **Item Weight:** 4.12 pounds
- **Color:** Onyx Black
- **Care Instructions:** Dishwasher Safe (select parts)

9. WARRANTY AND SUPPORT

For warranty information or product support, please contact KitchenAid customer service. Details regarding your specific warranty coverage can typically be found in the product packaging or on the official KitchenAid website. Please have your model number (KFCB529Q) and proof of purchase available when contacting support.



Related Documents - KFCB529Q

 A silver and black KitchenAid Food Chopper KFC3510. The device has a clear plastic chopping bowl with a black lid and a black handle. The base is silver with a black control panel. The KitchenAid logo and model number are visible on the top of the base.	<p>KitchenAid Food Chopper KFC3510 User Manual and Safety Guide</p> <p>Comprehensive user manual for the KitchenAid Food Chopper KFC3510. Includes parts and features, important safety precautions, product usage instructions, troubleshooting tips, and warranty information. Available in English, French, and Spanish.</p>
--	---