

Creality Ender 3 X

Creality Ender 3 X 3D Printer Instruction Manual

Model: Ender 3 X

1. INTRODUCTION

This manual provides detailed instructions for the assembly, setup, operation, and maintenance of your Creality Ender 3 X 3D Printer. Please read this manual thoroughly before operating the printer to ensure proper use and optimal performance.

2. PRODUCT FEATURES

- **Print Size:** 220x220x250mm, offering a generous build volume for various projects.
- **Filament Compatibility:** Supports 1.75mm PLA, ABS, TPU, and other filaments. PLA is recommended for beginners.
- **Print Platform:** Features a durable glass bed for excellent adhesion and easy removal of prints.
- **Rapid Heating:** The hotbed can reach 110°C in just 5 minutes, enabling faster printing and support for materials like ABS.
- **Power Resume Function:** In case of an unexpected power outage, the printer can resume printing from where it left off once power is restored.
- **Printer Body Size:** 440x440x465mm.
- **Printer Body Weight:** 6.62 KG.

3. UNBOXING AND ASSEMBLY

Carefully unpack all components and ensure all parts are present before beginning assembly. Refer to the included quick start guide for detailed steps.




Figure 3.1: Overview of the Creality Ender 3 X 3D Printer.




Figure 3.2: The Ender 3X features a 220x220x250mm print size and a glass bed.

3.1 Assembly Video Guide

For a visual guide on assembling your printer, please watch the official assembly video. Note that while this video is for the Ender 3 V3 KE, many assembly steps are similar.

Your browser does not support the video tag.

Video 3.1: Creality Ender 3 V3 KE Assembly and Unboxing Guide. This video demonstrates the general assembly process for Creality 3D printers.

3.2 Extruder Installation

The extruder is a critical component for feeding filament. Ensure it is securely installed.

停電復帰

突然の停電に対処するための印刷機能




Figure 3.3: Detailed view of the extruder assembly.

For detailed instructions on installing the extruder, refer to the following video. This video demonstrates the installation of a Sprite Extruder Pro Kit, which may have similar steps to your printer's extruder.

Your browser does not support the video tag.

Video 3.2: Creality Sprite Extruder Pro Kit Installation. This video provides guidance on installing a direct drive extruder.

4. SETUP

4.1 Power Connection and Voltage Adjustment

Before powering on, ensure the voltage switch on the printer's power supply is set to match your local power voltage (e.g., 115V for North America, 230V for Europe/Asia). Incorrect voltage can damage the printer.




Figure 4.1: Locate and adjust the voltage switch on the printer's power supply.

4.2 Bed Leveling

Proper bed leveling is crucial for successful prints. Adjust the print platform to ensure it is level and at the correct distance from the nozzle. Many online resources, including YouTube videos, offer detailed guides on bed leveling for Ender 3 series printers.

4.3 Filament Loading

Load the filament into the extruder according to the instructions provided with your filament or by following general 3D printer filament loading procedures. Ensure the filament feeds smoothly without kinks.

5. OPERATING INSTRUCTIONS

Once assembled and set up, you can begin your first print. Prepare your 3D model using slicing software (e.g., Cura) and save the G-code file to an SD card. Insert the SD card into the printer and select your file from the printer's interface to start printing.



Figure 5.1: The Ender 3 X in operation, printing a detailed figurine.

5.1 Power Resume Function

The Ender 3 X is equipped with a power resume function. If power is unexpectedly interrupted during a print, the printer will automatically save the print progress. Once power is restored, you can resume the print from the last saved point, preventing print failures due to power loss.




Figure 5.2: Illustration of the power resume function, showing print interruption and successful resumption.

6. MAINTENANCE

Regular maintenance ensures the longevity and performance of your 3D printer. Key maintenance tasks include:

- **Nozzle Cleaning:** Periodically clean the nozzle to prevent clogs and ensure smooth filament extrusion.
- **Bed Cleaning:** Clean the print bed regularly to maintain optimal adhesion.
- **Lubrication:** Lubricate moving parts such as lead screws and smooth rods as needed.
- **Belt Tension:** Check and adjust the tension of the X and Y-axis belts to prevent print quality issues.

6.1 Nozzle Cleaning Guide

A clogged nozzle can significantly impact print quality. The following video demonstrates a general method for cleaning a clogged nozzle on a 3D printer.

Your browser does not support the video tag.

Video 6.1: How to clean a clogged nozzle. This video provides general guidance on clearing blockages in 3D printer nozzles.

7. TROUBLESHOOTING

If you encounter issues with your Creality Ender 3 X, consider the following common troubleshooting steps:

- **Print Adhesion Issues:** Ensure the print bed is clean and properly leveled. Adjust bed temperature and first layer settings in your slicing software.
- **Filament Not Extruding:** Check for clogged nozzles (refer to maintenance section), ensure filament is loaded correctly, and verify extruder motor function.
- **Layer Shifting:** Check belt tension on X and Y axes. Ensure the printer is on a stable surface.
- **Poor Print Quality:** Adjust print speed, temperature settings (nozzle and bed), and cooling settings in your slicing software.

For further assistance, consult online communities, manufacturer support, or search for specific issues on platforms like YouTube. Remember to adjust the local voltage for first use and check various reference videos on YouTube for assembly and print platform adjustments. Printing materials have different properties, so pay attention to printing temperatures.

8. SPECIFICATIONS

Specification	Value
Print Size	220x220x250mm
Printable Filament	1.75mm PLA/ABS/TPU etc.
Print Platform	Glass Bed
Rapid Heating	Hotbed reaches 110°C in 5 minutes
Power Resume Function	Supported
Printer Body Size	440x440x465mm
Printer Body Weight	6.62 KG
Compatible OS	Windows, macOS
Connection Method	USB
Material	Stainless Steel
Color	Black

9. WARRANTY AND SUPPORT

The Creality Ender 3 X 3D Printer comes with a one-year warranty period. If you have any problems or defects, please feel free to contact us for assistance. Our support team is available to help with any questions or issues you may encounter.

For additional resources and support, you can visit the official Creality website or scan the QR code often found on the printer for quick access to online resources.

[Official Creality QR Code Link](#)

