

Oral-B Pro 300

Oral-B MEUKPE Pro 300 Sensitive Clean Vitality Electric Toothbrush User Manual

Model: Pro 300

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Oral-B MEUKPE Pro 300 Sensitive Clean Vitality Electric Toothbrush. Please read this manual thoroughly before first use and retain it for future reference.

IMPORTANT SAFETY INFORMATION

- Do not use this product if it appears damaged in any way.
- Do not modify or repair the product. This may result in fire, electric shock, or injury. Consult your dealer for repairs.
- This product is not intended for use by children under 3 years of age.
- Keep the charger and power cord away from water. Do not place or store the charger where it can fall or be pulled into a tub or sink.
- If the product is dropped, the brush head should be replaced before the next use, even if no visible damage is apparent.
- Do not use attachments or brush heads not recommended by Oral-B.
- Consult your dentist before using this product if you have had oral surgery or gum surgery in the previous two months.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 Oral-B Vitality Electric Toothbrush Handle
- 1 Sensitive Clean Replacement Brush Head
- 1 Charger



Image: The Oral-B Pro 300 electric toothbrush handle, a Sensitive Clean brush head, and the charging base.

SETUP

1. Charging the Toothbrush

Before first use, charge the toothbrush for at least 16 hours. The charging indicator light (if present, refer to your specific model's

design) will illuminate during charging. Once fully charged, the toothbrush can be left on the charger without risk of overcharging.

1. Plug the charger into an electrical outlet.
2. Place the toothbrush handle on the charging unit.

A full charge typically provides approximately 8 days of regular brushing (twice daily for 2 minutes).

2. Attaching the Brush Head

Align the brush head with the shaft of the toothbrush handle and push it down until it clicks into place.



Image: A close-up of the round brush head, highlighting its design for effective cleaning.

OPERATING INSTRUCTIONS

1. Brushing Your Teeth

1. Wet the brush head and apply a small amount of toothpaste.

2. Place the brush head on your teeth, holding it at a slight angle towards the gumline.
3. Press the On/Off button to start brushing.
4. Guide the brush head slowly from tooth to tooth, allowing it to clean each tooth surface for a few seconds. Do not scrub vigorously.
5. The toothbrush features a built-in 2-minute timer. It will briefly pause or emit a different sound after 2 minutes to indicate the recommended brushing time has been reached.
6. After brushing, press the On/Off button again to turn off the toothbrush.

Sensitive Mode



Image: A person using the Oral-B electric toothbrush, illustrating the gentle cleaning action of the extra-soft bristles.

Dentist-Inspired Round Brush Head



Image: An animated representation of the toothbrush bristles effectively cleaning teeth and protecting gums.

2. Sensitive Mode

The Oral-B Pro 300 is designed with a Sensitive Mode for a personalized and gentle brushing experience. This mode provides a softer vibration, ideal for individuals with sensitive teeth and gums.

Built-in 2-Min Timer



Image: An icon representing the Sensitive Mode, depicted as a feather, indicating a gentle cleaning setting.

3. Built-in 2-Minute Timer

The toothbrush includes a professional timer that signals every 30 seconds to move to the next quadrant of your mouth, and a longer signal after 2 minutes to indicate that you have brushed for the dentist-recommended time.



Trust the brush
Dentists use the most
worldwide

Image: An icon illustrating the built-in 2-minute timer feature of the toothbrush.

MAINTENANCE

1. Cleaning After Use

- After brushing, rinse the brush head thoroughly under running water with the handle switched on.
- Turn off the handle and remove the brush head.
- Rinse both the brush head and the handle separately under running water.
- Wipe the handle dry with a cloth.
- Store the toothbrush in an upright position to allow it to air dry.

2. Replacing the Brush Head

Dentists recommend replacing your brush head every 3 months, or sooner if the bristles become splayed or frayed. Indicator bristles will fade halfway to signal when to replace your brush head.



Image: A visual reminder to replace the toothbrush brush head every three months for optimal cleaning performance.

3. Battery Care

To maintain the maximum capacity of the rechargeable battery, unplug the charging unit and fully discharge the handle by regular use at least once every 6 months. Then, recharge it fully.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Toothbrush does not turn on.	Battery is discharged.	Charge the toothbrush for at least 16 hours.
Toothbrush does not hold a charge.	Battery capacity reduced.	Ensure proper charging. If issue persists, the battery may need servicing (contact customer support).

Problem	Possible Cause	Solution
Reduced brushing performance.	Worn brush head or low battery.	Replace the brush head. Recharge the toothbrush.
Excessive noise during operation.	Brush head not properly attached or damaged.	Ensure brush head is securely attached. Replace brush head if damaged.

SPECIFICATIONS

- **Model:** Oral-B MEUKPE Pro 300 Vitality
- **Power Source:** Rechargeable Battery (1 P76 battery included)
- **Dimensions:** 4.33 x 2.13 x 8.27 inches (Product)
- **Weight:** 10.58 ounces
- **Special Features:** Brushing Timer, Sensitive Mode
- **Manufacturer:** Procter and Gamble

WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts and accessories, please visit the official Oral-B website or contact Oral-B customer service. Keep your proof of purchase for warranty claims. You can find more information and contact details on the [Oral-B Store on Amazon](#).