

## XPOtool 63316

# XPOtool Portable MMA Electrode Welder

Model: 63316 - User Manual

## 1. INTRODUCTION

---

Thank you for choosing the XPOtool Portable MMA Electrode Welder, Model 63316. This manual provides important information regarding the safe operation, setup, maintenance, and troubleshooting of your welding machine. Please read these instructions carefully before using the device to ensure proper function and personal safety. This welder is designed for Manual Metal Arc (MMA) welding, suitable for both professional and DIY applications, featuring IGBT Inverter technology for stable performance.



Image 1.1: XPOtool Portable MMA Electrode Welder in an operational setting.

## 2. SAFETY INSTRUCTIONS

---

Welding can be dangerous if proper safety precautions are not observed. Always prioritize your safety and the safety of others. Failure to follow these instructions may result in serious injury or property damage.

### 2.1 Personal Protective Equipment (PPE)

- **Welding Helmet:** Always wear a welding helmet with appropriate shade filter to protect your eyes and face from arc rays and sparks.
- **Protective Clothing:** Wear flame-resistant clothing, long sleeves, and trousers to protect skin from burns and UV radiation.
- **Gloves:** Use heavy, flame-resistant welding gloves to protect hands.
- **Footwear:** Wear sturdy, closed-toe shoes, preferably leather, to protect feet from falling objects and sparks.

### 2.2 Work Area Safety

- **Ventilation:** Ensure adequate ventilation to remove welding fumes and gases. Work in an open area or use fume extractors.
- **Fire Hazards:** Keep the work area free of flammable materials. Have a fire extinguisher readily available.
- **Electrical Safety:** Ensure the welding machine is properly grounded. Do not operate in wet conditions. Inspect cables for damage before each use.
- **Clearance:** Maintain a safe distance from bystanders and ensure they are protected from arc flash and sparks.

## 2.3 General Precautions

- Do not touch live electrical parts.
- Disconnect power before performing any maintenance or adjustments.
- Never weld on containers that have held flammable materials.
- Avoid inhaling welding fumes.

## 3. PACKAGE CONTENTS

---

Upon unpacking, please verify that all items listed below are present and undamaged. If any items are missing or damaged, contact your retailer immediately.

- XPOtool Portable MMA Electrode Welder (Model 63316)
- Ground Cable with Clamp
- Welding Cable with Electrode Holder
- Welding Screen (UV protection)
- Wire Brush with Chipping Hammer
- Carrying Strap



Image 3.1: The XPOtool welder shown with its standard accessories, including cables, mask, and chipping hammer.

## 4. PRODUCT OVERVIEW

---

The XPOtool MMA Welder is a compact and efficient welding machine designed for versatility. It incorporates advanced IGBT Inverter technology for stable arc performance.

### 4.1 Main Components

- **Control Panel:** Features a digital display and a rotary knob for current adjustment.
- **Electrode Holder Connection:** Positive (+) terminal for connecting the electrode holder.
- **Ground Clamp Connection:** Negative (-) terminal for connecting the ground clamp.
- **Power Switch:** Located at the rear of the unit.
- **Cooling Fan:** Ensures proper heat dissipation during operation.
- **Carrying Strap:** For easy portability.



Image 4.1: Front view of the XPOtool welder, showing the control panel and cable connections.





Image 4.2: Detailed view of the control panel, including the digital display and current adjustment knob.



Image 4.3: Rear view of the welder, highlighting the power switch and cooling fan.

## 5. SETUP

---

Before starting any welding operation, ensure the welder is placed on a stable, non-flammable surface in a well-ventilated area.

1. **Connect Ground Clamp:** Attach the ground cable to the negative (-) terminal on the front panel of the welder. Secure the ground clamp firmly to the workpiece or a clean, bare metal part of the welding table, ensuring good electrical contact.
2. **Connect Electrode Holder:** Attach the welding cable with the electrode holder to the positive (+) terminal on the front panel. Insert the appropriate electrode into the electrode holder.
3. **Power Connection:** Ensure the welder's power switch (located at the rear) is in the OFF position. Connect the power plug to a standard 230V AC power outlet.
4. **Select Electrode:** Choose an electrode suitable for your material and welding task. The welder supports electrodes from 1.6 mm to 3.2 mm in diameter.



Image 5.1: The XPOtool welder with its power cable, ready for connection to a standard outlet.

## 6. OPERATING INSTRUCTIONS

---

Once the setup is complete and all safety precautions are in place, you can begin welding.

1. **Power On:** Flip the power switch at the rear of the welder to the ON position. The digital display will illuminate.
2. **Adjust Welding Current:** Use the rotary knob on the control panel to set the desired welding current (20-120 A). The optimal current depends on the electrode diameter and material thickness.
3. **Initiate Arc:** Strike the electrode against the workpiece to initiate the arc. The integrated **Hot-Start** function provides an initial surge of current to facilitate easier arc ignition.
4. **Maintain Arc:** Hold the electrode at a consistent angle and distance from the workpiece. The **Arc-Force** function helps stabilize the arc, preventing it from extinguishing during welding.
5. **Prevent Sticking:** If the electrode sticks to the workpiece, the **Anti-Stick** function will automatically reduce the current, allowing you to easily detach the electrode without damaging the machine or the electrode.
6. **Welding Process:** Move the electrode steadily along the joint, maintaining a consistent arc length.
7. **Power Off:** After welding, turn the power switch to the OFF position. Allow the machine to cool down.
8. **Clean Weld:** Use the chipping hammer to remove slag from the weld bead, then clean with the wire brush.

**Note:** Practice on scrap material before attempting critical welds. Always wear appropriate PPE.

## 7. MAINTENANCE

---

Regular maintenance ensures the longevity and reliable performance of your welding machine.

- **Cleaning:** Periodically clean the exterior of the welder with a dry, soft cloth. Use compressed air to blow out dust and debris from the cooling vents, ensuring they are not obstructed.
- **Cable Inspection:** Regularly inspect all welding cables, the electrode holder, and the ground clamp for signs of wear, cuts, or damage. Replace damaged components immediately.
- **Terminal Connections:** Ensure all cable connections are tight and free from corrosion.
- **Storage:** Store the welder in a clean, dry place, away from moisture and extreme temperatures.
- **Duty Cycle:** Observe the duty cycle (35% at maximum current) to prevent overheating. Allow the machine to cool down during prolonged use.

## 8. TROUBLESHOOTING

This section addresses common issues you might encounter during operation.

| Problem                                 | Possible Cause                                                                               | Solution                                                                                                        |
|-----------------------------------------|----------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
| Welder does not power on.               | No power supply; Power switch off; Faulty power cable.                                       | Check power outlet; Ensure power switch is ON; Inspect and replace power cable if damaged.                      |
| Arc is difficult to strike or unstable. | Incorrect current setting; Poor ground connection; Damp electrode; Incorrect electrode type. | Adjust welding current; Ensure ground clamp has good contact; Use dry electrodes; Select appropriate electrode. |
| Electrode sticks frequently.            | Low current setting; Incorrect arc length; Damp electrode.                                   | Increase welding current; Maintain proper arc length; Use dry electrodes. The Anti-Stick function should help.  |
| Welder overheats and shuts down.        | Exceeded duty cycle; Obstructed cooling vents; High ambient temperature.                     | Allow welder to cool down; Clear cooling vents; Work in a cooler environment.                                   |

If the problem persists after attempting these solutions, please contact customer support.

## 9. SPECIFICATIONS

| Feature               | Specification          |
|-----------------------|------------------------|
| Brand                 | XPOtool                |
| Model Number          | 63316                  |
| Welding Process       | MMA (Manual Metal Arc) |
| Technology            | IGBT Inverter          |
| Input Voltage         | AC 230V                |
| Welding Current Range | 20-120 A               |
| Electrode Diameter    | 1.6 - 3.2 mm           |
| Duty Cycle            | 35%                    |
| Color                 | Yellow / Black         |

| Feature                | Specification                    |
|------------------------|----------------------------------|
| Dimensions (L x W x H) | 21 x 6 x 15.5 cm                 |
| Weight                 | 3.1 kg                           |
| Integrated Functions   | Hot-Start, Arc-Force, Anti-Stick |



Image 9.1: Diagram showing the dimensions of the XPOtool Portable MMA Welder.

## 10. WARRANTY AND SUPPORT

Information regarding the product warranty and customer support details was not available in the provided data. For warranty

claims or technical assistance, please refer to the documentation included with your purchase or contact the retailer where the product was acquired.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

### Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

### Details

Submit question