

[manuals.plus](#) /

› [Timex](#) /

› [Timex UFC Takedown 33mm Digital Watch \(Model: TW5M52000JT\) Instruction Manual](#)

Timex TW5M52000JT

Timex UFC Takedown 33mm Digital Watch Instruction Manual

Model: TW5M52000JT

1. INTRODUCTION

This manual provides detailed instructions for the Timex UFC Takedown 33mm Digital Watch, Model TW5M52000JT. This timepiece is designed for durability and functionality, featuring a 100-hour chronograph, 24-hour countdown timer, 10-lap memory recall, customizable alarms, and INDIGLO backlight technology. It is water resistant up to 100 meters.





Figure 1: Front view of the Timex UFC Takedown 33mm Digital Watch.

2. SETUP

2.1 Battery Information

Your watch comes with one Lithium Metal battery (CR2025) pre-installed. The battery is designed for long-lasting performance. When the display dims or functions become erratic, it may be time for a battery replacement.

2.2 Setting Time and Date

To set the time and date:

1. Press the **MODE** button repeatedly until the time setting mode is displayed (usually indicated by flashing digits).
2. Use the **SET/ADJUST** button (or similar, typically on the top right) to select the digit you wish to change (e.g., hours, minutes, year, month, day).
3. Use the **START/STOP** button (or similar, typically on the bottom right) to increase the selected value. Hold to advance rapidly.

4. Repeat steps 2 and 3 for all time and date settings.
5. Press the **MODE** button to exit the setting mode and return to the normal time display.



Figure 2: Side view showing watch buttons for control.

3. OPERATING INSTRUCTIONS

3.1 Mode Navigation

Press the **MODE** button to cycle through the different functions: Time, Chronograph, Timer, and Alarm.

3.2 Chronograph (Stopwatch)

The chronograph measures elapsed time up to 100 hours with 10-lap memory recall.

1. Enter Chronograph mode by pressing **MODE**.
2. Press **START/STOP** to begin timing.
3. Press **START/STOP** again to pause timing. Press again to resume.
4. To record a lap time, press **LAP/RESET** while the chronograph is running. The lap time will display briefly.
5. To reset the chronograph, ensure it is stopped, then press **LAP/RESET**.

3.3 Countdown Timer

The 24-hour countdown timer can be set for various durations.

1. Enter Timer mode by pressing **MODE**.
2. To set the timer, press and hold **SET/ADJUST** until digits flash.
3. Use **SET/ADJUST** to select hours, minutes, or seconds. Use **START/STOP** to adjust the value.
4. Press **MODE** to confirm settings.
5. Press **START/STOP** to start the countdown.
6. An audible alert will sound when the timer reaches zero.

3.4 Alarms

Set customizable alarms to alert you at specific times.

1. Enter Alarm mode by pressing **MODE**.
2. To set an alarm, press and hold **SET/ADJUST** until digits flash.
3. Use **SET/ADJUST** to select hours or minutes. Use **START/STOP** to adjust the value.
4. Press **MODE** to confirm settings.
5. To activate/deactivate the alarm, press **START/STOP** while in Alarm mode (not setting). An alarm icon will appear/disappear.

3.5 INDIGLO Backlight

Press the **INDIGLO** button (typically on the top left) to illuminate the watch face for easy viewing in low-light conditions.



Figure 3: Watch face displaying digital time and features.

4. MAINTENANCE

4.1 Water Resistance

This watch is water resistant to 100 meters (328 feet). This means it is suitable for splashes, rain, and brief immersion in water. It is **not** suitable for swimming, diving, or bathing, especially with hot water or steam, as this can compromise the seals.

- Do not operate buttons underwater.
- Ensure the crown (if applicable) is pushed in completely after setting the time.

4.2 Cleaning

To clean your watch, wipe it with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, which can damage the case or strap.

4.3 Battery Replacement

Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.





Figure 4: Back view of the watch, highlighting the case back.

5. TROUBLESHOOTING

If you encounter issues with your watch, please refer to the following common solutions:

- **No Display or Dim Display:** The battery may be low or depleted. Consider professional battery replacement.
- **Buttons Unresponsive:** Ensure the watch is not in a locked mode (if applicable). If the issue persists, a battery reset (professional service recommended) might be needed.
- **Incorrect Time/Date:** Re-follow the time and date setting instructions in Section 2.2.
- **Water Inside Watch:** Immediately take the watch to a professional watch repair service to prevent further damage.

6. SPECIFICATIONS

Feature	Detail
Model Number	TW5M52000JT
Case Size	33mm
Water Resistance	100m (328ft)
Lens Material	Acrylic
Strap Material	Resin
Backlight	INDIGLO
Battery Type	1 Lithium Metal (CR2025)
Chronograph	100-hour, 10-lap memory
Countdown Timer	24-hour



Figure 5: Key features of the Timex UFC Takedown watch.

7. WARRANTY AND SUPPORT

Your Timex watch is covered by a manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Timex website. For technical support or service inquiries, please contact Timex customer service directly.