

Philco 099323103

User Manual

PHILCO 32" HD LED TV (MODEL: PTV32A21DFH)

Model Number: 099323103

Introduction

This manual provides comprehensive instructions for the installation, operation, maintenance, and troubleshooting of your Philco 32-inch HD LED TV, model PTV32A21DFH. Please read this manual thoroughly before operating your television and retain it for future reference.



Image: Front view of the Philco 32-inch HD LED TV, showcasing its slim bezel and the Philco logo at the bottom center.

Important Safety Information

To ensure safe operation and prevent damage, observe the following precautions:

- Do not expose the TV to rain or moisture.
- Do not block ventilation openings. Ensure adequate space around the TV for proper airflow.
- Protect the power cord from being walked on or pinched.
- Unplug the TV during lightning storms or when unused for long periods.

- Refer all servicing to qualified service personnel.
- Do not open the TV cabinet. High voltage is present inside.

What's in the Box

Verify that all components are present:

- Philco 32" HD LED TV
- TV Stand (2 pieces)
- Remote Control
- Power Cord
- User Manual (this document)

Setup

1. Attaching the Stand

1. Carefully place the TV face down on a soft, clean surface to prevent screen damage.
2. Align each stand piece with the corresponding slots on the bottom of the TV.
3. Secure the stands using the provided screws. Ensure they are firmly attached.



Image: The Philco 32-inch HD LED TV resting on its two-piece stand, ready for placement.

2. Connecting Devices

The TV features multiple input ports for various devices.



Image: Rear view of the Philco TV, highlighting the various input ports including HDMI, USB, and AV inputs.

- **HDMI:** Connect Blu-ray players, game consoles, or set-top boxes. The TV has multiple HDMI ports.
- **USB:** Insert USB drives for media playback.
- **Antenna/Cable:** Connect an antenna or cable TV signal for broadcast channels.
- **AV In:** For older devices using composite video and stereo audio cables.

3. Power Connection

Plug the power cord into the TV's power input, then into a wall outlet. Ensure the voltage matches the TV's requirements (127V or 220V).

Operating Instructions

Power On/Off

- Press the **POWER** button on the remote control or on the TV to turn it on or off.

Input Source Selection

- Press the **SOURCE** or **INPUT** button on the remote control.
- Use the arrow keys to navigate and select the desired input (e.g., HDMI1, USB, AV, TV).
- Press **OK** or **ENTER** to confirm your selection.

Basic Settings

- Volume:** Use the **VOL +/-** buttons.
- Channel:** Use the **CH +/-** buttons for TV channels.
- Menu:** Press the **MENU** button to access picture, sound, and system settings.
- Navigation:** Use arrow keys to navigate menu options and **OK** to select.

Maintenance

Cleaning the TV

- Always unplug the TV before cleaning.
- Use a soft, dry cloth to wipe the screen and cabinet.
- For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive screen cleaner. Do not spray cleaner directly onto the screen.
- Avoid using abrasive cleaners, waxes, or solvents.

General Care

- Keep the TV away from direct sunlight and heat sources.
- Ensure proper ventilation to prevent overheating.
- Do not place heavy objects on top of the TV.

Troubleshooting

Problem	Possible Cause	Solution
No Power	Power cord not connected; Power outlet not working.	Check power cord connection; Test outlet with another device.
No Picture, But Sound	Incorrect input source selected; Loose video cable.	Press SOURCE/INPUT button to select correct input; Check video cable connections.
No Sound, But Picture	Volume too low or muted; Audio cable loose.	Increase volume or unmute; Check audio cable connections.

Problem	Possible Cause	Solution
Remote Control Not Working	Batteries dead or incorrectly inserted; Obstruction between remote and TV.	Replace batteries; Ensure clear line of sight to TV's IR sensor.

Specifications

Feature	Detail
Model Name	PTV32A21DFH (099323103)
Screen Size	32 Inches (82 cm diagonal)
Display Technology	LED
Resolution	720p HD
Aspect Ratio	16:9
Connectivity	HDMI, USB
Voltage	127 Volts, 220 Volts
Wattage	38.2 Watt-hours
Item Weight	7.08 pounds (3.22 Kilograms)
Product Dimensions (L x W x H)	70.87 x 186.22 x 287.4 inches
Manufacturer	AOOEPU
First Available	August 17, 2023

Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Philco website. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance, you may contact Philco customer service through their official channels.

© 2023 Philco. All rights reserved.

Philco



MANUAL DE INSTRUÇÕES
PT V32A21DFH

[pdf] User Manual

Manual TV PHILCO PTV32A21DFH LED 099323103 philco vteximg br Jul 18 2023 — Parabéns pela escolha de um produto da nossa linha Para garantir o melhor desempenho do leia atentamente as recomendações a seguir arquivos |||

PTV32A21DFH Sumário INTRODUÇÃO INSTRUÇÕES AO USUÁRIO 4 CONES DE INSTRUÇÃO 4 LOCAL DE INSTALAÇÃO 5 PRECAUÇÕES QUANTO À SEGURANÇA 5 MANUSEIO E LIMPEZA 6 INFORMAÇÕES IMPORTANTES: 6 MEIO AMBIENTE 7 Embalagem 7 Pilhas 7 Produto 7 CONHECENDO SEU APARELHO 8 CONTEÚDO DA EMBALAGEM 8 MONTAGEM E INSTALAÇÃO...

lang:pt score:25 filesize: 1.55 M page_count: 27 document date: 2022-06-22